

[manuals.plus](#) /

› [Farberware](#) /

› [Farberware Classic Stick Vacuum Cleaner \(Model VCS-90B1\) - Instruction Manual](#)

## Farberware VCS-90B1

# Farberware Classic Stick Vacuum Cleaner

MODEL VCS-90B1 - USER MANUAL

## 1. Product Overview and Components

The Farberware Classic Stick Vacuum Cleaner is designed for efficient cleaning across various floor types. This section details the components included with your vacuum.



**Figure 1:** The Farberware Classic Stick Vacuum Cleaner shown with its main body, extension wand, floor head, crevice tool, dust brush, and wall mount.

#### **Included Components:**

- Corded Stick Vacuum Main Unit
- Floor Head with Lighted Motor Brush
- Extension Wand
- Crevice Tool
- Dust Brush
- Cord Management Accessory
- Hanging Wall Mount
- Washable Filter (pre-installed)

**Video 1:** An overview of the Farberware Classic Stick Vacuum Cleaner, demonstrating its features and versatility.

## **2. Setup**

Follow these steps to assemble your Farberware Classic Stick Vacuum Cleaner:

- 1. Attach the Extension Wand:** Insert the extension wand into the main vacuum unit until it clicks securely into place.
- 2. Attach the Floor Head:** Connect the floor head to the bottom of the extension wand, ensuring it locks firmly.
- 3. Select an Attachment (Optional):** For handheld use or specific cleaning tasks, attach the crevice tool or dust brush directly to the main unit or the extension wand.
- 4. Power Connection:** Ensure the 15-foot power cord is fully extended and plugged into a suitable electrical outlet.



**FARBERWARE®**

**MULTI-PURPOSE**  
**Three Attachments**

Figure 2: The vacuum configured for handheld use with the crevice tool, ideal for cleaning edges and tight spaces.

### 3. Operating Instructions

Your Farberware Classic Stick Vacuum is designed for ease of use across various surfaces.

- 1. Power On/Off:** Plug the power cord into an outlet. Press the power button located on the handle to turn the vacuum on. Press it again to turn off.

2. **Lighted Motor Brush:** The floor head features a lighted motor brush that illuminates dust and debris, ensuring a thorough clean.
3. **Multi-Surface Cleaning:** The powerful 700W motor provides 18,000 PA suction, suitable for hardwood, rugs, and carpets. The swivel head allows for easy navigation around furniture.
4. **Handheld Conversion:** Detach the extension wand and floor head to convert the unit into a handheld vacuum for cleaning upholstery, stairs, or car interiors. Attach the crevice tool or dust brush as needed.

**FARBERWARE**

**LIGHTED MOTOR BRUSH**  
Easily Detect Dirt and Debris

**Figure 3:** The lighted motor brush head effectively highlights dust and debris on various floor surfaces for improved visibility during cleaning.



**FARBERWARE®**

**LARGE DUST BIN**  
0.8L Capacity

**Figure 4:** The vacuum's versatility is shown through its multiple configurations, allowing it to be used as a stick vacuum, handheld unit, or with an extended reach for high-up cleaning.

## 4. Maintenance

Regular maintenance ensures optimal performance of your vacuum cleaner.

- 1. Emptying the Dustbin:** The 0.8L large-capacity dustbin should be emptied regularly. Press the one-button release to detach the dustbin and dispose of collected debris.
- 2. Cleaning the Washable Filter:** The internal filter is washable and reusable. Remove the filter from the dustbin, rinse it under running water, and allow it to air dry completely before reinserting.
- 3. Brush Roll Cleaning:** Periodically check the brush roll for tangled hair or debris. Remove any obstructions to maintain effective cleaning.



Includes Cord Management Accessory

**FARBERWARE®**

**LONG POWER CORD**  
15 Feet to Clean More Areas at Once

Figure 5: The large-capacity dustbin is easily emptied with a one-button release mechanism.

## 5. Troubleshooting

If you encounter any issues with your vacuum cleaner, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check for tripped circuit breakers.
- **Reduced Suction:** Check if the dustbin is full and needs emptying. Inspect the filter for clogs and clean it if necessary. Verify that the brush roll or any attachments are free from blockages.
- **Unusual Noise:** Turn off the vacuum and unplug it. Inspect the brush roll and air pathways for any foreign objects that may be causing the noise.
- **Motor Brush Not Rotating:** Ensure the floor head is properly attached. Check for any obstructions in the brush roll.

If problems persist after attempting these solutions, please contact customer support.

## 6. Specifications

Feature	Specification
Brand	Farberware
Model Name	Classic (VCS-90B1)
Power Source	Corded Electric
Wattage	700 watts
Capacity	0.8 Liters
Special Features	Bagless, Headlight, Lightweight, Portable, Washable Filter
Product Dimensions	11.22" L x 11.18" W x 43.7" H
Item Weight	1 pounds
UPC	728633013067

## 7. Warranty and Support

The Farberware Classic Stick Vacuum Cleaner (Model VCS-90B1) comes with a **3-year warranty** from the date of purchase, covering defects in materials and workmanship under normal household use.

For warranty claims, technical assistance, or to purchase replacement parts, please contact Farberware Customer Support:

- **Website:** [Visit the Farberware Store on Amazon](#)
- **Email:** [support@farberware.com](mailto:support@farberware.com) (example)
- **Phone:** 1-800-FARBERWARE (example)