

Raycon RBO725

Raycon Everyday Open Earbuds Instruction Manual

Model: RBO725

1. SETUP

1.1. Package Contents

Your Raycon Everyday Open Earbuds package includes:

- Raycon Everyday Open Earbuds (Left and Right)
- Charging Capsule
- USB-C Charging Cable

1.2. Initial Charging

Before first use, ensure your earbuds and charging capsule are fully charged. The charging capsule provides up to 40 hours of battery life, with the earbuds holding an 8-hour charge.



The Raycon Everyday Open Earbuds with their sleek charging case.



The charging case extends the earbuds' playtime significantly, offering up to 40 hours of total battery life.

1.3. Bluetooth Pairing

The earbuds utilize Bluetooth 5.2 for stable and seamless connectivity.

1. Open the charging capsule and remove the earbuds. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Select "Raycon Open Earbuds" from the list of available devices.
4. Once connected, you will hear an audible confirmation.

1.4. Achieving the Perfect Fit

The ergonomic design with multi-angular hooks ensures a secure and comfortable fit, allowing you to stay aware of your surroundings.

1. Gently rotate the earbud hooks to align them with your ear shape.
2. Place the earbuds into your ears so the hooks rest naturally over the tops of your ears.
3. Ensure the buds sit just above your ear canal; they are designed to stay put without going directly into your ears.

4. Gently wiggle and rotate the earbuds back and forth to find the most comfortable and secure position.



MULTI-ANGULAR HOOK

Innovative ear hook designed for a perfect fit, allowing earbuds to be angled for personalized positioning.

The multi-angular hook allows for personalized positioning and a secure fit.



40 HOURS OF BATTERY

Get 8 hours of playtime, plus 40 more from the case — power for days on a single charge.

The open-ear design provides comfort and allows for environmental awareness.

2. OPERATING INSTRUCTIONS

2.1. Touch Controls

The Raycon Everyday Open Earbuds feature intuitive touch controls. All functions are activated by tapping or holding the Raycon logo on either earbud.

Earbud Touch Controls

Action	Left Earbud	Right Earbud	Either Earbud
Volume Down	Tap 1x		
Previous Track	Tap 3x		
Volume Up		Tap 1x	
Next Track		Tap 3x	

Action	Left Earbud	Right Earbud	Either Earbud
Play/Pause			Tap 2x
Voice Command			Tap 4x
Answer/End Call			Tap 2x
Reject Call			Hold 3s
Power On			Hold 2s
Power Off			Hold 10s

2.2. Sound Quality & Call Clarity

The earbuds deliver superior sound quality with crisp, clear audio, rich bass, and balanced tones. Digital Signal Processing (DSP) technology enhances speech and blocks external noise, ensuring clear calls in various environments.




OPEN-EAR DESIGN

Breathable, open fit for comfort and safety, keeping you alert while enjoying immersive high-definition audio.



2.3. Multipoint Connectivity

The Raycon Everyday Open Earbuds support multipoint connectivity, allowing you to seamlessly switch between two paired devices without needing to disconnect and reconnect.



The diagram features a central black Raycon Everyday Open Earbud with a white 'R' logo. Four blue line-art icons are connected to the earbud by thin lines: a smartphone and tablet, a stationary bike, a desktop monitor, and a video game controller. A circular icon with two overlapping squares is positioned to the right of the earbud. Below the earbud, the text 'MULTIPOINT CONNECTIVITY' is written in large, bold, blue capital letters. Underneath this, a short horizontal line is followed by the text 'Seamlessly switch audio inputs and spend less time in settings and more time listening to what you love.' in a black serif font.

MULTIPOINT CONNECTIVITY

Seamlessly switch audio inputs and spend less time in settings and more time listening to what you love.

Connect your earbuds to multiple devices simultaneously for effortless switching.

3. MAINTENANCE

3.1. Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.

3.2. Water Resistance

The earbuds are rated IPX5 water resistant, meaning they can withstand splashes and sweat. They are suitable for workouts and outdoor activities, but should not be submerged in water.



CLEAR CALLS

Digital Signal Processing enhances speech and blocks noise, ensuring clear calls in any environment.



IPX5 water resistance protects your earbuds from sweat and splashes.

4. TROUBLESHOOTING

For common issues and solutions, please refer to the official Raycon Product Guide video below. Key troubleshooting topics include charging issues, resetting your earbuds, and fit adjustments.

Your browser does not support the video tag.

Official Raycon Product Guide video for troubleshooting and usage tips.

4.1. Earbuds Won't Charge

- Ensure the charging capsule has sufficient power. The LED lights on the front indicate charge level.
- Check for any obstructions blocking the connection points between the earbuds and the case.
- Place earbuds firmly into the case. A blinking white light on the front of the case indicates charging.

4.2. Charging Capsule Won't Charge

- Use the provided USB-C cable.

- Ensure the cable is firmly connected to both the charging capsule and the power adapter.

4.3. Resetting Your Earbuds (Soft Reset)

- On your device, go to Bluetooth settings and "Forget" or "Remove" "Raycon Open Earbuds" from the list.
- Place both earbuds back into their charging capsule.

4.4. Hard Reset

- Place both earbuds into the charging capsule.
- Close the lid and wait for 5 to 10 seconds. This action performs a hard reset.


5. SPECIFICATIONS






Feature	Detail
Model Name	RBO725
Connectivity Technology	Wireless (Bluetooth 5.2)
Battery Life (Earbuds)	8 Hours
Total Battery Life (with Case)	40 Hours
Water Resistance Level	IPX5
Earpiece Shape	Earhook
Audio Driver Type	Balanced Armature Driver
Frequency Range	20 Hz - 20,000 Hz
Material	Plastic, Silicone
Item Weight	6.7 ounces
UPC	811162032354

6. WARRANTY AND SUPPORT

For warranty information or further assistance, please visit the official Raycon website or contact Raycon customer support directly. You can also find more information at the [Raycon Store on Amazon](#).

Related Documents - RBO725

	<p>Raycon RBO725 Open Earbuds: Safety, Specifications, and Compliance Information</p> <p>This document provides essential safety guidelines, detailed technical specifications, and FCC/IC compliance information for the Raycon RBO725 Open Earbuds, ensuring safe and compliant usage.</p>
---	--

	<p>Raycon Open Earbuds Quick Start Guide</p> <p>A quick start guide for Raycon Open Earbuds, covering connection, functions, and how to wear the earbuds.</p>
	<p>Raycon Open Earbuds User Manual and Guide</p> <p>Comprehensive guide to Raycon Open Earbuds, covering setup, functions, troubleshooting, safety, and specifications. Learn how to connect, charge, and optimize your audio experience.</p>
	<p>Raycon Everyday Earbuds Pro User Manual and Features</p> <p>Comprehensive guide to Raycon Everyday Earbuds Pro, covering features, setup, troubleshooting, safety, and specifications. Learn about ANC, Multipoint, and more.</p>
	<p>Raycon Essential Open Earbuds User Guide</p> <p>Comprehensive user guide for Raycon Essential Open Earbuds, covering setup, features like Multipoint, troubleshooting, safety, and specifications.</p>
	<p>Raycon Everyday Earbuds Classic User Manual: Features, Setup, and Troubleshooting</p> <p>Comprehensive user guide for the Raycon Everyday Earbuds Classic. Discover features like Active Noise Cancellation, Multipoint Connectivity, detailed setup instructions, charging information, fit guidance, troubleshooting tips, safety guidelines, and product specifications.</p>