

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Raycon](#) /

› [Raycon Everyday Open Earbuds User Manual](#)

## Raycon RBO725

# Raycon Everyday Open Earbuds User Manual

Model: RBO725

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Raycon Everyday Open Earbuds. Please read this manual carefully before using your earbuds to ensure optimal performance and longevity.

The Raycon Everyday Open Earbuds are designed for comfort and awareness, allowing you to enjoy audio while remaining connected to your surroundings. They feature a secure hook design, IPX5 water resistance, and extended battery life.

## PACKAGE CONTENTS

Verify that all items are present in your package:

- Raycon Everyday Open Earbuds (Left and Right)
- Charging Capsule
- USB-C Charging Cable
- User Manual



Image: Raycon Everyday Open Earbuds (Blue) with their charging case. The earbuds feature an open-ear hook design, and the case is a sleek, elongated oval shape with LED indicators on the front.

## SETUP

### 1. Charging the Earbuds and Case

Before first use, fully charge your earbuds and charging case.

1. Place both earbuds into the charging capsule. Ensure they are seated correctly.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED indicators on the front of the charging case will light up white to indicate charging. All four LEDs will be solid white when fully charged.



## MULTIPOINT CONNECTIVITY

Seamlessly switch audio inputs and spend less time in settings and more time listening to what you love.

Image: A close-up of the Raycon Everyday Open Earbuds charging case showing four white LED indicator lights, signifying battery level or charging status. The text indicates "8 Hours of Playtime" and "40 Hours of Battery Life" from the case.

### 2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
3. Select "Raycon Open Earbuds" from the list of available devices.
4. Once connected, you will hear an audible confirmation.

### OPERATING INSTRUCTIONS

#### Wearing the Earbuds

The Raycon Everyday Open Earbuds feature a multi-angular hook design for a secure and comfortable fit. They are designed to sit just above your ear canal, allowing for environmental awareness.

1. Gently rotate the ear hooks to align with the natural curve of your ears.
2. Place the earbuds into your ears, ensuring the hooks rest comfortably over the tops of your ears.
3. Adjust the earbuds by gently wiggling and rotating them back and forth until they feel snug and comfortable, sitting just above your ear canal.




## 40 HOURS OF BATTERY

---

Get 8 hours of playtime, plus 40 more from the case — power for days on a single charge.

Image: A close-up of a single Raycon Everyday Open Earbud highlighting its multi-angular hook design, which allows for personalized positioning and a secure fit.



## MULTI-ANGULAR HOOK

Innovative ear hook designed for a perfect fit, allowing earbuds to be angled for personalized positioning.

Image: An illustration showing a Raycon Everyday Open Earbud positioned on an ear, emphasizing its open-ear design that allows for comfort and environmental awareness while listening to audio.

### Touch Controls

The Raycon Everyday Open Earbuds feature intuitive touch controls on each earbud. All controls are activated by tapping or holding the Raycon logo on the earbud.

Action	Left Earbud	Right Earbud	Either Earbud
Volume Down	Tap 1x	-	-
Previous Track	Tap 3x	-	-
Volume Up	-	Tap 1x	-
Next Track	-	Tap 3x	-

Action	Left Earbud	Right Earbud	Either Earbud
Play/Pause	-	-	Tap 2x
Voice Command	-	-	Tap 4x
Answer/End Call	-	-	Tap 2x
Reject Call	-	-	Hold 3s
Power On	-	-	Hold 2s
Power Off	-	-	Hold 10s




Image: A close-up of the blue Raycon Everyday Open Earbuds, showcasing the touch-sensitive Raycon logo on the side of each earbud, which is used for various controls.

## MAINTENANCE

## Cleaning

Regular cleaning helps maintain the performance and hygiene of your earbuds.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both the earbuds and case are clean and free of debris.

## Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

## Water Resistance (IPX5)

The Raycon Everyday Open Earbuds are IPX5 water resistant, meaning they can withstand splashes and sweat. They are not designed for submersion in water.



## CLEAR CALLS

---

Digital Signal Processing enhances speech and blocks noise, ensuring clear calls in any environment.



Image: A black Raycon Everyday Open Earbud with water splashing around it, illustrating its IPX5 water resistance feature. The text highlights its ability to withstand any weather worry-free.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your Raycon Everyday Open Earbuds.

### Earbuds Won't Charge

1. Ensure the charging case has sufficient power. Check the LED indicators on the front of the case.
2. Verify that there is no obstruction blocking the charging contacts on both the earbuds and inside the case.
3. Place the earbuds firmly into the charging case. A blinking white light on the front of the case indicates charging.

Your browser does not support the video tag.

Video: Raycon - The Open Earbuds: Product Guide. This video provides visual instructions on troubleshooting charging issues, resetting earbuds, finding the right fit, and using touch controls for the Raycon Open Earbuds.

### Charging Capsule Won't Charge

1. Ensure the USB-C cable is firmly connected to both the charging case and the power adapter.
2. Try using a different USB-C cable or power adapter to rule out cable/adapter issues.

### Resetting Your Earbuds (Hard Reset)

If you experience connectivity issues or other malfunctions, a hard reset may resolve the problem.

1. On your device, go to Bluetooth settings and "Forget" or "Remove" "Raycon Open Earbuds" from the list of paired devices.
2. Place both earbuds into the charging capsule.
3. Close the lid of the charging capsule and wait for 5 to 10 seconds.
4. Open the lid and re-pair the earbuds with your device as described in the "Pairing with Your Device" section.

## SPECIFICATIONS

Feature	Detail
Model Name	RBO725
Connectivity Technology	Wireless (Bluetooth 5.2)
Battery Life (Earbuds)	8 Hours
Total Battery Life (with Case)	40 Hours
Water Resistance Level	IPX5 (Water Resistant)
Earpiece Shape	Hook
Frequency Range	20 Hz - 20,000 Hz
Control Method	Remote (Touch Controls)
Audio Driver Type	Dynamic Driver

Feature	Detail
Item Weight	6.7 ounces
UPC	811162032361

## WARRANTY AND SUPPORT

For warranty information and customer support, please visit the official Raycon website or contact their customer service directly. Keep your proof of purchase for warranty claims.


If you encounter issues not covered in this manual, please refer to the video guide provided or contact Raycon support for assistance.

Your browser does not support the video tag.

Video: Raycon - The Open Earbuds: Product Guide. This video provides visual instructions on troubleshooting charging issues, resetting earbuds, finding the right fit, and using touch controls for the Raycon Open Earbuds.

© 2024 Raycon Inc. All rights reserved.


## Related Documents - RBO725

	<p><a href="#">Raycon RBO725 Open Earbuds: Safety, Specifications, and Compliance Information</a></p> <p>This document provides essential safety guidelines, detailed technical specifications, and FCC/IC compliance information for the Raycon RBO725 Open Earbuds, ensuring safe and compliant usage.</p>
	<p><a href="#">Raycon Open Earbuds Quick Start Guide</a></p> <p>A quick start guide for Raycon Open Earbuds, covering connection, functions, and how to wear the earbuds.</p>
	<p><a href="#">Raycon Essential Open Earbuds User Guide</a></p> <p>Comprehensive user guide for Raycon Essential Open Earbuds, covering setup, features like Multipoint, troubleshooting, safety, and specifications.</p>
	<p><a href="#">Raycon Open Earbuds User Manual and Guide</a></p> <p>Comprehensive guide to Raycon Open Earbuds, covering setup, functions, troubleshooting, safety, and specifications. Learn how to connect, charge, and optimize your audio experience.</p>



### [Raycon Everyday Earbuds Pro User Manual and Features](#)

Comprehensive guide to Raycon Everyday Earbuds Pro, covering features, setup, troubleshooting, safety, and specifications. Learn about ANC, Multipoint, and more.



### [Raycon Everyday Earbuds Classic User Manual: Features, Setup, and Troubleshooting](#)

Comprehensive user guide for the Raycon Everyday Earbuds Classic. Discover features like Active Noise Cancellation, Multipoint Connectivity, detailed setup instructions, charging information, fit guidance, troubleshooting tips, safety guidelines, and product specifications.