Tapo Tapo C101

Tapo C101 1080P Indoor Security Camera Instruction Manual

Model: Tapo C101 | Brand: Tapo

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Tapo C101 1080P Indoor Security Camera. Please read these instructions carefully before using the device to ensure optimal performance and safety. The Tapo C101 is designed to provide reliable indoor surveillance with features such as high-definition video, motion detection, two-way audio, and night vision.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- Tapo C101 Camera
- Power Adapter
- Mounting Screws
- Mounting Template
- Quick Start Guide

PRODUCT OVERVIEW

Familiarize yourself with the physical components of your Tapo C101 camera.

Figure 1: Front view of the Tapo C101 Indoor Security Camera.

1080p
Full HD

Customizable
Privacy Mode

Sharing
Funny Clips | Tapo Devices

Two-Way Audio

Free microSD Storage
512G

Baby Crying Detection

Motion Detection
and Notification

850nm Advanced
Night Vision

Up to 40ft

Person
Detection

Figure 2: Overview of Tapo C101 key features including 1080p Full HD video, customizable privacy mode, two-way audio, free microSD storage up to 512GB, baby crying detection, motion detection, and 850nm advanced night vision up to 40ft.

Figure 3: Illustration of local microSD card storage (up to 512GB) and optional Tapo Care cloud storage for recorded videos.

SETUP

1. **Download the Tapo App:** Search for 'Tapo' in the App Store (iOS) or Google Play Store (Android) and download the official Tapo app.

2. **Create a Tapo Account:** Open the app and follow the on-screen instructions to create a new Tapo account or log in if you already have one.

3. **Power On the Camera:** Connect the provided power adapter to the camera and plug it into a power outlet. The LED indicator on the camera will start blinking red and green.

4. **Add Camera to App:** In the Tapo app, tap the '+' icon to add a new device. Select your Tapo C101 model and follow the in-app instructions to connect it to your 2.4GHz Wi-Fi network.

5. **Position the Camera:** Place the camera on a flat surface or use the included mounting template and screws to mount it on a wall or ceiling. Ensure the camera has a clear view of the area you wish to monitor.

OPERATING INSTRUCTIONS

Motion Detection & Instant Notification

The Tapo C101 camera features advanced motion detection. When motion, a person, or baby crying is detected, you will receive instant push notifications on your smartphone. You can customize activity zones within the Tapo app to focus on specific areas and reduce unnecessary alerts.


Figure 4: Motion detection and customizable activity zones feature in action.

2-Way Audio with Built-in Siren

Utilize the integrated two-way audio feature to communicate with individuals near the camera or to deter intruders with the built-in siren. The camera includes a microphone and speaker for clear communication.

Figure 5: Two-way audio functionality, allowing communication through the camera.

Night Vision

The Tapo C101 provides clear night vision up to 30 feet using an integrated IR sensor, ensuring continuous monitoring even in low-light conditions.

Storage Options

You have two options for storing your video footage:

- **Local Storage:** Insert a microSD card (up to 512 GB, sold separately) into the camera for continuous recording without additional fees.
- **Cloud Storage:** Subscribe to Tapo Care for cloud storage, which offers a 30-day video history and additional benefits like motion tracking and baby crying detection.

Smart Home Compatibility

The Tapo C101 is fully compatible with Amazon Alexa and Google Assistant. Use voice commands to view the live stream on compatible devices like Echo Show or Google Chromecast with a screen.

Maintenance

- **Firmware Updates:** Regularly check for and install firmware updates through the Tapo app to ensure

your camera performs optimally and has the latest security features.

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **MicroSD Card Management:** If using local storage, periodically review and manage your microSD card footage to prevent it from filling up.

TROUBLESHOOTING

Connectivity Issues

- Ensure your camera is within range of your 2.4GHz Wi-Fi network.
- Restart your Wi-Fi router and the camera.
- Verify that your Wi-Fi password is entered correctly in the Tapo app.

Video Quality Problems

- Check your internet connection speed. A stable connection is crucial for optimal 1080P streaming.
- Ensure the camera lens is clean and free from obstructions.
- Adjust the camera's position to avoid direct glare or reflections.

Motion Detection Not Working

- Verify that motion detection is enabled in the Tapo app settings.
- Adjust the sensitivity level of the motion detection.
- Ensure activity zones are correctly configured to cover the desired areas.

SPECIFICATIONS

Feature	Detail
Indoor/Outdoor Usage	Indoor
Video Capture Resolution	1080p Full HD
Connectivity Technology	Wireless (Wi-Fi 2.4GHz)
Power Source	Corded Electric (DC Adapter)
Night Vision Range	Up to 30 Feet (Infrared LED)
Special Features	2-Way Audio, Cry Detection, HD Resolution, Local Recording, Night Vision
Local Storage	microSD card up to 512 GB (sold separately)
Smart Home Compatibility	Amazon Alexa, Google Assistant
Field Of View	117 Degrees
Dimensions (L x W x H)	2.66 x 2.15 x 3.89 inches
Item Weight	9.2 ounces

WARRANTY AND SUPPORT

For warranty information, technical support, and frequently asked questions, please visit the official TP-Link website or contact their customer service. You can typically find detailed support resources at tp-link.com/us/support/.

Contact Information:

- Phone: (866) 225-8139
- Website: myproducts.tp-link.com/us
- Email: support.USA@tp-link.com