



Manuals.plus /

› ChooChoo /

› ChooChoo 47-inch Farmhouse Console Table (Model ST2402-RB) Instruction Manual

ChooChoo ST2402-RB

ChooChoo 47-inch Farmhouse Console Table (Model ST2402-RB) Instruction Manual

Model: ST2402-RB

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your ChooChoo 47-inch Farmhouse Console Table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The ChooChoo 47-inch Farmhouse Console Table, showcasing its rustic brown finish, single drawer, and lower shelf, adorned with decorative items.

IMPORTANT SAFETY INFORMATION

WARNING:

- Always follow the assembly instructions carefully.
- Keep children and pets away from the assembly area.
- Use appropriate tools and safety gear during assembly.
- Do not overload the table or shelves.
- Ensure the table is placed on a level surface to prevent tipping.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (A)
- Drawer Front (B)

- Drawer Sides (C, D)
- Drawer Back (E)
- Drawer Bottom (F)
- Lower Shelf (G)
- Legs (H)
- A-Design Support Brackets (I)
- Hardware Pack (screws, cam locks, dowels, handles, etc.)
- Assembly Guide

Note: The exact number and labeling of parts may vary slightly. Refer to the included assembly guide for precise details.

SETUP AND ASSEMBLY

Assembly is required for this console table. It is recommended that two people assemble this product to ensure stability and ease of construction. All panels are numbered, and a clear assembly guide is included.

Recommended Tools:

- Screwdriver (not included)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Identify each part using the labels and the included assembly guide.
2. **Assemble the Drawer:** Follow the specific instructions in your assembly guide to construct the drawer using the drawer front, sides, back, and bottom. Attach the drawer handles.
3. **Attach Legs and Support Brackets:** Secure the legs to the tabletop and the lower shelf. Install the A-design support brackets to enhance stability.
4. **Insert Drawer:** Once the main frame is assembled, carefully slide the completed drawer into its designated slot.
5. **Final Tightening:** Once all parts are in place, gently tighten all screws and fasteners. Do not overtighten.



Image: Close-up of the A-design support brackets and corner metal accents, highlighting the structural details.

OPERATING INSTRUCTIONS

The ChooChoo Console Table is designed for functional storage and display.

- **Drawer Usage:** The single drawer provides enclosed storage for smaller items. Pull the handles gently to open and push to close. Avoid forcing the drawer.
- **Shelf Usage:** The lower open shelf is suitable for displaying decorative items, books, or storage baskets. Distribute weight evenly on the shelf.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the tabletop or the lower shelf. Refer to the specifications section for details.



Image: The console table with its drawer open, demonstrating the internal storage capacity.

MAINTENANCE

Proper care will extend the life and appearance of your console table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Tighten Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Table is wobbly	Uneven floor; loose fasteners	Adjust floor levelers (if present) or place shims under legs. Tighten all assembly screws.
Drawer does not slide smoothly	Misaligned drawer slides; obstruction	Ensure drawer slides are correctly installed and aligned. Check for any debris in the tracks.
Parts do not fit	Incorrect orientation; wrong parts used	Refer to the assembly guide to confirm correct part orientation and usage. Do not force parts.

SPECIFICATIONS

Brand: ChooChoo

Model Number: ST2402-RB

Product Dimensions: 11.8"D x 47.2"W x 31.5"H

Color: Rustic Brown

Style: Farmhouse

Base Material: Engineered Wood

Finish Type: Stained

Item Weight: 37.4 Pounds

Number of Shelves: 1

Number of Drawers: 1

Required Assembly: Yes

Recommended Number of People for Assembly: 2



Image: Dimensional diagram of the console table, indicating its length, depth, and height.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact ChooChoo customer service directly. Contact details are typically available on the manufacturer's website or through your retailer.