

[Manuals.plus](#) /

> [SoBuy](#) /

> SoBuy FSR79-B Shoe Cabinet Instruction Manual

SoBuy FSR79-B

SoBuy FSR79-B Shoe Cabinet Instruction Manual

Model: FSR79-B | Brand: SoBuy

1. PRODUCT OVERVIEW

The SoBuy FSR79-B is a modern, slim shoe cabinet designed for efficient space-saving in entryways. It features four tilt-out doors, an integrated drawer, and reversible side hooks, offering versatile storage for up to 16 pairs of shoes. Constructed from durable, FSC-certified MDF, this cabinet combines functionality with a sleek design.



Image: The SoBuy FSR79-B shoe cabinet, showcasing its design and FSC certification, positioned in an entryway.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use.

- **Anti-Tipping Device:** It is crucial to fix the shoe cabinet to the wall using the provided anti-tipping kit to prevent overturning. Failure to do so may result in serious injury.
- **Load Capacity:** Ensure the total weight of shoes and items stored does not exceed the maximum load capacity of 60 kg to prevent damage or injury.

- **Proper Storage:** Store shoes correctly within the compartments to avoid obstruction or tripping hazards.
- **Assembly:** Follow all assembly instructions carefully. Do not attempt to modify the product.



Image: Detailed view of key features including the anti-tipping device, metal handle, adjustable shelf, and felt feet.

3. SETUP AND ASSEMBLY

The SoBuy FSR79-B shoe cabinet requires assembly. Please refer to the detailed assembly instructions included in the product packaging. Ensure all components are present before beginning assembly.

3.1 Unpacking and Component Check

Carefully unpack all parts and lay them out on a clean, soft surface to prevent scratches. Verify that all hardware and panels listed in the instruction manual are present.

3.2 Assembly Steps

Follow the step-by-step diagrams and instructions provided in the separate assembly guide. It is recommended to have two people for assembly to ensure stability and ease of construction.

3.3 Wall Mounting

After assembly, securely attach the shoe cabinet to a solid wall using the anti-tipping kit. This step is essential for safety, especially in households with children or pets.



Image: Dimensional drawing of the shoe cabinet, indicating its width (104cm), depth (24cm), and height (83cm).

Progettato per spazi piccoli

Solo 24cm di profondità, creando spazio di archiviazione dal nulla per ingressi compatti



Image: The slim profile of the shoe cabinet (24cm depth) demonstrated in a narrow hallway, emphasizing its space-saving feature.

4. OPERATING INSTRUCTIONS

4.1 Shoe Storage

The cabinet features four tilt-out doors, each designed to hold multiple pairs of shoes. The internal shelves are adjustable, allowing you to customize the space for different shoe types, including sneakers and ankle boots. The total capacity is up to 16 pairs of shoes.

4.2 Integrated Drawer

Utilize the top integrated drawer for storing small items such as keys, wallets, or shoe care accessories.

4.3 Reversible Side Hooks

The cabinet includes side hooks that can be installed on either the left or right side, depending on your preference and space requirements. These hooks are ideal for hanging coats, bags, or umbrellas.

Design laterale reversibile

Moduli laterali sinistra/destra intercambiabili, si adattano facilmente a qualsiasi pianta.



Image: The integrated drawer and reversible side hooks, demonstrating their functionality for small items and hanging accessories.

5. MAINTENANCE

To ensure the longevity and appearance of your SoBuy FSR79-B shoe cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as they can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture absorption into the MDF material.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or swelling of the wood.
- **Hardware:** Periodically check and tighten all screws and fittings to ensure the cabinet remains stable.

6. TROUBLESHOOTING

- **Cabinet Instability:** If the cabinet feels unstable, ensure all screws are tightened. Verify that the anti-tipping device is correctly installed and securely fastened to the wall.
- **Doors Not Closing Properly:** Check for any obstructions within the tilt-out compartments. Ensure shoes are placed correctly and not overfilling the space. Adjust the internal shelves if necessary.
- **Drawer Sticking:** Ensure the drawer runners are clean and free from debris. If issues persist, check the assembly of the drawer and its runners.
- **Scratches/Dents:** For minor scratches, touch-up pens or furniture repair kits matching the cabinet's color may be used.

If you encounter issues not covered here or require further assistance, please contact SoBuy customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	FSR79-B
Brand	SoBuy
Color	Blue
Material	Engineered Wood (MDF E1, FSC Certified)
Product Dimensions (W x D x H)	104 cm x 24 cm x 83 cm
Item Weight	24.2 kg
Maximum Weight Capacity	60 kg
Shoe Capacity	Up to 16 pairs
Number of Doors	4 (tilt-out)
Number of Drawers	1
Special Features	Anti-tipping device, Adjustable shelves, Reversible side hooks, Felt feet
Assembly Required	Yes

Nostro



✓ Sicuro & Stabile

✓ Resistente all'umidità

✓ Sostenibile

MDF(E1)

Altri



✗ Liscio

✗ Resistente all'umidità

✗ Sostenibile

Particleboard

Image: Material comparison illustrating the superior quality of SoBuy's MDF(E1) over standard particleboard.

8. WARRANTY AND SUPPORT

8.1 Return Policy

This product is returnable within 30 days of receipt. Please refer to the retailer's return policy for detailed terms and conditions.

8.2 Customer Support

For any questions, concerns, or assistance with your SoBuy FSR79-B shoe cabinet, please contact SoBuy's specialized customer assistance. Contact details can typically be found on the retailer's website or within your purchase documentation.

