



Manuals.plus /

- › OKD /
- › OKD Fireplace TV Stand User Manual

OKD RPC70FP42A-ABW

OKD Fireplace TV Stand User Manual

Model: RPC70FP42A-ABW | Brand: OKD

1. PRODUCT OVERVIEW

The OKD Fireplace TV Stand is a farmhouse-style entertainment center designed to accommodate televisions up to 80 inches. It features a 42-inch electric fireplace insert, offering both warmth and ambiance, along with ample storage solutions including drawers and adjustable shelves.



Image 1.1: The OKD Fireplace TV Stand in an antique brush white finish, supporting a large television.

This unit combines modern country aesthetics with vintage allure, featuring a beautifully weathered oak grain and distressed finish. The electric fireplace provides 5200 BTU heating, capable of warming up to 400 sq. ft., and includes 7 flame colors and 7 LED lighting options for customizable ambiance.




Image 1.2: Visual representation of the TV stand's compatibility with televisions up to 80 inches.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and operation. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Ensure the product is placed on a stable, level surface.
- Do not overload the TV stand. Refer to specifications for weight limits.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace heater.
- Do not use the fireplace if the cord is damaged or if the unit malfunctions.
- Unplug the fireplace from the power outlet before cleaning or maintenance.
- Supervise children and pets when the fireplace is in operation.
- This product is for indoor use only.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. The item ships in two separate parcels, which may arrive on different days.

- TV Stand Components (Engineered Wood Panels, Hardware)
- 42" Electric Fireplace Insert
- Remote Control for Fireplace
- Adjustable Shelves
- Storage Drawers
- Assembly Instructions Manual

Product Dimensions



Image 3.1: Product dimensions and illustration of the two-package delivery.

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly requires two people and basic hand tools (Phillips screwdriver recommended). Do not use power tools as they may overtighten screws and damage the wood.

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches. Refer to the parts list in your included manual to identify each piece.
2. **Assemble Base Frame:** Follow the diagrams to connect the base panels using the provided hardware. Ensure all connections are secure.
3. **Attach Side Panels:** Secure the side panels to the base frame. Pay attention to the orientation of each panel as indicated in the manual.
4. **Install Center Support and Shelves:** Assemble the central support structure and insert the fixed shelves.
5. **Insert Electric Fireplace:** Carefully slide the 42-inch electric fireplace insert into its designated opening in the center of the TV stand. Ensure it is flush and secure.
6. **Assemble and Install Drawers:** Follow the instructions to assemble the two small drawers. Install the smooth-glide tracks and then insert the assembled drawers into their respective compartments.
7. **Attach Cabinet Doors:** Secure the cabinet doors to the side compartments. Adjust hinges as needed for proper alignment.
8. **Install Adjustable Shelves:** Place the adjustable shelves into the side cabinets at your desired height.
9. **Attach Top Panel:** Carefully place and secure the top panel onto the assembled frame.
10. **Final Checks:** Ensure all screws are tightened, and the unit is stable. Utilize the built-in wire management holes for a clean and organized appearance.



Image 4.1: Detailed view of the TV stand's top surface and smooth sliding drawers, highlighting dimensions.

5. OPERATING INSTRUCTIONS

5.1 Electric Fireplace Operation

The 42-inch electric fireplace can be operated using the control panel on the unit or the included remote control.



5200 BTU Electric Fireplace

5200 BTU can provide auxiliary heating for a 400 sq. ft. space



Timer
1-8H



Without Noise
(40dB)



Heat up
400 sq. ft.



Super Infra
Remote Control



Overheat
Protection



CSA/UL
Listed

Image 5.2: Key features of the 5200 BTU electric fireplace, including heating capacity and safety.

5.2 Storage Features

The TV stand offers versatile storage solutions to keep your living space organized.

- **Open Cubby:** Ideal for media consoles, soundbars, or decorative items.
- **Storage Drawers:** Two small drawers provide concealed storage for remotes, small accessories, or personal items. They feature smooth-glide tracks for easy operation.
- **Side Cabinets with Adjustable Shelves:** Two side cabinets with glass-paneled doors offer additional storage. The shelves inside are adjustable, allowing you to customize the space to fit various items like books, DVDs, or decor.

Bring Home the Holiday Spirit

70" Farmhouse TV Stand with 42" Fireplace



Smooth-Glide Tracks



Open Shelf for Soundbar



Adjustable Shelf

Image 5.3: Overview of storage features including smooth-glide drawers, open shelf, and adjustable cabinet shelves.

6. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the unit with a dry, lint-free cloth.
- **Fireplace Care:** Ensure the fireplace is unplugged before cleaning. Wipe the glass and exterior surfaces with a soft cloth. Do not spray water directly onto the unit.
- **Hardware Check:** Periodically check and tighten all hardware connections to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your OKD Fireplace TV Stand, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------------|---|---|
| Fireplace not turning on. | No power, remote battery low, unit overheated. | Check power cord connection. Replace remote batteries. Allow unit to cool down if overheating protection activated. |
| No heat output from fireplace. | Heating function not activated, thermostat setting too low. | Ensure heating function is turned on. Increase thermostat setting. |
| Flame effect not working. | Flame effect not activated. | Ensure flame effect is turned on via control panel or remote. |
| Drawers or doors are misaligned. | Improper assembly, loose hardware. | Review assembly instructions for correct alignment. Tighten all relevant screws. Adjust hinges on doors. |
| Unit is wobbly. | Loose hardware, uneven floor. | Tighten all assembly hardware. Move unit to a level surface or use shims if necessary. |

8. SPECIFICATIONS

| Feature | Detail |
|----------------------------|--|
| Brand | OKD |
| Model Name | RPC70FP42A-ABW |
| Product Dimensions | 15.6"D x 70"W x 32"H |
| Material | Engineered Wood |
| Finish Type | Antique Textured |
| Color | Antique Brush White |
| Installation Type | Freestanding |
| Power Source | Corded Electric |
| Heat Output | 5200 BTU |
| Heating Coverage | 400 sq ft |
| Special Features | Adjustable Flame, LED Flame, 1-8h Timer, Overheating Protection |
| Maximum Compatible TV Size | 80 Inches |
| Item Weight | 93 Pounds |
| Included Components | Adjustable Shelves, Electric Fireplace Insert, Remote Control, Storage Drawers |

9. WARRANTY AND SUPPORT

This product comes with an **Extended Warranty**. For specific details regarding your warranty coverage, please refer to the documentation included with your purchase or contact OKD customer support.

If you have any questions, require assistance with assembly, or need to report a damaged part, please contact OKD customer support. Contact information can typically be found on the packaging, in the included manual, or on the official OKD website.

Please retain your proof of purchase for warranty claims.