

Stouchi CGA001

Stouchi CGA001 RF Remote Control Page Turner User Manual

Model: CGA001 | Brand: Stouchi

1. INTRODUCTION

The Stouchi CGA001 RF Remote Control Page Turner is designed to enhance your reading experience by providing hands-free page-turning functionality for various touchscreen devices. This manual provides essential information for setting up, operating, and maintaining your device.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Page Turner Clip
- Remote Control
- USB-C Charging Cable
- Wrist Strap
- User Manual (this document)

More Friendly, More Comfortable

Keep distance from the screen, protect your eyesight/neck



Image: The package contents laid out, including the remote, clip, USB-C cable, wrist strap, and user manual.

3. PRODUCT OVERVIEW

The Stouchi CGA001 consists of two main components: the page turner clip and the remote control. These components are designed for seamless interaction.

Key Features:

- **Two-in-One Magnetic Charging:** The clip magnetically attaches to the back of the remote control for simultaneous charging with a single USB-C cable. The remote can also reverse charge the clip when its battery is low.

- **Compact Design with Mute Button:** The clip's design avoids obstructing the screen. The remote features a mute button for quiet operation, ideal for silent reading environments.
- **RF Remote Control:** Utilizes RF technology for stable and responsive page turning without direct line-of-sight.



Image: The Stouchi page turner remote and clip, showcasing their compact design and magnetic charging capability.

Game Changer for Charging

Magnetic Charging with 1 Cable



Image: A close-up of the magnetic charging feature, illustrating how the clip and remote connect for charging.

User Friendly Design



Mute Button



Charging Contacts



Ergonomically Design



Image: Details of the mute button, charging contacts, and ergonomic design of the remote control.

4. SETUP AND PAIRING

The Stouchi CGA001 is designed for easy setup with automatic pairing between the clip and remote.

Initial Setup:

1. **Power On:** Hold the switch button on both the clip and the remote control until a green light turns on. They will automatically pair.
2. **Attach Clip:** Clip the page turner onto the appropriate position on your e-reader or tablet. Ensure the silicone pad touches the screen for proper functionality.

3. **Adjust Margins:** For optimal performance, adjust your device's reading app margins to ensure text visibility and prevent the clip from interfering with the display.




Image: Visual guide on correct and incorrect placement of the page turner clip on a Kindle device.

Video: A demonstration of the Stouchi page turner's features, including its case-friendly design, mute button, and how it attaches to an e-reader.

5. OPERATION

Once set up, operating the page turner is straightforward.

Page Turning:

- Press the main button on the remote control to advance to the next page.
- To go back to the previous page, you may need to reposition the clip to the opposite side of the screen or adjust your device's settings if applicable.




Image: Illustration showing how to clip the device for forward and backward page turning.

Mute Function:

- Press the dedicated mute button on the remote control to silence any operational sounds, ensuring a quiet reading experience.

Video: A demonstration of the page turning functionality on a Kindle and iPhone, highlighting its use for reading and taking photos/videos.

6. COMPATIBILITY

The Stouchi CGA001 is compatible with a wide range of touchscreen devices.

Compatible Devices:

- 2024 Kindle Colorsoft, 2024 New Kindle, Kindle 10, Kindle 11, Kindle Scribe
- Kindle Paperwhite (all generations: 5/4/3/2/1), Kindle Oasis (all generations: 3/2/1), Kindle Kids Edition, Kindle Voyage
- iPad, iPhone, Android Tablets, Android Phones

Incompatible Devices:

- Kindle 7th/8th Generation
- Amazon Fire HD 10 (10th/11th Generation)

Important Note: If your device's thickness is more than 1.2 cm, the page turner may not work properly.



Image: A chart illustrating the wide compatibility of the page turner with various e-readers, tablets, and phones, along with a list of incompatible models.



Image: A diagram showing the maximum device thickness (1.2 cm) for proper functionality of the page turner clip.

Video: A demonstration highlighting the case-friendly design of the page turner, showing it working with a device in a protective case.

7. CHARGING AND BATTERY

The Stouchi CGA001 features an innovative magnetic two-in-one charging system.

Charging Instructions:

- Connect the provided USB-C cable to the remote control.
- To charge the clip simultaneously, magnetically attach it to the back of the remote control.
- The remote can also reverse charge the clip when the clip's battery is low.

Battery Life:

- The clip can last up to one month on standby.
- The remote control can last up to three months on standby.

8. TROUBLESHOOTING

If you encounter issues with your Stouchi CGA001, please refer to the following common solutions:

- **Device Not Responding:** Ensure both the clip and remote are powered on and properly paired (indicated by a green light).
- **Page Turning Issues:** Verify the clip's silicone pad is making proper contact with the screen. Adjust the clip's position if necessary. Check your device's reading app margin settings to ensure the clip does not interfere with the active touch area.
- **Charging Problems:** Ensure the USB-C cable is securely connected and the clip is correctly magnetically attached to the remote for simultaneous charging. Check if the indicator lights are active during charging.
- **Incompatible Device:** Confirm your device is listed under the compatible devices section. Note that Kindle 7th/8th Generation and Amazon Fire HD 10 (10th/11th Generation) are not supported.
- **Device Thickness:** Ensure your device's thickness, including any case, does not exceed 1.2 cm.

9. SPECIFICATIONS

Brand	Stouchi
Model	CGA001
Product Dimensions	9.65 x 3.81 x 1.52 cm
Weight	50 g
Battery Type	Lithium-Ion Polymer





Charging Interface	USB-C
Special Features	Lightweight, Long-lasting Battery Life, Mute Button, Ergonomic, RF Remote Control, Two-in-One Magnetic Charging

10. WARRANTY AND SUPPORT

Stouchi provides a **36-month term of service** for the CGA001 RF Remote Control Page Turner. If you experience any quality issues with the product during this period, please contact Stouchi customer support for assistance.

For further support or inquiries, please visit the official Stouchi website or contact their customer service directly.

Related Documents - CGA001

	STOUCHI Wireless Charging Dock User Manual User manual for the STOUCHI Wireless Charging Dock (Model CGB001-ST, S031A-ST). Provides setup, safety instructions, specifications, and FCC compliance information.
	STOUCHI Card Wallet User Manual - Setup, Features, and Troubleshooting Comprehensive user manual for the STOUCHI Card Wallet (STOUCHI TAG), covering setup with Apple Find My, device management, troubleshooting, charging, and safety information.
	STOUCHI Wireless Remote Control Ring CGD001-ST User Manual User manual for the STOUCHI Wireless Remote Control Ring (Model CGD001-ST). Learn about specifications, Bluetooth connection, instructions for use, and charging.
	Stoichi Page Turner User Manual and Specifications Comprehensive user manual and technical specifications for the Stoichi Page Turner, including charging instructions, product diagrams, and FCC compliance information.