



[Manuals.plus](#) /

> [Bellemave](#) /

> Bellemave Twin Floor Bed Instruction Manual

Bellemave GZZ000123TN

Bellemave Twin Floor Bed Instruction Manual

Model: GZZ000123TN

[Introduction](#)

[Safety Information](#)

[Components](#)

[Setup & Assembly](#)

[Operating
Instructions](#)

[Warranty &
Support](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bellemave Twin Floor Bed. This Montessori-style bed is designed for children, featuring a low profile, sturdy wooden construction, integrated slats, a center support bar, and a unique fence with a functional door for enhanced safety and accessibility. Please read this manual thoroughly before beginning assembly or use to ensure proper setup and safe operation.



Figure 1.1: Fully assembled Bellemave Twin Floor Bed in a child's bedroom setting.

2. SAFETY INFORMATION

WARNING: Improper assembly, use, or maintenance of this bed frame could result in injury or damage. Always follow the assembly instructions provided, ensuring a secure connection of all components. Do not exceed the recommended weight capacity of 250 pounds. Take care when handling the center support bar and slats, as improper use could lead to instability or collapse. Be cautious when opening and closing the small door on the fence, as it may present a pinch or entrapment hazard. Regularly inspect the bed frame for any signs of wear or damage, and address any issues promptly to maintain the safety and integrity of the bed frame.

- Ensure all screws and fasteners are tightened securely before use and periodically check for looseness.
- Do not allow children to jump on the bed.
- Keep small parts away from children during assembly to prevent choking hazards.
- Place the bed on a flat, stable surface.

3. COMPONENTS LIST

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

| Part | Description | Quantity |
|--------------------|---|----------|
| Bed Frame Panels | Includes headboard, footboard, and side rails with fence. | 4 |
| Slats | Plywood slats for mattress support. | 8 |
| Center Support Bar | Provides additional central support for the slats. | 1 |
| Door Assembly | Small hinged door for entry/exit. | 1 |
| Hardware Pack | Screws, bolts, nuts, and Allen wrench. | 1 set |



Figure 3.1: Overview of the bed frame components, showing the open door section.

4. SETUP & ASSEMBLY

Assembly of the Bellemave Twin Floor Bed is designed to be straightforward. All necessary accessories and detailed installation instructions are included in the product parcel. It is recommended to assemble the bed with two people.

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Refer to the components list to ensure all parts are present.
- 2. Assemble Frame:** Connect the headboard, footboard, and side rails using the provided hardware. Ensure all connections are snug but do not overtighten until the frame is fully assembled.
- 3. Install Center Support Bar:** Attach the center support bar to the designated points on the headboard and footboard for added stability.
- 4. Place Slats:** Lay the plywood slats across the bed frame, ensuring they are evenly spaced and securely seated. The slats are designed to provide direct mattress support, eliminating the need for a box spring.
- 5. Attach Door Assembly:** Secure the small door assembly to the designated opening in the fence using the provided

hinges and latch. Ensure the door swings freely and the latch operates correctly. The door is removable if desired.

6. **Final Tightening:** Once the entire frame is assembled, go back and securely tighten all screws and bolts.

SIZE: INCH




Figure 4.1: Dimensional diagram of the Twin Floor Bed, useful for planning placement.



Figure 4.2: View of the bed frame showing the installed slats and center support.



Figure 4.3: Detail of the door hinges, illustrating how the door is attached.



Figure 4.4: Detail of the door latch mechanism, showing how to secure the door.

5. OPERATING INSTRUCTIONS

The Bellemave Twin Floor Bed is designed for ease of use and child safety. Its low profile allows children to easily get in and out of bed independently, aligning with Montessori principles.

5.1 Using the Door

The bed features a small, hinged door that can be opened and closed. This door provides a secure enclosure when closed and easy access when open.

- To open the door: Slide the latch mechanism to unlock and gently swing the door outwards.
- To close the door: Swing the door inwards until it aligns with the frame, then slide the latch mechanism to secure it.
- The door can be removed if preferred, by detaching it from its hinges.



Figure 5.1: The bed with the door securely closed, providing a safe sleeping environment.



Figure 5.2: The bed with the door open, illustrating convenient entry and exit.

5.2 Mattress Compatibility

This bed is designed for a Twin size mattress. A recommended mattress thickness of 4 inches is suggested to ensure the safety fence remains effective. Thicker mattresses may reduce the height of the fence above the mattress, potentially compromising safety. The slats are removable if a different mattress setup is desired, though this is not recommended for optimal support and safety.

6. MAINTENANCE

Regular maintenance will help prolong the life and ensure the safety of your Bellemave Twin Floor Bed.

- **Cleaning:** Wipe down the wooden surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Hardware Check:** Periodically (e.g., monthly) check all screws, bolts, and fasteners to ensure they are tight. Retighten any loose hardware to maintain structural integrity.

- **Slats and Support Bar:** Inspect the slats and center support bar for any signs of cracking, warping, or damage. Replace any damaged components immediately.
- **Door Mechanism:** Ensure the door hinges and latch operate smoothly. Lubricate with a small amount of silicone spray if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your Bellemave Twin Floor Bed, refer to the common problems and solutions below. If the problem persists, contact customer support.

| Problem | Possible Cause | Solution |
|---|--|--|
| Bed feels wobbly or unstable. | Loose hardware; uneven assembly. | Ensure all screws and bolts are fully tightened. Disassemble and reassemble if necessary, ensuring parts are aligned correctly. |
| Parts do not align during assembly. | Incorrect orientation of parts; manufacturing tolerance. | Double-check the assembly diagrams. Try rotating parts or gently wiggling them into place. Do not force parts. If significant misalignment, contact support. |
| Door does not close or latch properly. | Hinges or latch misaligned; loose screws. | Check that hinges are securely fastened and aligned. Adjust the latch position if possible. Ensure the bed frame is square. |
| Slats are not providing adequate support. | Slats incorrectly placed; mattress too heavy/thick. | Ensure all slats are properly seated in their designated slots. Verify mattress thickness is within recommended guidelines (4 inches). |

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------------|----------------------|
| Size | Twin |
| Product Dimensions (L x W x H) | 78"L x 41"W x 17.5"H |
| Inner Bed Size (L x W) | 75.4" x 39.3" |
| Fence Height | 16" |
| Special Feature | No Box Spring Needed |
| Color | Natural Slats |
| Finish Type | Painted |
| Included Components | Guardrails, Slats |
| Compatible Mattress Size | Twin |
| Recommended Mattress Thickness | 4" |
| Brand | Bellemave |
| Furniture Finish | Natural |

| Feature | Detail |
|-------------------|--------------------------------|
| Assembly Required | Yes |
| Manufacturer | Bellemave |
| UPC | 733805193423 |
| Form Factor | Floor Bed with Slats |
| Target Audience | Children (both girls and boys) |
| Item Weight | 23 pounds |
| Model Number | GZZ000123TN |

Your browser does not support the video tag.

Video 8.1: Official product video demonstrating the Bellemave Twin Floor Bed in a room setting.

9. WARRANTY & SUPPORT

For any questions, concerns, or assistance with your Bellemave Twin Floor Bed, please contact Bellemave customer support. While specific warranty details are not provided in this manual, Bellemave is committed to customer satisfaction.

- **Customer Support Email:** Bellemave@outlook.com
- **Returns:** This product typically includes a 30-day easy returns policy. Please refer to your purchase platform for specific return instructions.
- **Protection Plans:** Extended protection plans may be available for purchase separately. Check with your retailer for options.

Please retain your proof of purchase for any warranty or support claims.