

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Miroddi](#) /

› [Miroddi Credit Card Holder Instruction Manual - Model CB055](#)

### Miroddi CB055

# Miroddi Credit Card Holder Instruction Manual - Model CB055

Your guide to using and maintaining your Miroddi Credit Card Holder.

## INTRODUCTION

Thank you for choosing the Miroddi Credit Card Holder, Model CB055. This compact and secure card holder is designed to organize your essential cards and cash efficiently. Crafted from premium PU leather with RFID blocking technology, it offers both style and protection. This manual provides instructions for optimal use and care.

## PRODUCT OVERVIEW



Image: The Miroddi Credit Card Holder in Sky Blue, showcasing its compact design.


The Miroddi Credit Card Holder (Model CB055) features a minimalist design with double-sided elastic pockets, capable of holding up to 14 cards and some cash. Its dimensions are approximately 3.85 x 2.87 x 0.23 inches, making it suitable for front pockets or small bags.

- **Material:** High-quality PU Leather
- **Capacity:** Up to 14 cards and cash
- **Security:** RFID Blocking technology
- **Dimensions:** 3.85" x 2.87" x 0.23"

## SETUP AND INITIAL USE

1. **Unpacking:** Remove the card holder from its packaging.

- 2. Inserting Cards:** Gently slide your credit cards, ID cards, and other essential cards into the elastic pockets on either side. The elastic is designed to securely hold multiple cards.
- 3. Adding Cash:** Fold any banknotes and place them within the elastic pockets alongside your cards, or in the central compartment if available.

A woman with long, wavy blonde hair and dark sunglasses is holding a teal-colored card holder. The card holder has two elastic pockets on the sides and a central slot. Several cards are visible in the pockets. She is wearing a dark floral top and a necklace. In the foreground, there is an illustration of the card holder with cards being inserted into the side pockets. The background is a blurred outdoor setting.

**Double Side Pockets**  
Hold up to 14 cards and some cash

Image: Illustration of cards being inserted into the double-sided pockets of the card holder.

## OPERATING INSTRUCTIONS

---

The Miroddi Credit Card Holder is designed for quick and easy access to your cards.

- Accessing Cards:** Utilize the thumb slot at the bottom of each card pocket. Push up gently with your thumb to reveal the cards, allowing you to select the desired one.
- RFID Protection:** The integrated RFID blocking material protects your cards from unauthorized scanning, safeguarding your personal information. Ensure cards are fully enclosed within the holder for maximum protection.
- Portability:** Its slim profile allows it to be easily carried in a front pocket, jeans pocket, or a small bag.

# Quick Access Cards

Simply design to easily slide in-and-out your cards



Image: A hand demonstrating how to quickly access cards using the thumb slot.

# RFID Blocking

Special lining protects your magnetic-stripe cards



Image: Visual representation of the RFID blocking feature protecting cards from scanners.

## MAINTENANCE AND CARE

To ensure the longevity and appearance of your Miroddi Credit Card Holder, follow these care guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the PU leather.
- **Storage:** Store the card holder in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Avoid Overstuffing:** While the elastic pockets are designed to hold multiple cards, excessive overstuffing can stretch the material and potentially affect its shape and card retention over time.
- **Protect from Sharp Objects:** Keep the card holder away from sharp objects to prevent scratches or punctures to the leather.

## TROUBLESHOOTING

Issue	Possible Cause	Solution
Cards are difficult to insert or remove.	Overstuffing or new elastic.	Reduce the number of cards. The elastic may loosen slightly with regular use.
Cards feel loose.	Understuffing or elastic has stretched over time.	Ensure an appropriate number of cards are inserted to maintain tension. If the elastic is permanently stretched, consider replacing the card holder.
RFID blocking seems ineffective.	Card not fully enclosed or external interference.	Ensure all cards are fully inserted into the pockets. RFID blocking is designed for passive scanning; it does not prevent all forms of electronic interference.

## SPECIFICATIONS

- **Model:** CB055
- **Product Dimensions:** 3.85" (Length) x 2.87" (Width) x 0.23" (Thickness)
- **Item Weight:** Approximately 1.76 ounces (0.05 Kilograms)
- **Material:** Premium PU Leather
- **Color:** Sky Blue (as per current product)
- **Style:** Card Holder
- **Features:** RFID Blocking, Double-sided Elastic Pockets, Thumb Slot for quick access
- **Manufacturer:** Miroddi

# Information Protecting

Special lining protects your magnetic-stripe cards



## RFID BLOCK

Image: Visual representation of the card holder's dimensions and key features.

## WARRANTY AND SUPPORT

Miroddi is committed to providing high-quality products. If you encounter any issues or have questions regarding your Miroddi Credit Card Holder, please contact our customer support.

For assistance, please visit the official Miroddi Store on Amazon:[Miroddi Store](#).

© 2025 Miroddi. All rights reserved.