

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EarFun](#) /

› [EarFun Air Life Wireless Earbuds User Manual](#)

EarFun TW205

EarFun Air Life Wireless Earbuds User Manual

Model: TW205

INTRODUCTION

This manual provides comprehensive instructions for the EarFun Air Life Wireless Earbuds. Please read thoroughly to ensure proper use, maintenance, and optimal performance of your device.

WHAT'S IN THE Box?

- EarFun Air Life Wireless Earbuds
- Charging Case
- S/M/L Ear Tips
- User Manual



The EarFun Air Life Wireless Earbuds are presented with their compact charging case, showcasing their sleek black design.

Your browser does not support the video tag.

This video provides an unboxing experience for the EarFun Air Life Wireless Earbuds, showing all included components.

1. Initial Setup

1. Before first use, remove the insulating films from the charging contacts on both earbuds. This ensures proper charging and connection.
2. Place both earbuds back into the charging case and close the lid. This will activate them and prepare for pairing.

2. Wearing the Earbuds

1. Choose the suitable ear tip size (S, M, or L) for the best sound quality and a secure fit. Experiment with different sizes to find the most comfortable and effective seal.
2. Select the left or right earbud and insert it into the corresponding ear.
3. Rotate the earbud back and forth gently to ensure the ear tip creates a comfortable and secure seal within your ear canal.

Customize via EarFun Audio App


 30 Preset and personalized EQs

 Customized Touch Control

 Game Mode

 Updated Firmware

 Find Headphones



EarFun Audio



GET IT ON
Google Play

Available on the
App Store

A woman demonstrates the comfortable and secure fit of the EarFun Air Life earbuds, highlighting the included S, M, and L ear tip sizes for optimal sealing.

Your browser does not support the video tag.

Watch this video segment for detailed instructions on getting a better wearing experience with your EarFun Air Life earbuds.

3. First-Time Pairing

1. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
2. Activate Bluetooth on your Bluetooth-enabled device (e.g., smartphone, tablet).
3. From the list of available Bluetooth devices, select "EarFun Air Life" to connect. A voice prompt will confirm successful pairing.

Your browser does not support the video tag.

This video segment provides detailed instructions on connecting your EarFun Air Life earbuds to a device for the first time.

OPERATING INSTRUCTIONS

1. Connecting to a New Device (Option A: Unpairing from Old Device)

1. On the previously connected device, go to its Bluetooth settings and unpair or "forget" "EarFun Air Life".
2. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
3. On your new device, activate Bluetooth and select "EarFun Air Life" from the available devices to connect.

Your browser does not support the video tag.

This video segment demonstrates how to connect your EarFun Air Life earbuds to a new device by first unpairing from an old one.

2. Connecting to a New Device (Option B: Manual Pairing)

1. Power on and put on both earbuds.
2. Simultaneously press and hold both earbuds for 3 seconds until the indicator lights flash rapidly, indicating pairing mode.
3. On your new device, activate Bluetooth and select "EarFun Air Life" from the available devices to connect.


Your browser does not support the video tag.

This video segment illustrates the manual pairing process for connecting your EarFun Air Life earbuds to a new device.

3. Using the EarFun Audio App

Enhance your listening experience by customizing settings via the EarFun Audio App.

1. Ensure your EarFun Air Life earbuds are successfully paired to your Bluetooth-enabled device.
2. Download and open the EarFun Audio App from your device's app store.
3. Follow the in-app instructions to connect your earbuds. Once connected, you can access features such as:
 - 30 Preset EQs and Custom EQ
 - Customized Touch Control
 - Game Mode (for reduced audio latency)
 - Updated Firmware
 - Find Headphones function



FIRM AND COZY FIT

Featuring an excellent ergonomic design for a steady and comfortable fit, with IPX5 splashproof durability, perfect for various sports activities.

Screenshots of the EarFun Audio App interface, showcasing features like 30 preset EQs, customized touch controls, game mode, and the 'Find Headphones' function.

Your browser does not support the video tag.

This video segment guides you through connecting your EarFun Air Life earbuds to the EarFun Audio App.

4. Touch Controls

The EarFun Air Life earbuds feature intuitive touch controls for managing music playback, calls, and voice assistant.

Function	Action	Earbud (R/L)
Volume Up	Tap once	Right (R)
Volume Down	Tap once	Left (L)
Play/Pause	Tap twice	Right (R) or Left (L)
Next Track	Tap triple	Right (R)

Function	Action	Earbud (R/L)
Previous Track	Tap triple	Left (L)
Answer/End a call	Tap twice	Right (R) or Left (L)
Reject a call	Tap and hold for 2s	Right (R) or Left (L)
Answer and transfer two calls	Tap triple	Right (R) or Left (L)
Voice Assistant	Tap and hold for 2s	Right (R) or Left (L)

Your browser does not support the video tag.

This video segment demonstrates how to control music, phone calls, and game mode using the EarFun Air Life earbuds.

MAINTENANCE

1. Cleaning the Earbuds and Charging Case

Regular cleaning helps maintain optimal performance and longevity of your EarFun Air Life earbuds.

- The charging contacts on both earbuds and within the charging case may accumulate sweat or dust, which can affect charging or connection. Use a dry cotton swab to gently clean these contacts.
- The protective grille of both earbuds may accumulate earwax and dust, resulting in muffled volume. Use a clean, dry cotton swab to carefully clean the grille.
- For personal hygiene and earbud longevity, it is recommended to clean your ears regularly.

Your browser does not support the video tag.

This video segment provides instructions on how to properly clean your EarFun Air Life earbuds and charging case.

TROUBLESHOOTING

1. Resetting Earbuds

If you experience pairing issues, sound problems, or other malfunctions, resetting the earbuds can often resolve the issue.

1. Place both earbuds into the charging case and ensure they are charging.
2. On your Bluetooth device, delete the previous "EarFun Air Life" connection from your Bluetooth settings.
3. With the earbuds in the charging case and the lid open, simultaneously press and hold the touch control areas on both earbuds for 8 seconds until the indicator lights flash rapidly, then turn off. This indicates a successful reset.
4. Close the charging case lid, then open it again. The earbuds will re-enter pairing mode.
5. Reactivate Bluetooth on your device and search for "EarFun Air Life" to reconnect.

Your browser does not support the video tag.

This video segment demonstrates the steps to reset your EarFun Air Life earbuds.

2. Common Issues and Solutions

- **No Sound from One Earbud:** Ensure both earbuds are charged. Try placing them back in the case, closing the lid, and reopening. If the issue persists, perform a reset.

- **Earbuds Not Charging:** Clean the charging contacts on both earbuds and inside the case with a dry cotton swab. Ensure the charging cable is securely connected and the power source is active.
- **Connection Drops Frequently:** Ensure you are within the Bluetooth range (typically 10 meters/33 feet) of your device. Avoid obstacles that may interfere with the signal. Try resetting the earbuds and re-pairing.
- **Muffled Sound or Low Volume:** Ensure ear tips are properly sealed in your ear canal. Clean the protective grilles of the earbuds to remove any earwax or debris. Adjust EQ settings in the EarFun Audio App.

SPECIFICATIONS

Feature	Detail
Model Name	EarFun Air Life
Bluetooth Version	5.4
Driver Size	12mm Composite Dynamic Driver
Playtime (Single Charge)	Up to 11 hours
Playtime (with Charging Case)	Up to 35 hours
Fast Charging	10 minutes charge for 150 minutes playtime
Microphones	4 Mics with AI ENC Call Technology
Water Resistance	IPX5 (Sweat and Water Resistant)
Control Method	App, Touch
Frequency Response	20Hz - 20,000Hz
Impedance	32 Ohm
Item Weight	38 Grams (1.34 ounces)
Product Dimensions	2.4 x 0.98 x 1.81 inches

ROBUST BASS

Premium 12mm composite dynamic driver provides deep, powerful bass with clear, substantial volume

12mm driver



An internal diagram highlights the 12mm composite dynamic driver, engineered to deliver powerful and deep bass.

ENHANCED BLUETOOTH 5.4 CHIP

The up-to-date Bluetooth 5.4 features seamless connectivity with ultra-fast response and minimal delay.



Fast Connection



Low Latency



Best Reliability



Excellent Security

15M

15M



An illustration demonstrating the integrated Bluetooth 5.4 chip, ensuring stable and fast wireless connectivity.

UNWAVERING BATTERY LIFE

35H

with Charging Case

11H

Single Charge



Fast Charge



This graphic illustrates the impressive battery life of the EarFun Air Life earbuds, offering 11 hours on a single charge and up to 35 hours with the charging case.

4 MICS AI ENC CALL

Enjoy remarkably clear calls with advanced 4 Mics and AI-powered ENC that accurately captures your voice and effectively reduces background noise.



A visual representation of the 4-microphone AI-powered Environmental Noise Cancellation (ENC) technology, designed for crystal-clear calls by reducing background noise.

WARRANTY AND SUPPORT

EarFun products typically come with a standard manufacturer's warranty. For specific warranty details, technical support, or further assistance, please refer to the official EarFun website or contact their customer service.

- Official User Manual (PDF): [Download PDF](#)
- EarFun Brand Store: [Visit Store](#)