

Manuals.plus /
› SRJTEK /
› for Samsung Galaxy M13 4g Screen Replacement for Samsung M13 4g LCD Display Touch Screen for Samsung SM-M135F Digitizer Assembly Replacement Repair Parts Black SM-M135F/DSN (Not for 5g)

SRJTEK SM-M135F, SM-M135F/DSN

User Manual: SRJTEK LCD Display Touch Screen Digitizer Assembly Replacement for Samsung Galaxy M13 4G

Model: SM-M135F, SM-M135F/DSN

INTRODUCTION

This manual provides essential information for the installation and proper use of the SRJTEK LCD Display Touch Screen Digitizer Assembly Replacement for Samsung Galaxy M13 4G (SM-M135F, SM-M135F/DSN). This product is designed to replace defective LCD displays and touch screens, addressing issues such as incorrect screen response, display problems, pixel distortion, cracked screens, and color inaccuracies. Please read this manual thoroughly before proceeding with installation.

SAFETY INFORMATION AND PRECAUTIONS

Important Safety Notice:

- The screen is made of glass and is a very fragile product. Handle with extreme care to prevent damage.
- Always test the product thoroughly before installation. Do not remove any protective films or labels until testing is complete and the screen is confirmed to be in good working condition.
- Be mindful of static electricity. Static discharge can damage electronic components. Consider using anti-static precautions.
- Do not bend the flex cable excessively. Bending the LCD cable by more than 90 degrees can result in a black screen or other display issues.
- Non-professional installation is not recommended. If you lack experience in repairing electronic equipment, seek assistance from a professional repair shop to avoid potential damage to your device or the replacement part.

PRODUCT OVERVIEW

The SRJTEK LCD Display Touch Screen Digitizer Assembly is a complete unit designed for direct replacement. It features high color saturation, high resolution, a wide color gamut, and a smooth touch feel. All units undergo strict

Quality Control testing to ensure they are 100% intact, free from scratches, dead zones, or pixel defects.



Image: The SRJTEK screen replacement kit, showing the new display assembly and included basic repair tools.

LCD Sereen Replacement (Front)




Image: Front view of the LCD screen replacement, showing the display area and notch for the front camera.

LCD Sereen Replacement (The Back)



Image: Back view of the LCD screen replacement, highlighting the integrated flex cable and connector for the phone's motherboard.

100% Tested one by one,
High level material for the flex cable



Image: Close-up view detailing the flex cable, connector, camera hole, and ARC frame of the screen replacement.

WHAT'S IN THE BOX

Your package should contain the following items:

- 1 x SRJTEK LCD Display Touch Screen Digitizer Assembly for Samsung Galaxy M13 4G
- Basic repair tools (may include screwdrivers, prying tools, suction cup, SIM ejector pin, dust absorber, and disassembly tool card)

Package



Image: Visual representation of the package contents, including the screen replacement and various repair tools.

INSTALLATION INSTRUCTIONS (SETUP)

Replacing a phone screen requires precision and care. Please follow these steps carefully. If you are not confident in your ability to perform this repair, it is highly recommended to seek professional assistance.

1. **Preparation:** Before starting, ensure your phone is powered off completely. Gather all necessary tools. Note that

the provided tools are universal, and you may need additional specialized tools for a more professional repair.

2. **Pre-Installation Test:** This is a critical step. Before fully installing the new screen, connect the flex cable of the new display to your phone's motherboard. Do not remove any protective films or labels at this stage. Power on your phone and test the display and touch functionality thoroughly. Check for any dead pixels, lines, color issues, or unresponsive touch areas. If any issues are found, contact support immediately.
3. **Disassembly:** Carefully disassemble your phone to remove the old, damaged screen. This typically involves heating the edges to loosen adhesive, then carefully prying the screen away. Be extremely cautious of internal components and existing flex cables.
4. **Transfer Components:** The new screen does not include components such as the power buttons, volume buttons, earpiece speaker, front camera, or home button (if applicable). You must carefully remove these components from your old screen assembly and transfer them to the new screen.
5. **Cleaning:** Thoroughly clean any old adhesive residue from the phone frame. Ensure the surface is clean and smooth for proper adhesion of the new screen.
6. **Installation:** Carefully align the new screen assembly with the phone frame. Ensure the flex cable is properly routed and connected without any bends greater than 90 degrees. Apply new adhesive if necessary (not included).
7. **Final Test:** Once the new screen is securely installed, power on your phone and perform another comprehensive test of all display and touch functions.

For visual guidance, it is highly recommended to search for relevant installation videos on platforms like YouTube for your specific phone model (Samsung Galaxy M13 4G SM-M135F/DSN) and follow the steps demonstrated.

OPERATING THE DISPLAY

Once installed, the SRJTEK LCD Display Touch Screen Digitizer Assembly functions identically to the original display. It provides a responsive touch interface and vibrant visual output for your Samsung Galaxy M13 4G.

- **Touch Functionality:** The digitizer assembly ensures accurate and smooth touch response for all gestures and inputs.
- **Display Quality:** Experience high-resolution visuals with accurate color reproduction, suitable for all daily tasks, media consumption, and gaming.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your new screen, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth, slightly dampened with water or a screen-specific cleaning solution, to gently wipe the screen. Avoid harsh chemicals, abrasive materials, or excessive moisture.
- **Protection:** Consider applying a screen protector and using a protective case for your phone to minimize the risk of future scratches or cracks.
- **Avoid Impact:** While the screen is designed to be durable, direct impacts or drops can still cause damage. Handle your device with care.
- **Temperature Extremes:** Avoid exposing your phone to extreme temperatures, as this can affect the display's performance and lifespan.

TROUBLESHOOTING

If you encounter issues after installation, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Black Screen After Installation	This often indicates the main flex cable is not properly connected. Try pressing and holding the power key and volume key simultaneously. If the phone vibrates, it confirms a connection issue. Power off, recheck the flex cable connection, and reinstall. Ensure the flex cable is not bent excessively (more than 90 degrees), as this can cause permanent damage leading to a black display.
Unresponsive Touch / Ghost Touches	Check the digitizer flex cable connection. Ensure it is securely seated. Perform a hard reset of the phone. Ensure there is no debris or foreign material between the screen and the phone frame.
Display Lines / Dead Pixels / Color Issues	These issues typically point to a defective screen or damage during installation. If these were present during the pre-installation test, the screen is likely faulty. If they appeared after installation, recheck flex cable connections for damage or improper seating. If the issue persists after rechecking connections, the screen may be defective. Contact customer support.
Screen Not Fitting Properly	Ensure all old adhesive residue has been completely removed from the phone frame. Verify that the model number of the screen matches your phone (SM-M135F, SM-M135F/DSN). This screen is NOT compatible with the 5G version of the M13. Check for any bent frame components on your phone that might prevent proper seating.

If you are unable to resolve the issue after following these steps, please refer to the "Warranty and Support" section for further assistance.

SPECIFICATIONS

Feature	Detail
Product Type	LCD Display Touch Screen Digitizer Assembly Replacement
Compatible Model	Samsung Galaxy M13 4G (SM-M135F, SM-M135F/DSN)
Display Type	PLS LCD
Resolution	1080 x 2408 pixels
Screen Size	6.6 inches
Color	Black
Item Weight	0.32 ounces (approximately 9 grams)
Manufacturer	SRJTEK
Country of Origin	China

WARRANTY AND SUPPORT

SRJTEK stands by the quality of its products. All screens are strictly QC tested before shipment to ensure they are 100% intact and free from defects.

- **Quality Assurance:** We ensure there are no scratches, dead zones, dot pixels, or lines on the screen upon

delivery.

- **Installation Assistance:** While professional installation is recommended, if you need help or encounter issues during the process, please contact us. We aim to respond within 24 hours to assist you.
- **Contact Information:** For support, please reach out to SRJTEK customer service through the platform where you purchased the product.

Please remember to test the screen before final installation to ensure its normal function. This is crucial for warranty claims related to initial defects.

© 2024 SRJTEK. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DBQCSD66>

More documents and user manuals: <https://manuals.plus/>