

HOOBRO BN51HX01

HOOBRO Rattan Shoe Storage Bench BN51HX01 Instruction Manual

1. INTRODUCTION

Thank you for choosing the HOOBRO Rattan Shoe Storage Bench, Model BN51HX01. This versatile furniture piece is designed to provide efficient shoe storage and a convenient seating option for your entryway, hallway, living room, or bedroom. Its compact design and stylish rattan-like decor blend functionality with aesthetic appeal.

This manual provides detailed instructions for the assembly, operation, and maintenance of your shoe storage bench to ensure long-lasting use and satisfaction.

2. SAFETY INFORMATION

- **Maximum Weight Capacity:** The top surface of this shoe storage bench is designed to support a maximum weight of **300 pounds (136 kg)**. Do not exceed this limit to prevent damage or injury.
- **Indoor Use Only:** This product is intended for indoor use only. Exposure to outdoor elements can cause damage to the materials and compromise its structural integrity.
- **Stable Placement:** Ensure the bench is placed on a flat, stable surface to prevent tipping.
- **Children Safety:** Keep small children away from moving parts during operation and assembly. Do not allow children to climb on or play inside the drawers.

3. SETUP AND ASSEMBLY

The HOOBRO Rattan Shoe Storage Bench is designed for straightforward assembly. All necessary hardware and detailed instructions are included in the product packaging. Please follow the step-by-step guide provided with your purchase carefully.

Key Assembly Tips:

- Unpack all components and verify against the parts list in the instruction manual.
- Assemble on a soft, clean surface to prevent scratching the furniture.

- Do not overtighten screws during initial assembly; tighten fully once all parts are aligned.
- If you encounter any difficulties, refer to the troubleshooting section or contact customer support.

4. OPERATING INSTRUCTIONS

4.1 Using the Tipping Bucket Drawers

The shoe storage bench features two tipping bucket drawers for easy access and organization of your footwear. Each drawer can accommodate approximately 4 pairs of adult shoes.

- To open, gently pull the handle on the drawer front. The drawer will tip forward, revealing the internal shelves.
- To close, push the drawer firmly back into the bench until it is flush with the frame.



Image: Both flip drawers open, showing shoes stored inside.

4.2 Adjustable Shelves

Each tipping drawer is equipped with adjustable or removable shelves, allowing you to customize the storage space for various shoe types, including sneakers, dress shoes, and boots.

- To adjust a shelf, carefully lift it from its current position and place it into the desired slot.
- To remove a shelf, simply lift it out of the drawer. This creates a larger compartment for taller items like boots.

Adjustable Shelves

Flexible height settings for storing different sizes of shoes and boots.



Image: Adjustable shelves inside a flip drawer, demonstrating flexibility for various shoe sizes.

4.3 Seating Function

The sturdy top surface of the bench doubles as a comfortable seat, allowing you to sit down and change shoes without bending over. Ensure the bench is stable before using it as a seat.



Image: A person utilizing the bench as a seat for changing shoes.

5. MAINTENANCE

To keep your HOOBRO Rattan Shoe Storage Bench in optimal condition, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the engineered wood finish and rattan-like elements.
- **Dusting:** Regularly dust the bench with a dry, soft cloth to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the material.
- **Ventilation:** The bench features an open back design to help keep shoes dry and reduce odors. Ensure adequate airflow around the unit.

Breathable Design

Open back helps to keep shoes and boots dry and odorless.



Image: Illustration of the breathable design with airflow arrows.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Shoes do not fit in drawers:** For larger shoe sizes (e.g., men's size 10.5 and above), shoes may need to be placed sideways or the internal shelves may need to be adjusted or removed to accommodate them.
- **Drawers are difficult to open/close:** Ensure that shoes are properly placed within the compartments and are not obstructing the drawer mechanism. Check for any foreign objects that might be blocking the drawer's movement.
- **Bench feels unstable:** Verify that all assembly screws are securely tightened. Ensure the bench is placed on a level surface.

7. SPECIFICATIONS

or warranty claims, please contact HOOBRO customer service. Refer to the contact information provided in your product packaging or visit the official HOOBRO website for support.

Please retain your purchase receipt for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question