

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw 22mm Glitter Clear Silicone Smart Watch Band Instruction Manual for GTX12 and T60 Series

Lamshaw GTX12, T60

Lamshaw 22mm Glitter Clear Silicone Smart Watch Band Instruction Manual

Compatible with GTX12 and T60 Series Smart Watches

1. PRODUCT OVERVIEW

The Lamshaw 22mm Glitter Clear Silicone Smart Watch Band is designed to provide a comfortable and secure fit for compatible smartwatches. Crafted from soft, transparent silicone with embedded glitter, this band offers a lightweight and flexible wearing experience. It features a quick-release metal buckle for easy attachment and removal.



Image 1: The Lamshaw 22mm Glitter Clear Silicone Smart Watch Band in blue, attached to a smartwatch, showcasing its transparent and glitter-infused design.

2. COMPATIBILITY

This 22mm size band is compatible with the following smartwatches:

- Fitpolo GTX12
- ENOMIR GTX12
- Tensky GTX12
- uave T60

- QXQ T60
- QCOQ T60

Before ordering, please verify your watch model to ensure proper fitment. If unsure, consult your watch's documentation or contact the manufacturer.

Compatible with Model



Fitpolo GTX12



ENOMIR GTX12



Tensky GTX12



uaue, QXQ, QCOQ T60

Image 2: Visual representation of various smartwatch models, including Fitpolo GTX12, ENOMIR GTX12, Tensky GTX12, uaue T60, QXQ T60, and QCOQ T60, illustrating compatibility with the 22mm band.

3. INSTALLATION AND REMOVAL

The Lamshaw smart watch band is designed for easy installation and removal, featuring a quick-release mechanism.

3.1. Installation

1. Locate the quick-release pins on the ends of the watch band.
2. Align one end of the pin with the lug hole on your smartwatch.
3. Push the quick-release lever inward to retract the pin, then guide the other end into the opposite lug hole.
4. Release the lever, ensuring both ends of the pin are securely seated in the watch lugs. Gently tug on the band to confirm it is locked in place.

3.2. Removal

1. Turn your smartwatch over to access the underside of the band.
2. Locate the quick-release lever on one side of the band.
3. Push the quick-release lever inward to retract the pin, then gently pull the band away from the watch case.
4. Repeat for the other side of the band.

4. FEATURES

- **Glitter Appearance:** These silicone bands incorporate glitter for a distinctive visual appeal.
- **Slim and Narrow Design:** The band's design is thinner and more flexible, contributing to a lighter feel and allowing for greater wrist movement. This design is particularly suitable for individuals preferring a less bulky watch band.
- **Comfortable Material:** Made from soft silicone, the band is designed for comfort during extended wear.
- **Easy Installation:** Equipped with a quick-release metal buckle for straightforward attachment and detachment from your smartwatch.



Image 3: A rear view of a smartwatch fitted with the glitter clear silicone band, emphasizing its transparent quality, lightness, softness, and subtle shine.



Image 4: Several smartwatches displaying the glitter clear silicone band in different colors, illustrating the product's aesthetic and design consistency.

5. CARE AND MAINTENANCE

To maintain the appearance and longevity of your silicone watch band, follow these guidelines:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely before reattaching to your watch.
- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals, solvents, or abrasive cleaners, as these can damage the silicone material and glitter.
- **Storage:** Store the band in a cool, dry place away from direct sunlight when not in use to prevent discoloration or degradation of the material.

6. SPECIFICATIONS

Specification	Detail
Material	Silicone

Band Width	22mm
Clasp Type	Tang Buckle
Metal Type	No Metal Type (for band material)

7. TROUBLESHOOTING

- **Band does not fit:** Ensure your smartwatch model is listed under the compatibility section and that it requires a 22mm band.
- **Difficulty installing:** Ensure the quick-release pins are fully retracted and aligned with the lug holes. Do not force the band; if it does not slide in easily, re-check alignment.
- **Band feels loose/tight:** The band is designed to be adjustable. Ensure the tang buckle is secured in an appropriate hole for your wrist size.

8. WARRANTY AND SUPPORT

For information regarding returns or product support, please refer to the retailer's return policy or contact Lamshaw customer service directly. A 30-day return policy is typically offered for this product.