

Decaura US55535BK

Decaura Kitchen Faucet with Pull Down Sprayer

Model: US55535BK

Manufacturer: Decaura

INTRODUCTION

Thank you for choosing the Decaura Kitchen Faucet with Pull Down Sprayer. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new faucet. Please read this manual thoroughly before installation and keep it for future reference. This high-quality faucet is designed for durability and ease of use, featuring a matte black finish and stainless steel construction.



Image: Decaura Kitchen Faucet with Pull Down Sprayer in Matte Black.

SETUP AND INSTALLATION

Before beginning installation, ensure you have all necessary tools and components. The Decaura Kitchen Faucet is designed for easy installation and can fit 1 or 3-hole kitchen sinks with the included deck plate.

Included Components:

- Faucet body with pre-attached supply lines
- Deck plate (for 3-hole installation)
- Mounting hardware (washer, nut, screws)
- Gravity ball weight
- User manual

Installation Steps:

1. Insert the faucet body into the sink hole(s). If using a 3-hole sink, place the deck plate first.
2. From underneath the sink, secure the faucet using the rubber washer, metal washer, and mounting nut. Tighten the screws on the mounting nut for a firm hold.
3. Connect the hot and cold water supply lines to your angle stops. Ensure a tight, leak-free connection.
4. Attach the pull-down hose to the quick-connect fitting on the faucet's underside.
5. Install the gravity ball weight onto the pull-down hose. For optimal retraction, position the gravity ball approximately 1.77 inches from the bottom of the hose loop.



Image: All mounting accessories and parts included for installation.



Image: Proper placement of the gravity ball on the pull-down hose for optimal retraction.

Installation Video:

For a visual guide, please refer to the official installation video:

Video: Official installation instructions for the Decaura Kitchen Faucet, demonstrating each step from mounting to connecting water lines and installing the gravity ball.

OPERATING INSTRUCTIONS

The Decaura Kitchen Faucet is designed for versatile and convenient use in your kitchen.

Single Handle Operation:

The single lever handle controls both water flow volume and temperature. Move the handle forward 90 degrees for cold water and backward for hot water. This design allows for installation in tighter spaces without requiring back clearance.




Image: Illustration of the single lever handle's 90-degree forward rotation for temperature control, designed to avoid hitting walls.

3-Function Pull-Down Sprayer:

The pull-down sprayer offers three distinct spray modes to suit various cleaning needs. Easily switch between modes directly on the spout.

- **Stream Mode:** Provides a steady, aerated flow for filling pots and general washing.
- **Spray Mode:** Delivers a wide, powerful spray for rinsing dishes and cleaning the sink.
- **Blade Mode:** Offers a stronger, concentrated water flow for stubborn food debris.

3-FUNCTION SPRAY HEAD



Stream/Spray Mode

Tap the button to switch between stream and spray




Image: Visual representation of the three spray functions: Stream, Spray, and Blade, available directly on the pull-down spray head.



Image: The pull-down sprayer extended up to 20 inches, demonstrating its reach for cleaning.

360-Degree Swivel:

The faucet features a 360-degree swivel capability, making it suitable for single or double sinks and providing maximum flexibility during use.



Stainless steel spray head

Enjoy long-lasting performance

Image: The faucet head swiveling 360 degrees, highlighting its versatility for various sink configurations.

Product Operation Video:

See the faucet in action with this product video:

Video: A demonstration of the Decaura Pull Down Kitchen Faucet in Matte Black, showcasing its features and functionality.

MAINTENANCE

To ensure the longevity and pristine appearance of your Decaura Kitchen Faucet, follow these maintenance guidelines:

- **Regular Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish.
- **Spot Cleaning:** For water spots or fingerprints, wipe with a damp cloth and dry immediately to prevent mineral buildup.
- **Aerator Maintenance:** Periodically unscrew the aerator from the spray head and clean any mineral deposits or debris to maintain optimal water flow.
- **Hose and Weight:** Ensure the pull-down hose moves freely and the gravity ball weight is positioned correctly for smooth retraction.

- **Ceramic Spool:** The faucet features a durable ceramic spool designed for 500,000 cycles, providing sensitive control. No regular maintenance is required for the spool itself, but ensure water quality is good to prevent premature wear.

TROUBLESHOOTING

If you encounter any issues with your Decaura Kitchen Faucet, please refer to the common troubleshooting tips below. For problems not listed or if issues persist, contact Decaura customer support.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; kinked supply lines.	Clean aerator; fully open shut-off valves; check supply lines for kinks.
Leaking from Faucet Base	Loose mounting nut; worn O-rings.	Tighten mounting nut; contact support for replacement O-rings.
Sprayer Not Retracting Fully	Gravity ball weight misplaced or obstructed; hose kinked.	Adjust gravity ball position; clear any obstructions; straighten hose.
Water Temperature Issues	Incorrect hot/cold supply line connection; water heater issues.	Verify supply line connections; check water heater settings.

SPECIFICATIONS

Feature	Detail
Brand	Decaura
Model Name	US55535BK
Material	Stainless Steel (SUS304)
Color	Matt Black
Number of Handles	1 (Single Lever)
Mounting Type	Deck Mount (1 or 3 Holes)
Spout Height	7.3 Inches
Spout Reach	20 Inches (Pull-down extension)
Item Weight	6.2 Pounds
Product Dimensions	11.8"D x 2.8"W x 26.8"H
Special Features	Pull Down Sprayer, 360 Swivel, 3 Function Sprayer, Lead Free
Valve Type	Ceramic Cartridge Valve



Image: Detailed dimensions of the Decaura Kitchen Faucet, including height and spout reach.

WARRANTY AND SUPPORT

The Decaura Kitchen Faucet comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact Decaura customer support.

Customer Support:

If you have any questions, require technical assistance, or need to claim warranty service, please contact Decaura US customer support. Contact information can typically be found on the product packaging or the official Decaura website.

We are committed to providing quality products and excellent customer service.