

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LIGHTAILING](#) /
- › [LIGHTAILING LED Lighting Kit for Lego 10369 Plum Blossom Instruction Manual](#)

LIGHTAILING 10369

LIGHTAILING LED Lighting Kit for Lego 10369 Plum Blossom

Model: 10369 | Brand: LIGHTAILING

1. PRODUCT OVERVIEW

The LIGHTAILING LED Lighting Kit is specifically designed to bring your Lego 10369 Plum Blossom model to life with vibrant illumination. This kit provides a custom lighting solution, transforming your static model into a dynamic display piece. Please note that this product is a lighting accessory and **does not include the Lego 10369 Plum Blossom model set**.




Image: The LIGHTAILING LED Lighting Kit installed and illuminating the Lego 10369 Plum Blossom model.

2. SETUP AND INSTALLATION

2.1 Package Contents

Before beginning installation, please verify that all components are present in your package:

- 1 x USB Light Kit
- 1 x Instruction Guide
- 1 x Battery Box



Image: Overview of the LIGHTAILING LED Lighting Kit package contents, including the product box, instruction manual, remote control, and USB light kit.

2.2 Power Requirements

The lighting kit can be powered using either three AA batteries (not included) or a USB charger. When using a USB charger, ensure the voltage is **less than 5V** to prevent damage to the lighting components.

2.3 Installation Steps

The installation of the light set is designed to be integrated with your Lego 10369 Plum Blossom model. Follow the detailed instructions provided in the included instruction guide for precise placement of each LED and wire. Install the LED lights carefully, avoiding hard pulling, bending, or shaking of the components to ensure proper function and longevity.




Image: A close-up view of the illuminated base of the Lego Plum Blossom model, demonstrating the effect of the installed lighting kit.

3. OPERATION

3.1 Powering On/Off

Once the lighting kit is fully installed and connected to a power source (batteries or USB), the lights will illuminate. To turn the lights off, disconnect the power source.

3.2 Adjusting Brightness

If your kit includes a remote control or dimmer, refer to the instruction guide for specific steps on adjusting the brightness levels of the LED lights. This allows you to customize the ambiance of your illuminated model.



Image: A visual representation demonstrating the adjustable brightness feature of the lighting kit, showing a dimmer control.

3.3 Operational Demonstration Video

Your browser does not support the video tag.

Video: This video demonstrates the LIGHTAILING LED Lighting Kit for the Lego 10369 Plum Blossom model in operation, showcasing how the lights illuminate the model and enhance its appearance.

4. MAINTENANCE

To ensure the longevity and optimal performance of your LIGHTAILING LED Lighting Kit, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the LED components and wires with a soft, dry cloth to remove dust. Avoid using liquid cleaners directly on the electrical components.
- **Handling:** Always handle the installed lighting kit with care. Avoid excessive force, hard pulling, bending, or shaking, as this can damage the delicate wires and connections.
- **Storage:** If storing the model with the lighting kit installed, ensure it is placed in a stable environment where it will not be subjected to pressure or impact.

5. TROUBLESHOOTING

If you encounter any issues with your lighting kit, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Lights do not turn on.	No power, incorrect battery installation, or loose connection.	Check if batteries are correctly inserted or if the USB cable is securely connected. Ensure the power source is active.

Problem	Possible Cause	Solution
Lights are dim or flickering.	Low battery power or unstable power supply.	Replace batteries or try a different USB power source. Ensure USB voltage is stable and less than 5V.
Individual lights are not working.	Damaged LED or loose wire connection.	Carefully inspect the specific LED and its wiring for any visible damage or disconnections. Re-secure any loose connections. Avoid hard pulling on wires during installation.
Lights pop off the model.	Insufficient attachment or improper installation.	Ensure each light component is securely attached to the Lego bricks as per the instruction guide. Apply gentle, firm pressure during installation.

6. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	LIGHTAILING
Model Number	10369
Light Source Type	LED
Power Source	Battery Powered (3x AA, not included) / USB (Voltage < 5V)
Material	Plastic
Color	Colorful
Item Weight	3.53 ounces (100 Grams)
Product Dimensions	6.5 x 4.72 x 1.57 inches
Recommended Age	6 years and up

7. WARRANTY AND SUPPORT

LIGHTAILING is committed to providing quality products and services. If you encounter any problems with your LED lighting kit, please do not hesitate to contact the seller or manufacturer directly for assistance. Refer to your purchase documentation for specific warranty details and contact information.