

Aiwa PB-07

AIWA PartyBox PB-07 Bluetooth Speaker User Manual

Model: PB-07

1. INTRODUCTION

1.1 Welcome

Thank you for choosing the AIWA PartyBox PB-07 Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure optimal performance and longevity.

1.2 Key Features

- 100W RMS Power Output
- High-Definition Sound with 6.5" Woofer and 1.5" Tweeter
- AIWA Brasil App Control for DJ Effects, Equalization, and Light Modes
- IPX4 Water Resistance (splash-proof)
- Up to 8 Hours Battery Life
- Dynamic RGB Color Lights
- Multiple Connectivity Options: Bluetooth 5.3, USB, AUX, Micro SD, Microphone Input
- True Wireless Sound (TWS) Function for connecting two speakers
- Compact Size with Carry Handle

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent damage to the device or personal injury:

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Avoid submerging the speaker in water, despite its IPX4 rating, which protects against splashes only.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for assistance.
- Keep the speaker away from children and pets.
- Use only the provided charging cable.
- Ensure proper ventilation when charging and operating the speaker.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x AIWA PartyBox PB-07 Speaker
- 1 x Charging Cable
- 1 x User Manual

4. PRODUCT OVERVIEW

4.1 Speaker Components

The AIWA PartyBox PB-07 features a robust design with intuitive controls. Below is an overview of its main components.



Figure 1: Front view of the AIWA PartyBox PB-07 speaker, showcasing its dynamic RGB lighting.

4.2 Control Panel

The control panel is located on the top of the speaker, providing easy access to various functions.

3,7 kg



Figure 2: Top view of the AIWA PartyBox PB-07, highlighting the control buttons and input slots.

Common controls include:

- **Power Button:** To turn the speaker on or off.
- **Volume Controls:** Adjust the playback volume.
- **Play/Pause Button:** Control music playback.
- **Mode Button:** Switch between input sources (Bluetooth, USB, AUX, Micro SD).
- **Light Mode Button:** Change RGB lighting effects.

4.3 Input/Output Ports

The speaker offers multiple connectivity options:

The advertisement is split into two main sections. The left section features a large, stylized 'PB' logo in blue and green, with the AIWA PartyBox PB-07 speaker positioned in front of it. The speaker has a colorful RGB light effect. Below the logo, the text reads 'ATÉ 8 HORAS* DE REPRODUÇÃO' and 'Aproveite a música sem se preocupar com a bateria!'. A small footnote at the bottom left states: '*8 horas com 50% do volume e luzes desligados. A duração real da bateria varia conforme as condições de uso.' The right section has a dark background with the text 'RGB COLOR LIGHTS' in a colorful font, followed by 'LUZ, COR E AÇÃO' in large, multi-colored letters. Below this, it says 'Mergulhe no cenário pulsante das luzes dinâmicas com efeito MULTICOLORIDO. Um motivo a mais para deixar a galera ainda mais animada.' At the bottom right, there is a photograph of three young people (two men and one woman) smiling and posing with the AIWA PartyBox PB-07 speaker outdoors.

Figure 3: Diagram illustrating the various input ports available on the AIWA PartyBox PB-07 speaker.

- **Microphone Input:** For connecting an external microphone.
- **USB Port:** For USB drive playback.
- **AUX Input:** For connecting external audio devices via a 3.5mm audio cable.
- **Micro SD Card Slot:** For Micro SD card playback.
- **Charging Port:** For connecting the charging cable.

5. SETUP GUIDE

5.1 Charging the Speaker

Before initial use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and a suitable power adapter. The charging indicator will show the charging status. A full charge provides up to 8 hours of playback, depending on volume and light usage.

MÚLTIPLAS CONEXÕES

✓ 1 ENTRADA PARA MICROFONE

✓ 1 ENTRADA AUX

✓ 1 ENTRADA USB

✓ 1 ENTRADA MICRO SD



Figure 4: The AIWA PartyBox PB-07 is designed for up to 8 hours of continuous playback on a single charge.

5.2 Powering On/Off

Press and hold the **Power Button** on the control panel to turn the speaker on or off.

5.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing Bluetooth light).
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "AIWA PB-07" from the list of devices.
4. Once paired, the Bluetooth indicator light will become solid, and you will hear a confirmation sound.



LEVE SUA FESTA PARA ONDE QUISER!

Com tamanho compacto e alça de transporte,
carregue a PartyBox AIWA com você

Figure 5: The AIWA PartyBox PB-07 features Bluetooth 5.3 for stable and efficient wireless connections.

5.4 True Wireless Sound (TWS) Pairing

The TWS function allows you to connect two AIWA PartyBox PB-07 speakers for a stereo audio experience.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the TWS button (refer to control panel diagram for exact button location).
3. The speakers will automatically search and pair with each other. A confirmation sound will indicate successful pairing.
4. Once paired, connect your mobile device to one of the speakers via Bluetooth as described above. Both speakers will then play audio in stereo.

SEU SMARTPHONE NO CONTROLE

Baixe o aplicativo **AIWA Brasil**, comande a equalização, controle as luzes e ative o **BOOST** para sentir os graves pulsarem.



*App Store® é marca registrada da Apple Inc., registrada nos EUA e em outros países.
*Google Play e o logotipo do Google Play são marcas registradas da Google LLC.



DUPLIQUE SUA EXPERIÊNCIA SONORA

Amplie o som da sua festa com a função **TWS (True Wireless Sound)**. Basta conectar duas PartyBoxes AWS-PB-07 e obter um áudio mais rico.



*Para a execução da função os dispositivos devem ser do mesmo modelo.

Figure 6: Visual representation of two AIWA PartyBox PB-07 speakers connected via TWS for enhanced stereo sound.

5.5 AIWA Brasil App Control

Enhance your experience by controlling the speaker's functions, including DJ Effects, equalization, and light modes, via the AIWA Brasil app.

1. Download the AIWA Brasil app from your device's app store:
 - [Download on the App Store](#)
 - [Get it on Google Play](#)
2. Ensure your speaker is powered on and connected to your mobile device via Bluetooth.
3. Open the AIWA Brasil app and follow the on-screen instructions to connect to your speaker.
4. Through the app, you can adjust bass, mid, and treble levels, activate BOOST for stronger bass, and customize RGB light patterns.



APP **aiwa**

Comande a equalização do seu som. E, ao ativar a função BOOST, desfrute de graves mais potentes, principalmente quando o volume estiver acima de 70%.



*App Store® é marca registrada da Apple Inc., registrado nos EUA e em outros países.

*Google Play e o logotipo do Google Play são marcas registradas da Google LLC.

Figure 7: Screenshot of the AIWA Brasil app interface, showing equalization and DJ effects controls.

6. OPERATING INSTRUCTIONS

6.1 Audio Playback

After connecting your audio source (Bluetooth, USB, AUX, Micro SD), you can control playback using the speaker's control panel or your connected device.

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up/Down:** Press the Volume + or Volume - buttons.
- **Next/Previous Track:** Use the dedicated track skip buttons (if available, otherwise control from source device).

6.2 Using Microphone Input

Connect a microphone to the dedicated microphone input port. Adjust the microphone volume using the corresponding knob (if available) or through the AIWA Brasil app.

6.3 RGB Lighting Effects

Press the **Light Mode Button** to cycle through different RGB lighting effects. You can also customize and control the lights via the AIWA Brasil app.



Luzes dinâmicas
com efeitos
MULTICOLORIDOS



**BATERIA DE
8 HORAS***

Bateria recarregável de alto desempenho

(*) 8 horas com 50% do volume e luzes desligados.
A duração real da bateria varia conforme as condições de uso.

Figure 8: The AIWA PartyBox PB-07 displaying its vibrant RGB color lighting effects.

7. CARE AND MAINTENANCE

7.1 Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the surface.

7.2 Water Resistance (IPX4)

The AIWA PartyBox PB-07 is IPX4 rated, meaning it is resistant to splashes of water from any direction. This makes it suitable for outdoor use or near pools, but it is **not waterproof**. Do not submerge the speaker in water or expose it to heavy rain.

SOM DE ALTA DEFINIÇÃO

Uma experiência sonora sem distorções,
com graves excelentes e agudos mais nítidos



1 WOOFER DE 6,5” + 1 TWEETER DE 1,5”

Figure 9: The AIWA PartyBox PB-07 positioned near a pool, demonstrating its IPX4 splash-resistant design.

8. TROUBLESHOOTING

If you encounter issues with your AIWA PartyBox PB-07, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the Power button for a few seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is in Bluetooth pairing mode. Enable Bluetooth on your device. Move device closer to speaker (within 10 meters).

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on speaker or source device; Incorrect input mode.	Increase volume on both speaker and source device. Ensure correct input mode is selected (Bluetooth, USB, AUX, Micro SD).
TWS pairing fails.	Speakers already connected to another device; Speakers too far apart.	Disconnect both speakers from any Bluetooth devices. Ensure speakers are close to each other during TWS pairing.
App not connecting to speaker.	Bluetooth not connected; App permissions missing.	Ensure Bluetooth is connected. Check app permissions (e.g., location access) on your phone. Restart the app and speaker.

9. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	AIWA PartyBox PB-07
Power Output	100W RMS
Speaker Type	Woofer (6.5 inches), Tweeter (1.5 inches)
Connectivity	Bluetooth 5.3, USB, AUX, Micro SD, Microphone Input
Battery Life	Up to 8 hours (at 50% volume with lights off)
Water Resistance	IPX4 (splash-proof)
Special Features	RGB Color Lights, TWS Function, AIWA Brasil App Control
Dimensions (W x D x H)	26.4 cm x 25.5 cm x 30.2 cm (approximately 10.4 x 10.0 x 11.9 inches)
Weight	3.79 kg (approximately 8.35 lbs)
Material	PP
Certification	ANATEL: 06884-24-16928



Bluetooth 5.3: Conexão mais rápida e mais estável, com menor consumo de energia



Conecte duas PartyBoxes AWS-PB-07 e turbine sua festa!

Figure 10: Detailed dimensions and weight of the AIWA PartyBox PB-07 speaker.

10. WARRANTY AND SUPPORT

10.1 Manufacturer's Warranty

The AIWA PartyBox PB-07 comes with a **12-month manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

The warranty does not cover damages caused by:

- Accidental damage or misuse.
- Unauthorized repairs or modifications.
- Normal wear and tear.
- Failure to follow instructions in this manual.

10.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact AIWA customer support through their official channels. Refer to the AIWA Brasil website or the contact information provided with your purchase for details.

You can also visit the official AIWA store on Amazon for more information: [AIWA Official Store](#)

