

BAODLON BD-RC Truck-01-Green

BAODLON RC Monster Truck BD-RC Truck-01-Green Instruction Manual

Model: BD-RC Truck-01-Green

Brand: BAODLON

1. SAFETY INFORMATION

- Recommended age: 36 months - 12 years. Adult supervision is recommended for younger children.
- Keep hands, hair, and loose clothing away from moving parts (wheels, etc.) when the vehicle is in operation.
- Do not operate the vehicle near people, pets, or fragile objects.
- Avoid operating in wet conditions or near water to prevent electrical damage.
- Do not use the quick-charge charging device to charge, to avoid burning out the USB charging cable.
- Always turn off the vehicle and remote control when not in use.
- Remove batteries from the remote control if storing for extended periods.

2. PACKAGE CONTENTS

Please check the package to ensure all items are present:

- BAODLON RC Monster Truck (with built-in rechargeable battery)
- 2.4GHz Remote Control
- USB Charging Cable
- Screwdriver
- Small Water Bottle (for spray function)
- Product Manual (this document)



Image: The BAODLON RC Monster Truck, its remote control, and included accessories such as a screwdriver and charging cable, displayed next to the product box.

3. SETUP

3.1 Remote Control Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Use the included screwdriver to open the battery compartment cover.
3. Insert 2 x 1.5V "AAA" batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

3.2 Charging the Vehicle Battery

The RC Monster Truck has a built-in rechargeable battery.

1. Ensure the vehicle is turned off before charging.

2. Connect the USB charging cable to the charging port on the vehicle.
3. Connect the other end of the USB charging cable to a standard USB power adapter (e.g., computer USB port, wall charger, not a quick-charge device).
4. The charging indicator light will show the charging status (refer to the light behavior described in the product packaging for specifics).
5. Once fully charged, disconnect the charging cable. A full charge provides up to 25 minutes of playtime.

3.3 Adding Water for Spray Function

1. Locate the water inlet on the top of the vehicle.
2. Use the provided small water bottle to carefully fill the water tank with clean tap water. Do not overfill.
3. Close the water inlet securely.



Image: A close-up of the RC Monster Truck showing the water inlet and the process of adding water using the small bottle for the mist spraying function.

4. OPERATING INSTRUCTIONS

4.1 Pairing the Remote Control

1. Turn on the RC Monster Truck using the power switch located on the vehicle.
2. Turn on the remote control.
3. The remote control and vehicle will automatically pair. The indicator light on the remote will stop flashing and remain solid once paired.
4. If pairing fails, turn off both devices and repeat the steps.



Image: The BAODLON RC Monster Truck and its 2.4GHz remote control, highlighting the radio system for anti-interference operation.

4.2 Basic Controls

The remote control allows for precise movement and stunts. The control range is up to 130 ft.

- **Forward/Backward:** Use the left joystick (or corresponding button) to move the truck forward or backward.
- **Turn Left/Right:** Use the right joystick (or corresponding button) to steer the truck left or right.

4.3 Stunt Functions

The RC Monster Truck is capable of various stunts:

- **360° Rotation:** Press the designated stunt button (refer to remote diagram on packaging) to perform a 360-degree spin in place.
- **Upright 360° Rotation:** The truck can perform a 360-degree rotation while standing upright.
- **Upright Forward:** The truck can move forward while maintaining an upright position.



Image: A sequence of images demonstrating the RC Monster Truck performing a 360-degree rotation, an upright 360-degree rotation, and moving forward while upright.

4.4 Spray Function

After filling the water tank (Section 3.3), activate the spray function:

- Press the "Fog On / Off" button on the remote control to activate or deactivate the mist spray.

4.5 LED Lights

The truck features captivating LED lights that enhance the play experience, especially in low-light conditions. These lights activate automatically when the truck is powered on.



Image: The BAODLON RC Monster Truck illuminated with colorful LED body lights, showcasing its visual appeal during operation.

EXCITING RC EXPERIENCE



Image: The BAODLON RC Monster Truck highlighting its key features: 2.4GHz control, over 25 minutes of run time, 3 LED lights, 360-degree spin capability, and 4-wheel drive.

5. MAINTENANCE

5.1 Cleaning

- Turn off the vehicle and remote control before cleaning.
- Wipe the vehicle with a soft, dry cloth. Do not use chemical cleaners or water directly on electronic components.
- Remove any debris (dirt, grass, hair) from the wheels and axles to ensure smooth operation.

5.2 Storage

- Store the vehicle and remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- Remove AAA batteries from the remote control if storing for extended periods to prevent leakage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not respond to remote.	- Vehicle or remote is off. - Batteries in remote are low or incorrectly installed. - Vehicle battery is low. - Not paired correctly.	- Ensure both are switched ON. - Check remote batteries, replace if necessary, and ensure correct polarity. - Charge the vehicle battery fully. - Turn off both devices and re-pair (Section 4.1).
Vehicle moves slowly or inconsistently.	- Vehicle battery is low. - Obstruction in wheels/axles.	- Charge the vehicle battery fully. - Clear any debris from moving parts.
Spray function not working.	- Water tank is empty. - Spray button not pressed.	- Refill water tank (Section 3.3). - Ensure the "Fog On / Off" button is pressed.
Interference with other RC vehicles.	Operating multiple 2.4GHz devices in close proximity.	The 2.4GHz system is designed to minimize interference. If issues persist, try operating in a different area or ensure other devices are off.

7. SPECIFICATIONS

Model Number	BD-RC Truck-01-Green
Product Dimensions	7 x 5 x 4 inches
Item Weight	14.4 ounces
Recommended Age	36 months - 12 years
Vehicle Battery	Built-in Rechargeable Battery
Remote Control Batteries	2 x 1.5V "AAA" batteries (not included)
Playtime	Up to 25 minutes (per full charge)
Control Frequency	2.4GHz
Control Range	Up to 130 ft
Material	High-quality ABS material

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official BAODLON website. Keep your purchase receipt as proof of purchase.

Manufacturer: BAODLON

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question