LOFREE EP115

LOFREE Wavy Chips Dual-Mode Wireless Mouse (Model EP115) User Manual

Your guide to setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the LOFREE Wavy Chips Dual-Mode Wireless Mouse. This mouse is designed for comfort and versatility, offering both Bluetooth and 2.4GHz wireless connectivity, adjustable DPI settings, and multi-gesture support. This manual provides detailed instructions to help you get started and make the most of your new device.

2. PACKAGE CONTENTS

Please check the package for the following items:

- LOFREE Wavy Chips Dual-Mode Wireless Mouse
- USB Receiver (2.4GHz)
- USB-C Charging Cable
- User Manual

3. SETUP AND CONNECTION

The LOFREE Wavy Chips mouse supports two connection modes: Bluetooth and 2.4GHz wireless. You can connect to up to two devices simultaneously.

3.1 Power On/Off and Mode Selection

Locate the switch on the bottom of the mouse. Slide it to 'ON' to power on the mouse. To select your preferred connection mode, use the dedicated switch:

- **Bluetooth Mode:** Slide the switch to the Bluetooth icon.
- **2.4GHz Mode:** Slide the switch to '2.4G'.

Image: Mouse bottom with dual mode connection options and 2.4GHz receiver.

3.2 2.4GHz Wireless Connection

1. Take out the USB receiver from the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Slide the mode switch on the mouse to '2.4G'. The mouse will automatically connect to your device.

3.3 Bluetooth Connection

1. Slide the mode switch on the mouse to the Bluetooth icon.
2. On your device (computer, tablet, or phone), go to Bluetooth settings.
3. Search for new devices and select "LOFREE Wavy Chips Mouse" from the list.
4. Confirm pairing if prompted. The mouse will connect.

The mouse can connect to two devices simultaneously. To switch between connected devices, briefly press the mode switch on the bottom of the mouse.

Image: Mouse connected to multiple devices simultaneously.

4. OPERATING INSTRUCTIONS

4.1 Adjustable DPI Levels

The mouse features 5 adjustable DPI (Dots Per Inch) levels, allowing you to customize cursor sensitivity to your preference. The available DPI settings are typically 800, 1600, 2400, and 3600 DPI.

- To adjust the DPI, press the dedicated DPI button located on the top of the mouse, near the scroll wheel.

- Each press will cycle through the available DPI levels.

Image: Mouse with DPI adjustment button and visual representation of DPI levels.

4.2 Thumb Wheel and Multi-Gesture Button

The mouse is equipped with a thumb wheel and an additional button designed for multi-gesture use, enhancing navigation and productivity.

- The thumb wheel allows for horizontal scrolling or other customizable functions depending on your operating system settings.
- The multi-gesture button can be programmed for various shortcuts or actions, such as switching between applications or virtual desktops. Refer to your operating system's mouse settings for customization options.

Image: Mouse held in hand, showing thumb wheel and multi-gesture button.

5. BATTERY LIFE AND CHARGING

The LOFREE Wavy Chips mouse is powered by a built-in Lithium Polymer battery, offering an impressive battery life of up to 50 days on a single charge, depending on usage.

- To charge the mouse, connect the provided USB-C charging cable to the charging port on the mouse and to a USB power source.
- An indicator light will typically show the charging status.
- It is recommended to fully charge the mouse before its first use.

Image: Mouse highlighting its long battery life.

6. COMPATIBILITY

The LOFREE Wavy Chips mouse is designed for broad compatibility across various operating systems:

- **Windows:** Fully compatible with Windows operating systems.
- **MacOS:** Fully compatible with MacOS operating systems.
- **iOS:** Compatible with iOS devices that support mouse input.
- **Android:** Compatible with Android devices that support mouse input.

Image: Mouse compatibility across Windows, MacOS, iOS, and Android.

7. MAINTENANCE

To ensure the longevity and optimal performance of your LOFREE Wavy Chips mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Sensor Cleaning:** Periodically clean the optical sensor on the bottom of the mouse with a cotton swab to ensure accurate tracking.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store it in a cool, dry place.
- **Avoid Liquids:** Do not expose the mouse to liquids, as this can cause damage to internal components.

8. TROUBLESHOOTING

If you encounter any issues with your mouse, please refer to the following troubleshooting steps:

- **Mouse not responding:**

- Ensure the mouse is powered on.
- Check the battery level and charge if necessary.
- Verify the correct connection mode (Bluetooth or 2.4GHz) is selected.
- For 2.4GHz, ensure the USB receiver is securely plugged into your device.
- For Bluetooth, ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing if needed.

- **Cursor movement is erratic or slow:**

  - Clean the optical sensor on the bottom of the mouse.
  - Ensure you are using the mouse on a suitable surface.
  - Adjust the DPI settings to a higher sensitivity if the cursor is too slow.

- **Cannot connect to a second device:**

  - Ensure the mouse is in the correct pairing mode for the second device (e.g., Bluetooth pairing mode).
  - Follow the Bluetooth connection steps carefully for the new device.

9. SPECIFICATIONS

Feature	Detail
Model Number	EP115
Connectivity Technology	Bluetooth, 2.4GHz Wireless
DPI Levels	5 Adjustable Levels (e.g., 800, 1600, 2400, 3600)
Battery Type	1 Lithium Polymer (included)
Battery Life	Up to 50 days (approx.)
Special Features	Rechargeable, Soundless, Multi-Gesture Thumb Wheel
Movement Detection	Optical
Compatibility	Windows, MacOS, iOS, Android
Item Weight	14.9 ounces
Package Dimensions	8.11 x 6.06 x 2.32 inches

10. WARRANTY AND SUPPORT

LOFREE products are designed for quality and reliability. For specific warranty details, please refer to the warranty card included with your product or visit the official LOFREE website. If you require technical assistance or have questions not covered in this manual, please contact LOFREE customer support through their official channels.
Online Support: Visit the LOFREE official website for FAQs, drivers, and contact information.
Email Support: Refer to your product packaging or the official website for the customer support email address.