Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

memzuoix M-697

memzuoix Wired Optical Mouse M-697 User Manual

Model: M-697

Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your memzuoix Wired Optical Mouse, Model M-697. This ergonomic 5-button mouse features a 1400 DPI optical sensor and a 5-foot USB cable for a stable connection.

Package Contents

- memzuoix Wired Optical Mouse (M-697)
- Integrated USB Cable (5 feet)

Setup

The memzuoix Wired Optical Mouse is designed for plug-and-play functionality, requiring no additional drivers for most operating systems.

Connecting the Mouse

1. Locate an available USB-A port on your computer (PC, laptop, desktop, or MacBook).
2. Insert the USB connector of the mouse cable into the USB-A port.
3. The operating system will automatically detect and install the necessary drivers. The mouse will be ready for use within a few seconds.



Image: The memzuoix wired mouse, red and black, connected to a silver laptop via its USB-A cable. This illustrates the simple plug-and-play setup.



Image: A top-down view of the memzuoix wired mouse on a desk next to a laptop, with labels indicating its length (4.19 inches) and height (1.50 inches). This shows the compact size of the mouse.

Operating Instructions

Your memzuoix mouse features 5 buttons and a scroll wheel for efficient navigation.

Button Functions

- **Left Click Button:** Primary selection and activation.
- **Right Click Button:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls documents and web pages vertically. Can also be pressed for middle-click functionality (application-dependent). The scroll wheel has an anti-slip rubber surface.
- **Side Buttons (Forward/Backward):** Located on the left side of the mouse, these buttons allow for quick navigation (e.g., moving forward or backward in a web browser). *Note: Side buttons are not available for Mac OS.*



Image: A detailed view of the mouse's top and left side, highlighting the anti-slip rubber scroll wheel, and the "Previous Page Button" and "Next Page Button" on the side.



Image: The red and black mouse from a slightly elevated angle, with white arrows pointing to the main click areas, illustrating the ergonomic design for comfortable use.

Ergonomic Design

The mouse features an ergonomic shape with a convex arc designed to fit the natural curve of your hand, distributing pressure evenly across your palm to reduce strain during extended use. Its ambidextrous design makes it suitable for both right-handed and left-handed users.



Image: The mouse shown with an overlay indicating its ambidextrous design, suitable for both right and left-handed individuals. Smaller inset images show different hand grips.

DPI (Dots Per Inch)

The mouse operates at 1400 DPI, providing precise and responsive cursor control for various tasks.

Video Demonstration

Your browser does not support the video tag.

Video: A demonstration of the memzuoix Red Wired Mouse, highlighting its modern ergonomic design, left and right buttons, and forward and backward buttons. This video is provided by the seller.

Maintenance

Proper care will extend the life of your mouse.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.

- **Storage:** When not in use, store the mouse in a clean, dry environment. Avoid extreme temperatures.
- **Cable Care:** Do not sharply bend or pull the USB cable. This can damage the internal wires.

Troubleshooting

Problem	Solution
Mouse not responding	◦ Ensure the USB cable is securely plugged into a working USB port. ◦ Try plugging the mouse into a different USB port. ◦ Restart your computer. ◦ Test the mouse on another computer to determine if the issue is with the mouse or the computer.
Cursor movement is erratic or jumpy	◦ Ensure the optical sensor on the bottom of the mouse is clean and free of debris. ◦ Use the mouse on a clean, non-reflective surface or a mouse pad.
Side buttons not working on Mac OS	This is expected behavior. The side buttons are not supported on Mac OS. All other mouse functions will work normally.

Specifications

Feature	Detail
Brand	memzuoix
Model Name	M-697
Connectivity Technology	USB (Wired)
Movement Detection Technology	Optical
DPI	1400 DPI
Number of Buttons	5 (Left, Right, Scroll Wheel Click, Forward, Backward)
Cable Length	5 feet
Hand Orientation	Right (Ambidextrous design)
Compatible Devices	Personal Computer (PC, Laptop, Desktop, MacBook)
Operating System Compatibility	Windows 11, 10, 8.1, 8, 7, Vista, XP; Mac OS (side buttons not supported)
Item Weight	0.1 Kilograms
Material	Plastic

Warranty and Support

memzuoix provides a 12-month warranty for this product, covering manufacturing defects from the date of purchase.
For technical assistance or warranty claims, please contact memzuoix customer support. Refer to the product packaging or the official memzuoix website for contact details.

- **Warranty Period:** 12 Months
- **Support:** Lifetime customer support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBSJHDPZ

More documents and user manuals: **https://manuals.plus/**