

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Smuxee](#) /

› Smuxee Gold Luggage Rack Instruction Manual

Smuxee TXLJ0801004

Smuxee Gold Luggage Rack Instruction Manual

Model: TXLJ0801004

INTRODUCTION

Thank you for choosing the Smuxee Gold Luggage Rack. This foldable suitcase stand is designed to provide convenient and elevated storage for your luggage, enhancing comfort and organization in guest rooms, bedrooms, and hotels. Its sturdy construction and space-saving design make it an ideal solution for travelers and hosts alike.



Image: Two Smuxee Gold Luggage Racks, folded for compact storage.

SAFETY INFORMATION

- Ensure the luggage rack is fully unfolded and stable before placing any items on it.
- Do not exceed the maximum weight capacity: 88 lbs (top shelf) and 22 lbs (bottom shelf).
- Keep fingers clear of folding mechanisms during setup and folding to prevent pinching.
- Place the rack on a flat, stable surface to prevent tipping.
- Do not allow children to climb or play on the luggage rack.

PACKAGE CONTENTS

Your Smuxee Gold Luggage Rack package should contain the following:

- Smuxee Gold Luggage Rack frame (pre-assembled or requiring minor assembly)
- Fabric storage shelf (if applicable to your model)
- Nylon straps (pre-attached)

- Adjustable feet (pre-attached or requiring minor adjustment)
- Instruction diagram (if assembly is required)

Note: This product is typically sold as a pack of 2. Please verify your order for the correct quantity.

SETUP

The Smuxee Gold Luggage Rack is designed for easy setup. Some models may come fully assembled, while others require minimal, tool-free assembly.

Assembly Instructions (if applicable):

1. Carefully remove all components from the packaging.
2. Unfold the main frame of the luggage rack. Ensure the X-shaped support structure is fully extended.
3. If your model includes a separate fabric storage shelf, ensure it is securely attached to the lower frame. The nylon straps on the top shelf should be taut.
4. Adjust the feet at the bottom of the rack by twisting them to ensure stability on uneven surfaces. This also helps protect your floor from scratches.

MULTIPLE SCENES




Hotel



Big closet



Bedroom



Living room

Image: Easy Assembly Diagram.



Image: Adjustable Feet Detail.

OPERATING INSTRUCTIONS

Unfolding the Rack:

To use the luggage rack, simply pull the two main frame sections apart until the X-shaped structure is fully extended and locked into place. The rack will stand securely on its four legs.



Image: Luggage rack in use, providing elevated storage.

Placing Luggage:

Place your suitcase or bag on the top nylon straps. The elevated height allows for easy packing and unpacking without excessive bending or squatting. The lower fabric shelf can be used for shoes, smaller bags, or other personal items.

Easy To Pack Up

No need to bend or squat, let you pack easily.

After

Before

Image: Ease of packing with the luggage rack.

Folding for Storage:

When not in use, the luggage rack can be easily folded flat for compact storage. Gently push the two main frame sections together until the rack collapses. It can then be stored in a closet, under a bed, or against a wall.



Image: Expanded and Folded states of the luggage rack.



Image: Folded luggage rack stored against a wall.

Product Video:

For a visual guide on the features and use of the Smuxee Luggage Rack, please watch the official product video below:

Your browser does not support the video tag.

Video: Official product video demonstrating the foldable design and features of the Smuxee Luggage Rack.

MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. For the fabric shelf, spot clean with mild soap and water if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the folded luggage rack in a dry place to prevent rust or damage to the fabric.
- **Inspection:** Periodically check all connections and straps to ensure they are secure and in good condition.

TROUBLESHOOTING

Rack is unstable or wobbly:

- Ensure the rack is placed on a flat, level surface.
- Adjust the individual feet at the bottom of each leg by twisting them until the rack is stable.
- Verify that the X-shaped support structure is fully extended and locked.

Difficulty with assembly (if applicable):

- Refer to the "Easy Assembly" diagram provided in the Setup section.
- Ensure all parts are correctly oriented before attempting to connect them. Some components may appear similar but have specific orientations for proper fit.
- If you encounter significant resistance or parts do not align, double-check the diagram and ensure no parts are bent or damaged. Contact customer support if issues persist.

SPECIFICATIONS

Attribute	Detail
Brand	Smuxee
Model Number	TXLJ0801004
Material	Iron frame, Polyester fabric shelf, Nylon straps
Color	Gold (2PCS)
Unfolded Dimensions (L x W x H)	27.2 x 15 x 20.5 inches (69.1 x 38.1 x 52.1 cm)
Folded Dimensions (L x W x H)	27.2 x 4.3 x 26 inches (69.1 x 10.9 x 66 cm)
Item Weight	12.82 pounds (5.83 kg)
Weight Capacity (Top Shelf)	Up to 88 lbs (40 kg)
Weight Capacity (Bottom Shelf)	Up to 22 lbs (10 kg)
Assembly Required	No (minor assembly/adjustment may be needed for some models)



Image: Product Dimensions and Weight Capacity.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Smuxee customer service through the retailer's platform or the official Smuxee website. Please have your model number (TXLJ0801004) and purchase details ready when contacting support.

© 2025 Smuxee. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DBT8NCXK>

More documents and user manuals: <https://manuals.plus/>