



Manuals.plus /

› Secura /

› Secura 60-Minute Visual Timer User Manual

## Secura VT024-NB-NB

# Secura 60-Minute Visual Timer User Manual

Model: VT024-NB-NB

## 1. PRODUCT OVERVIEW

---

The Secura 60-Minute Visual Timer is an innovative time management tool designed to help individuals, especially children, visually understand the passage of time. Its unique cosmic design and silent operation make it ideal for various settings, including classrooms, offices, kitchens, and homes. This timer assists in improving focus, managing tasks, and reducing procrastination by providing a clear visual representation of remaining time.



Image: Secura 60-Minute Visual Timer in Navy Blue, featuring a clear dial and cosmic-themed design elements like a rocket and planets. This timer helps users visualize time passing.

## 2. SETUP AND BATTERY INSTALLATION

Before using your Secura Visual Timer, you will need to install two AAA batteries. Please ensure you use new alkaline batteries for optimal performance and to prevent damage to the device. Rechargeable batteries should not be used.

1. Locate the battery compartment on the back of the timer.
2. Open the battery compartment cover.
3. Insert 2 new AAA alkaline batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.
5. Adjust the ringing duration (3 or 30 seconds) and alarm volume (loud, low, or mute) using the switches located near the battery compartment.

# Exercise Timer

It is very important to control the time accurately when you are doing exercise. You need a timer to remind you how long you exercise every day.



Image: A step-by-step visual guide demonstrating how to install batteries, set the timer by turning the dial clockwise, and observe the countdown as the colored disk disappears, culminating in the alarm ringing.

## 3. OPERATING INSTRUCTIONS

The Secura Visual Timer is designed for straightforward operation. Follow these steps to set and use your timer:

- Setting the Time:** Turn the central dial clockwise to the desired time duration, up to 60 minutes. As you turn the dial, a colored disk will appear, representing the set time.
- Starting the Countdown:** Once the dial is set, the countdown begins immediately. The colored disk will gradually disappear as time elapses, providing a clear visual indication of remaining time.
- Silent Operation:** The timer operates silently without any loud ticking, making it suitable for quiet environments like classrooms or study areas.
- Alarm Notification:** When the set time expires, the timer will sound an alarm. The duration and volume of this alarm can be adjusted using the switches on the back of the unit.
- Stopping the Alarm:** To turn off the ringing, you can either wait for the set alarm duration to complete (3 or 30 seconds) or manually turn the volume button to 'mute'.
- Resetting the Timer:** To stop an active countdown or reset the timer, simply turn the dial back to the "0" position.

**Important Note:** Do not rotate the dial counter-clockwise beyond the "0" position, as this may cause internal damage to the timer mechanism.




Image: A hand demonstrating how to set the timer by rotating the central dial clockwise. This action reveals the colored disk, indicating the set time duration.

## How Secura Visual Timer Works?

**STEP 1**

Install 2AAA batteries (not included) and select the ring duration and volume.

**STEP 2**

Turn clockwise to the time you want.

**STEP 3**

The countdown begins and the disc gradually disappears.

**STEP 4**

The time is up and the bell rings.

Image: A child focused on studying at a desk with the Secura Visual Timer nearby, illustrating the timer's quiet operation which prevents distractions during concentration tasks.

## 4. MAINTENANCE AND CARE

To ensure the longevity and proper functioning of your Secura Visual Timer, please follow these simple maintenance guidelines:

- **Cleaning:** Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the timer in water.
- **Battery Replacement:** When the timer's performance diminishes or it stops functioning, replace the AAA batteries with new alkaline batteries. Always replace both batteries at the same time.
- **Storage:** Store the timer in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the timer with care. Avoid dropping it or subjecting it to strong impacts, as this can damage the internal mechanism.

## 5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer does not start or operate.	Batteries are dead, incorrectly installed, or not alkaline.	Ensure 2 new AAA alkaline batteries are installed correctly with proper polarity. Do not use rechargeable batteries.
Alarm does not sound or is too quiet.	Volume switch is set to 'mute' or 'low'.	Check the volume switch on the back of the timer and adjust to 'low' or 'loud' as desired.
Colored disk does not appear when setting time.	Dial not turned sufficiently clockwise, or internal mechanism is damaged.	Ensure the dial is turned fully clockwise to the desired time. If the issue persists after checking batteries, contact customer support.
Timer makes a clicking sound.	This model is designed for silent operation.	The Secura Visual Timer is specifically designed to operate without loud ticking. If you hear unusual noises, ensure the timer is on a flat, stable surface and not obstructed.

## 6. SPECIFICATIONS

---

- **Model Number:** VT024-NB-NB
- **Color:** Navy Blue & Navy Blue
- **Brand:** Secura
- **Material:** Plastic
- **Product Dimensions:** 1.97"D x 3.11"W x 3.11"H
- **Item Weight:** 0.24 Pounds (3.84 ounces)
- **Power Source:** 2 x AAA Alkaline Batteries (Not Included)
- **Maximum Time Setting:** 60 Minutes
- **Alarm Duration Options:** 3 seconds, 30 seconds
- **Alarm Volume Levels:** Loud, Low, Mute

## 7. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, product support, or any other inquiries, please contact Secura customer service. You can typically find contact details on the official Secura website or through the retailer where the product was purchased.

For more information about Secura products, visit the official Secura Store on Amazon.

