

SPORTARC VC101

SPORTARC Anko VC101 Handheld Cordless Stick Vacuum Filter Replacement Manual

PRODUCT OVERVIEW

These SPORTARC replacement filters are specifically designed for the Anko VC101 22.2V Handheld Cordless Stick Vacuum. They are essential for maintaining the vacuum's optimal suction power and protecting its motor from damage. Regular replacement and cleaning ensure efficient filtration of dust, smoke particles, and other airborne debris, contributing to a cleaner environment and extending the operational life of your vacuum cleaner.

INSTALLATION INSTRUCTIONS

Follow these steps to replace the filter in your Anko VC101 Handheld Cordless Stick Vacuum:

1. Ensure the vacuum cleaner is turned off and unplugged (if applicable for charging) before proceeding.
2. Locate the filter compartment on your Anko VC101 vacuum. This is typically found near the dustbin.
3. Open the filter compartment or remove the dustbin according to your vacuum's specific design.
4. Carefully remove the old, dirty filter. Dispose of it properly.
5. Insert the new SPORTARC filter into the compartment, ensuring it is seated correctly and securely.
6. Close the filter compartment or reattach the dustbin.
7. Your vacuum is now ready for use with the new filter.



Image: Two new SPORTARC replacement filters for the Anko VC101 vacuum, ready for installation.

FILTER FUNCTION

The filter plays a vital role in your vacuum cleaner's operation. It captures fine dust particles, allergens, and other debris, preventing them from being released back into the air or damaging the vacuum's motor. A clean filter ensures optimal airflow, which is essential for strong suction performance and overall cleaning efficiency.

MAINTENANCE AND CLEANING

To ensure the best performance and longevity of your Anko VC101 vacuum, regular filter maintenance is essential.

Cleaning the Filter

The washable motor filter should be cleaned regularly:

1. Remove the filter from the vacuum cleaner as described in the "Installation Instructions" section.
2. Gently tap the filter over a waste bin to remove loose dust and debris.

3. Wash the foam strainer under running water until the water runs clear. It can also be washed in a washing machine for thorough cleaning.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Do not use the vacuum with a damp filter.

Replacement Schedule

For optimal performance, the foam strainer should be washed every 2 weeks and replaced every 6 months. Adhering to this schedule prevents a decrease in suction power and protects the motor from overheating.



Image: A close-up view of the filter mesh, highlighting its fine structure designed to capture dust particles.

TROUBLESHOOTING COMMON ISSUES

Most performance issues related to vacuum filters can be resolved with proper maintenance.

Reduced Suction Power

If your vacuum's suction power decreases, the filter is likely dirty or clogged.

- Remove and clean the filter according to the "Maintenance and Cleaning" instructions.

- If cleaning does not restore suction, replace the filter with a new one.

Motor Overheating

A dirty or clogged filter can restrict airflow, causing the vacuum motor to work harder and potentially overheat.

- Immediately turn off and unplug the vacuum.
- Allow the motor to cool down.
- Clean or replace the filter before resuming use.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SPORTARC
Compatibility	Anko VC101 22.2V Handheld Cordless Stick Vacuum
Product Dimensions	10 x 10 x 3 cm
Quantity	2 Filters per pack
Washable	Yes



Image: Side view of a SPORTARC filter, showing its compact dimensions.

WARRANTY AND CUSTOMER SUPPORT

Specific warranty information for this product is not provided in the available documentation. For warranty claims, technical support, or further assistance, please contact the manufacturer, SPORTARC, directly through their official website or customer service channels. Always retain your purchase receipt as proof of purchase.