

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MEE audio](#) /

> [MEE Audio goSPKR Wearable Bluetooth Speaker Instruction Manual](#)

MEE audio GOSPKR-CLIP

MEE Audio goSPKR Wearable Bluetooth Speaker Instruction Manual

Model: GOSPKR-CLIP

INTRODUCTION

The MEE Audio goSPKR is a compact, wearable Bluetooth speaker designed for portable audio and hands-free communication. This manual provides essential information for the proper setup, operation, and maintenance of your goSPKR speaker.



Image: MEE Audio goSPKR Wearable Bluetooth Speaker, black color.

WHAT'S IN THE BOX

- MEE Audio goSPKR Wearable Bluetooth Speaker
- Power Cable (USB-C)

PRODUCT OVERVIEW

The goSPKR features a compact design with intuitive controls and a versatile clip for easy attachment.



Integrated Shirt Clip

Attach the goSPKR to almost any article of clothing using the built-in clip

Image: Side view of the MEE Audio goSPKR showing the integrated clip for attachment to clothing or other items.

Controls and Indicators

- **Power Button (O):** Power on/off, Play/Pause, Answer/End calls, Activate voice assistant.
- **Volume Up (+):** Increase volume, Next track (long press).
- **Volume Down (-):** Decrease volume, Previous track (long press).
- **LED Indicator:** Shows power, pairing, and charging status.
- **Microphone:** For hands-free calls and voice assistant.
- **USB-C Charging Port:** For charging the internal battery.





Image: Diagram illustrating the functions of the goSPKR's buttons: single press, double press, triple press, and long press actions for power, play/pause, calls, volume, track control, and voice assistant.

SETUP

Charging the Battery

Before first use, fully charge the goSPKR. Connect the provided USB-C cable to the charging port on the speaker and to a USB power source. The LED indicator will show charging status and turn off when fully charged. A full charge takes approximately 2 hours and provides up to 7 hours of playtime.



Built-in Rechargeable Battery

Enjoy up to 7 hours of uninterrupted playback on a single charge

Image: MEE Audio goSPKR speaker with an icon indicating 7 hours of battery life, highlighting its long-lasting charge.

Bluetooth Pairing

1. Ensure the goSPKR is charged.
2. Press and hold the Power button (O) for 3 seconds to turn on the speaker. The LED indicator will flash to indicate pairing mode.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings and select "MEE audio goSPKR" from the list of available devices.
4. Once connected, the LED indicator will show a solid light, and you will hear an audible confirmation.




Image: A smartphone screen displaying Bluetooth settings, with "MEE audio goSPKR" shown as connected, demonstrating the pairing process.

OPERATING INSTRUCTIONS

Basic Audio Playback

- **Play/Pause:** Press the Power button (O) once.
- **Volume Control:** Press the Volume Up (+) or Volume Down (-) buttons.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.

Hands-Free Calling


The goSPKR features a built-in microphone for hands-free calls.

- **Answer/End Call:** Press the Power button (O) once.
- **Reject Call:** Long press the Power button (O).

Voice Assistant

Access your device's voice assistant (Siri, Google Assistant) directly from the goSPKR.

- **Activate Voice Assistant:** Triple-click the Power button (O).



Built-in Mic and Voice Assistant

Access your phone's Siri / Google Assistant any time
by triple-clicking the main button

Image: Close-up of the MEE Audio goSPKR's control panel with a voice assistant icon, indicating the speaker's capability to activate Siri or Google Assistant.

Stereo Mode Pairing (Two goSPKR's)

For a wider soundstage, two goSPKR units can be paired together for stereo audio.

1. Ensure both goSPKR units are powered on and not connected to any other Bluetooth device.
2. On one goSPKR, double-click the Power button (O) to initiate stereo pairing. The LED indicators on both speakers will flash.
3. Once paired, one speaker will act as the left channel and the other as the right. The LED indicators will show a solid light.
4. Connect your device to the primary goSPKR via Bluetooth as described in the "Bluetooth Pairing" section.



Two is Better than One

Connect two goSPKR speakers together in stereo to enjoy louder, more natural sound with dedicated left and right channels

Image: Two MEE Audio goSPKR speakers shown together, with an icon indicating "Stereo Mode," demonstrating the ability to link two units for enhanced audio.

Wearable Design

The goSPKR features a built-in clip for easy attachment to clothing, bags, or other items, allowing for hands-free listening while maintaining awareness of your surroundings.



Ultra-Portable Bluetooth Speaker

The goSPKR is a pint-sized Bluetooth speaker so light, you'll forget you're wearing it!

Image: A person wearing the MEE Audio goSPKR clipped onto their hoodie, illustrating its lightweight and wearable design for convenient, hands-free use.

Your browser does not support the video tag.

Video: An official MEE audio video showcasing the goSPKR's features, including its compact size, clip-on design, and stereo pairing capabilities.

Your browser does not support the video tag.

Video: An official MEE audio video demonstrating various scenarios where the goSPKR can be used, emphasizing its portability and convenience for daily activities.

MAINTENANCE

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is securely closed to maintain water resistance.

Storage

Store the goSPKR in a cool, dry place away from extreme temperatures and direct sunlight. If storing for an

extended period, charge the battery periodically to maintain its lifespan.

Water Resistance

The goSPKR is IPX5 water resistant, meaning it can withstand splashes and light rain. It is not designed for submersion in water. Always ensure the charging port cover is sealed to prevent water ingress.



IPX5 Water Resistance

Weather-proof design for protection from moisture both indoors and out

Image: MEE Audio goSPKR held in a hand with an IPX5 icon, indicating its weather-resistant design for protection against moisture.

TROUBLESHOOTING

No Power

- Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
- Press and hold the Power button (O) for 3 seconds to turn on.

Cannot Pair via Bluetooth

- Ensure the goSPKR is in pairing mode (flashing LED). If not, turn it off and then on again, holding the power button until the LED flashes.
- Make sure Bluetooth is enabled on your device and it is within 30 feet (10 meters) of the speaker.

- If previously paired, try forgetting the device in your phone's Bluetooth settings and re-pairing.
- Restart both the speaker and your Bluetooth device.

No Sound or Low Volume

- Increase the volume on both the goSPKR and your connected device.
- Ensure the speaker is properly connected to your device via Bluetooth.
- Check if the speaker is muted.

Stereo Mode Not Working

- Ensure both goSPKRs are fully charged and not connected to any other Bluetooth device.
- Follow the stereo pairing instructions carefully, double-clicking the Power button on one speaker to initiate pairing between the two units.
- If issues persist, reset both speakers and attempt stereo pairing again.

SPECIFICATIONS

Feature	Detail
Model Number	GOSPKR-CLIP
Connectivity Technology	Bluetooth 5.3
Wireless Range	Up to 30 feet (10 meters)
Water Resistance	IPX5
Battery Life	Up to 7 hours
Charging Time	Approximately 2 hours
Speaker Output Power	5 Watts
Audio Output Mode	Stereo (when two units are paired)
Built-in Microphone	Yes
Dimensions (D x W x H)	1" x 3" x 4"
Weight	0.24 lbs (3.84 ounces)
Material	Plastic
Included Components	Power Cable

WARRANTY

The MEE Audio goSPKR is covered by a 1-year manufacturer warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For additional support, troubleshooting, or warranty inquiries, please visit the official MEE Audio website or contact their customer service department. You may find FAQs, product registration, and contact information on their support pages.

Official MEE Audio Website: www.meeaudio.com