



[Manuals.plus](#) /

> [MAHANCRIIS](#) /

> MAHANCRIIS TV Stand with Power Outlets, Model TVHR131E01 Instruction Manual

MAHANCRIIS TVHR131E01

MAHANCRIIS TV Stand with Power Outlets, Model TVHR131E01 Instruction Manual

Model: TVHR131E01

INTRODUCTION

Thank you for choosing the MAHANCRIIS TV Stand with Power Outlets, Model TVHR131E01. This entertainment center is designed to accommodate TVs up to 55 inches and features 3-tier storage shelves, a durable metal frame, and a rustic brown finish. It also includes a convenient power strip with two standard outlets and two USB Type-A ports. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your product.



Figure 1: Assembled MAHANCRIS TV Stand with Power Outlets (Model TVHR131E01).

This image shows the MAHANCRIS TV Stand fully assembled, featuring a rustic brown top surface, black metal frame, and mesh shelves. A television is placed on top, and various media devices, books, and decorative items are arranged on the shelves. A power cord extends from the integrated power strip on the top surface.

SAFETY INFORMATION

Please read and understand all safety information before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- Ensure proper installation and usage to prevent tip-over risks.
- Keep children away from power sources and small parts during assembly and use.
- Always follow the assembly instructions carefully.
- Do not exceed the maximum weight capacities for each shelf. The top surface supports up to 150 lb, and each mesh shelf supports up to 50 lb.
- Place the TV stand on a level and stable surface to prevent wobbling.
- Avoid placing hot items directly on the surface without protection.
- Do not modify the product or use it for purposes other than its intended use.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Panel (Rustic Brown)
- Metal Frame Components
- Mesh Shelves (2 units)
- Integrated Power Strip (with 2 AC outlets and 2 USB-A ports)
- Adjustable Feet
- Assembly Hardware (screws, bolts, twist-locks, etc.)
- Assembly Tool (e.g., Allen wrench)
- Instruction Manual



Figure 2: Components of the MAHANCRIS TV Stand prior to assembly.

This image displays the disassembled components of the TV stand, including the rustic brown top panel, black metal support bars, and two black mesh shelves, along with the integrated power strip and its cord. This view helps in identifying all parts before starting assembly.

ASSEMBLY INSTRUCTIONS

Assembly of the MAHANCRIS TV Stand is designed to be straightforward with its twist-lock installation system. Each component is numbered, and detailed illustrations are provided in the included assembly guide. Please follow the steps below carefully.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list to ensure everything is present.
2. **Assemble the Base Frame:** Connect the lower metal frame components using the provided hardware and twist-lock mechanisms. Ensure all connections are secure.
3. **Install Lower Mesh Shelf:** Place the larger mesh shelf onto the assembled lower frame.
4. **Attach Vertical Supports:** Secure the vertical metal support bars to the base frame.

5. **Install Upper Mesh Shelf:** Position and secure the smaller mesh shelf onto the designated vertical supports.
6. **Attach Top Panel:** Carefully place the rustic brown top panel onto the upper frame and secure it using the remaining hardware. Ensure the integrated power strip is positioned correctly.
7. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the stand's legs. Adjust them as needed to ensure stability and protect your floor.
8. **Connect Power Strip:** Plug the power strip's cord into a wall outlet.




Figure 3: Dimensions and Load Capacities.

This diagram illustrates the overall dimensions of the TV stand (47.2" L x 11.8" W x 19.7" H) and the recommended maximum TV size (up to 55 inches). It also clearly indicates the weight capacities: 150 lbs for the top surface and 50 lbs for each mesh shelf. This information is crucial for safe assembly and usage.

OPERATING INSTRUCTIONS

The MAHANCRIS TV Stand is designed for convenient media organization and power access.

Media Charging Hub

The integrated power strip provides two standard AC outlets and two USB Type-A ports. This allows you to power your television, gaming consoles, DVD players, soundbars, and charge mobile devices directly from the stand, reducing cable clutter.

Media Power Hub

Convenient charging for consoles, DVDs, etc.




Figure 4: Media Power Hub in use.

This image provides a close-up view of the power strip embedded in the top surface of the TV stand. It shows two standard electrical outlets and two USB-A ports. A smartphone is depicted charging via one of the USB ports, highlighting the convenience of the integrated charging hub.

Storage and Ventilation

The 3-tier design offers ample space for various media components. The mesh shelves are specifically designed to promote air circulation, aiding in heat dissipation for electronic devices such as receivers, gaming consoles, and media players, which helps maintain optimal performance and longevity.



Figure 5: Ventilated Mesh Shelves.

This image shows a detailed view of the mesh design of the shelves. The open grid pattern is intended to allow air to flow freely around electronic devices, preventing overheating and ensuring proper ventilation for optimal device performance.

MAINTENANCE

To ensure the longevity and appearance of your MAHANCRIS TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** The rustic brown top surface is designed to be wipe-clean. Use a soft, damp cloth to remove dust and spills. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining, especially on the wooden surfaces.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Adjustable Feet:** Ensure the adjustable feet are properly leveled to prevent wobbling and protect your flooring.



Wipe-Clean Surface

Smooth finish for effortless cleaning.

Figure 6: Wipe-Clean Surface.

This image demonstrates the wipe-clean nature of the TV stand's rustic brown surface. A hand is shown wiping away water droplets with a white cloth, illustrating the ease of cleaning and maintenance for the product.

TROUBLESHOOTING

If you encounter any issues with your MAHANCRIS TV Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stand is wobbly or uneven.	Uneven floor surface; adjustable feet not properly set; loose connections.	Adjust the leveling feet on the bottom of the stand until it is stable. Ensure all assembly screws and twist-locks are tightened securely.

Problem	Possible Cause	Solution
Power outlets or USB ports are not working.	Power cord not plugged in; wall outlet not functioning; internal wiring issue.	Ensure the power cord is fully plugged into a live wall outlet. Test the wall outlet with another device. If the issue persists, contact customer support.
Missing or damaged parts during assembly.	Packaging error; shipping damage.	Do not proceed with assembly. Contact MAHANCRIS customer support immediately with your purchase details and a description of the missing/damaged parts.
Difficulty with assembly.	Instructions unclear; parts misaligned.	Review the assembly instructions carefully, paying close attention to illustrations. Ensure parts are oriented correctly. If issues persist, seek assistance or contact customer support.

SPECIFICATIONS

- **Model:** TVHR131E01
- **Dimensions (L x W x H):** 47.2 x 11.8 x 19.7 inches
- **Material:** Engineered Wood, Metal
- **Color:** Rustic Brown + Black
- **Weight Capacity (Top Surface):** 150 lb
- **Weight Capacity (Each Mesh Shelf):** 50 lb
- **Compatible TV Size:** Up to 55 inches
- **Power Outlets:** 2 Standard AC Outlets, 2 USB Type-A Ports
- **Item Weight:** Approximately 16.7 pounds
- **Manufacturer:** MAHANCRIS

WARRANTY AND SUPPORT

MAHANCRIS is committed to providing quality products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official MAHANCRIS website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our customer support team:

- **Customer Service:** Refer to your purchase documentation for contact information.
- **Online Support:** Visit the [MAHANCRIS Store on Amazon](#) for product information and support resources.