COLUSI M600

COLUSI M600 Wireless Gaming Headset

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the COLUSI M600 Wireless Gaming Headset. This manual provides detailed instructions to help you set up, operate, and maintain your headset for an optimal gaming and audio experience. The M600 offers versatile connectivity options including 2.4GHz wireless, Bluetooth 5.3, and wired 3.5mm connections, ensuring compatibility with a wide range of devices such as PS5, PS4, PC, Laptops, Macs, and mobile phones.



Image: The COLUSI M600 Wireless Gaming Headset, showcasing its sleek black design and included USB wireless dongle.

2. What's in the Box

- 1 x COLUSI M600 Wireless Gaming Headset
- 1 x User Manual
- 1 x Charging Cable (Type-C)
- 1 x Type-C to 3.5mm Adaptor Cable

3. Key Features

- **Extended Playtime:** Enjoy over 48 hours of continuous use on a single full charge, ensuring long gaming sessions without interruption. A full charge takes approximately 3 hours.



Image: The COLUSI M600 headset positioned next to a PlayStation 5 console, illustrating its impressive 48-hour battery life and 1200mAh battery capacity.

- **Triple Connectivity Modes:** Seamlessly switch between 2.4GHz USB wireless, Bluetooth 5.3, and wired 3.5mm connections for ultimate versatility across various platforms.



Image: A visual guide demonstrating the headset's compatibility with various devices through USB (PC, Laptop, PS5, PS4), Bluetooth (Phone, Tablet, Switch), and 3.5mm jack (controllers).

- **Foldable & Comfortable Design:** Designed for portability and extended wear, featuring a pressure-relieving headband and breathable ear pads.



Image: A detailed view of the headset emphasizing its foldable structure, soft and breathable earcups, and overall lightweight design for comfort and portability.

- **Embeddable Microphone:** The microphone can be conveniently tucked into a groove on the headset when not in use, preventing obstruction.



Image: A close-up of the headset's microphone, demonstrating its ability to be embedded flush with the earcup when not in active use.

- **50mm Drivers:** Equipped with 50mm drivers for clear sound quality, allowing you to distinctly hear in-game audio cues like footsteps and gunshots.



Image: An exploded view diagram of the headset's 50mm audio driver, highlighting its components and role in delivering high-quality sound.

4. Setup Guide

4.1. 2.4GHz Wireless Mode (for PC, PS5/PS4, Mac, Laptop)

1. Plug the 2.4GHz USB adapter into an available USB port on your device (PC, PS5/PS4 console, Mac, or Laptop).
2. Turn on the M600 Gaming Headset by pressing and holding the Power button for 3 seconds.
3. The headset should automatically connect and emit a “connected” sound. If not, press and hold the “M” button on the headset for 3 seconds to switch to Adapter Mode. The headset will then connect automatically.

Video: Demonstrates how to use the headset in Adapter Mode (2.4GHz Wireless) for seamless connection to compatible devices.

4.2. Bluetooth 5.3 Mode (for iPads, Smartphones, Laptops, Macs)

1. Press and hold the “M” button on the headset for three seconds until you hear the “Bluetooth Mode” sound. This indicates the headset has switched to Bluetooth pairing mode.

2. On your Bluetooth-enabled device, turn on Bluetooth and search for available devices.
3. Select “M600” from the list of found devices to initiate pairing. You will hear a “connected” sound upon successful pairing.

4.3. Wired Mode (for PS5/PS4/Xbox Game Controllers)

1. Ensure the headset is powered off. When the headset is connected via the 3.5mm cable, it will automatically power off. This is normal behavior as wired mode does not require power.
2. Connect the Type-C end of the provided adaptor cable to the Type-C port on the headset.
3. Connect the 3.5mm end of the adaptor cable to the 3.5mm jack on your PS5/PS4/Xbox game controller.
4. **Note:** For older Xbox versions, a Microsoft adapter may be required (not supplied).
5. In wired mode, the microphone is active by default. To turn off the microphone, you must adjust the “Turn off microphone” setting directly on the system of the connected device.

Video: Provides a step-by-step guide on how to use the COLUSI M600 headset in wired mode with various devices.

5. Operating Instructions

5.1. Controls Overview



Image: A detailed diagram illustrating the various buttons and ports on the COLUSI M600 headset, including power, volume, mode switching, microphone mute, and charging port.

- **Power On/Off:** Press and hold the Power button for 3 seconds.
- **Play/Pause:** Single click the Power button.
- **Volume Adjustment:** Use the rolling adjustment wheel for Volume +/-.
- **2.4GHz Wireless Mode:** Press and hold the 'M' button for 3 seconds.
- **Bluetooth Mode:** Press and hold the 'M' button for 3 seconds.
- **Mic Mute/Off:** Double-click the dedicated Mic button.
- **Light On/Off:** Single click the Light button.

Video: A comprehensive introduction to all the buttons and controls on the M600 Wireless Gaming Headset.

5.2. Microphone Usage

The M600 features a 360° omni-directional microphone with 97% noise reduction for clear communication. This noise reduction applies only to the microphone, not the headset's audio output.

When using the headset in wired mode, the microphone is automatically on. To turn it off, you must adjust the microphone settings directly within the operating system or application of your connected device.

6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the headset. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in constant use.
- **Cable Care:** Handle cables gently. Avoid sharp bends or excessive pulling to prevent damage.

7. Troubleshooting

Problem	Solution
Headset not powering on/connecting wirelessly.	Ensure the headset is charged. For 2.4GHz, ensure the USB adapter is correctly plugged in and try pressing the 'M' button for 3 seconds to switch modes. For Bluetooth, ensure Bluetooth is enabled on your device and the headset is in pairing mode.
Microphone not working in wired mode.	In wired mode, the microphone is controlled by the connected device's settings. Navigate to your device's audio input settings and ensure the microphone is enabled and not muted.
No sound or low volume.	Check the volume wheel on the headset and the volume settings on your connected device. Ensure the correct audio output device is selected on your computer or console.
Headset automatically turns off when connected via 3.5mm cable.	This is normal. The headset is designed to operate in passive (off) mode when using the wired connection. All controls (including microphone mute) must be managed via the connected device.
Wireless connection not supported on Xbox Series.	The M600 wireless gaming headphones only support wired connection to Xbox One/Xbox Series S/X controllers. Wireless connection is NOT supported on any Xbox series consoles.

8. Specifications

Feature	Detail
Model Name	M600
Brand	COLUSI
Connectivity Technology	Wireless, Wired
Wireless Communication Technology	Bluetooth, 2.4GHz USB Dongle
Bluetooth Version	5.3
Bluetooth Range	15 Meters

Feature	Detail
Battery Life	48 Hours
Charging Time	3 Hours
Audio Driver Size	50 Millimeters
Audio Latency	20 Milliseconds
Noise Control	Sound Isolation
Headphones Jack	Type-C (for wired adapter)
Item Weight	8.82 Ounces
Product Dimensions	5 x 3 x 6 inches
Material	Plastic
Color	Black
Ear Placement	Over Ear
Form Factor	Over Ear
Impedance	32 Ohm

9. Warranty and Support

COLUSI products are manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official COLUSI website.

© 2025 COLUSI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question