

[manuals.plus](#) /

› [LEADZM](#) /

› [LEADZM Electric Massage and Heated Recliner Chair User Manual](#)

LEADZM G52003395

LEADZM Electric Massage and Heated Recliner Chair User Manual

Model: G52003395

1. INTRODUCTION

Thank you for choosing the LEADZM Electric Massage and Heated Recliner Chair. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new recliner. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Ensure all components are securely assembled before initial use.
- Do not exceed the maximum weight capacity of 120 kg (265 lbs).
- Keep children and pets away from the chair's moving parts, especially during recline operation.
- Unplug the chair from the power outlet before cleaning, maintenance, or if it will be unused for an extended period.
- Do not expose the chair to excessive moisture, direct sunlight, or extreme temperatures.
- If any part is damaged, missing, or appears to be malfunctioning, discontinue use immediately and contact customer support.
- The backrest recline is manually operated; it is **not motorized**. Do not attempt to force the recline mechanism with the remote control.
- The remote control is solely for massage and heating functions, not for adjusting the chair's position.

3. PACKAGE CONTENTS

Please verify that all parts are present and undamaged before beginning assembly. The package should contain:

- 1 x LEADZM Electric Massage and Heated Recliner Chair (main body)
- 1 x Wired Remote Control

- Power Adapter
- Assembly Hardware (if applicable, typically pre-attached or minimal)



Image: Overview of the recliner chair with its remote control, illustrating the massage and heat points.

4. SETUP AND ASSEMBLY

The LEADZM recliner chair is designed for straightforward assembly. Follow these general steps:

1. Carefully unpack all components from the shipping box and lay them out on a clean, soft surface to prevent scratches.
2. Connect the backrest to the seat base. Ensure the metal brackets align and slide securely into place until you hear a click or feel it lock.
3. Connect any internal wiring for the massage and heating functions. These connections are typically color-coded or clearly labeled.
4. Attach the chair legs to the base, ensuring they are tightened securely.
5. Plug the power adapter into the chair's power input port, then plug the adapter into a standard wall outlet.
6. Place the remote control in the integrated side storage pocket for convenient access.



Image: A view of the chair's internal wiring, typically accessed during the assembly process to connect the massage and heating elements.

5. OPERATING INSTRUCTIONS

5.1 Reclining Function

The recliner features a manual recline mechanism. To recline, simply lean back with your body weight. The backrest will smoothly recline up to 135 degrees, and the footrest will extend simultaneously. To return to the upright position, lean forward and gently push the backrest back into its original position.



Die Neigung der Rückenlehne ist nicht motorisiert



Image: An illustration clarifying that the backrest recline is manual and not controlled by the remote.



Image: Visual guide demonstrating the chair's adjustable recline positions (90° , 105° , 135°) suitable for reading, watching television, or napping.

5.2 Massage and Heating Functions

The massage and heating functions are controlled via the wired remote control. Ensure the chair is plugged into a power outlet before use.



Image: Detailed diagram of the remote control, highlighting its various buttons for controlling massage modes, intensity, heat, and specific massage areas.

The chair offers:

- **6 Vibrating Massage Points:** Strategically located with 4 points in the backrest and 2 points in the seat.
- **5 Massage Modes:** Choose from various massage patterns to suit your preference.
- **2 Vibration Intensities:** Adjust the strength of the massage (indicated as Low/Mid/High on the remote).
- **1 Lumbar Heating Function:** Provides soothing warmth to the lower back area.

Refer to the table below for specific remote control functions:

Remote Control Functions

Button/Feature	Description
ON/OFF	Powers the massage and heating functions on or off.
MODE	Cycles through the 5 different massage modes.
INTENSITY	Adjusts between the 2 vibration intensities.
HEAT	Activates or deactivates the lumbar heating function.
SHOULDER / BACK / SEAT	Selects specific massage areas to target.

Vibrationsmassage und Wärmefunktion



6 vibrierende Massagepunkte



5 Massagemodi



2 Vibrationsintensitäten



1 Lendenwirbel-Heizfunktion

Image: Visual representation of the six vibrating massage points and the lumbar heating area on the recliner chair.

6. MAINTENANCE

Proper maintenance will extend the life and performance of your recliner chair:

- **Cleaning:** For general cleaning, wipe the chair's fabric surface with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or excessive water, as these can damage the upholstery.
- **Spills:** In case of spills, immediately blot the affected area with a clean, dry cloth. Do not rub, as this can spread the stain.
- **Mechanism Check:** Periodically inspect the reclining mechanism and all visible hardware for any loose screws or components. Tighten them if necessary to ensure smooth operation.
- **Electrical Components:** Regularly check the power cord and remote control for any signs of damage, fraying, or loose connections. If any damage is found, discontinue use and contact customer support immediately.
- **Placement:** Avoid placing the chair in direct sunlight for prolonged periods, as this can cause the fabric to fade. Keep it away from direct heat sources like radiators or fireplaces.

7. TROUBLESHOOTING

If you encounter any issues with your recliner chair, please refer to the following table for common problems and their solutions:

Common Issues and Solutions

Problem	Possible Cause	Solution
Massage/Heat functions not working	Chair not plugged in; power outlet issue; loose internal connection; remote control malfunction.	Ensure the power cord is securely plugged into both the chair and a functional wall outlet. Try plugging another device into the outlet to confirm it has power. Check all internal wiring connections made during assembly. If the issue persists, the remote control or internal components may be faulty; contact customer support.
Chair does not recline smoothly or gets stuck	Obstruction in the mechanism; loose assembly hardware; uneven floor.	Check for any objects (e.g., toys, cables) that might be obstructing the reclining mechanism. Ensure all assembly hardware, especially around the base and backrest, is tightened. Verify the chair is on a flat, even surface.
Unusual noises (squeaking, grinding) during operation	Loose components; friction in the reclining mechanism.	Inspect all connections and hardware for tightness. If the noise persists after tightening, it may indicate an issue with the internal mechanism. Contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	LEADZM
Model Number	G52003395
Color	Dark Grey
Product Dimensions (Upright)	74D x 66.5W x 102H cm (approx. 29.1"D x 26.2"W x 39.8"H)
Product Dimensions (Reclined)	Approx. 163 cm (64.2") length when fully reclined
Item Weight	27 kg (approx. 59.5 lbs)
Weight Capacity	Up to 120 kg (265 lbs)
Recline Angle	Max. 135 degrees (manual operation)
Massage Points	6 (4 in backrest, 2 in seat)
Massage Modes	5
Vibration Intensities	2
Heating Function	Lumbar area

Feature	Detail
Frame Material	FSC-certified wood
Additional Features	Integrated storage pocket



Image: Detailed dimensions of the recliner chair in both upright and reclined positions, including its weight capacity.

9. WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your LEADZM Electric Massage and Heated Recliner Chair, please contact LEADZM customer support. We recommend thoroughly checking the product upon receipt for any manufacturing defects or shipping damage.

Contact Information: Please refer to the seller's contact details on your purchase platform or visit the official LEADZM website for the most up-to-date support information and warranty terms.

