

[Manuals.plus](#) /

› [ELEMARA](#) /

› ELEMARA 24V 9AH Ride on Tractor Instruction Manual

ELEMARA BDM-0925

ELEMARA 24V 9AH Ride on Tractor User Manual

Model: BDM-0925 | Brand: ELEMARA

1. SAFETY INFORMATION

Please read all safety warnings and instructions carefully before operating the product. Failure to follow these instructions may result in serious injury.

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 37 months. The product contains small parts; keep children away when assembling.

- Always supervise children during operation.
- Ensure the 3-point seat belt is securely fastened before use.
- Operate the tractor on level surfaces free from obstacles.
- Do not exceed the maximum weight capacity of 88 lbs.
- Recommended age for use is 3 to 8 years.

2. PRODUCT OVERVIEW

The ELEMARA 24V 9AH Ride on Tractor is an electric toy designed for children aged 3 and up, featuring a powerful motor and a detachable trailer for versatile play.



The ELEMARA 24V 9AH Ride on Tractor in green, featuring a child in a straw hat and overalls, demonstrating its use.

24V 9AH
LARGE BATTERY



200W * 2
STRONG MOTOR



2.5-4.5 MPH
SPEED



100-180 min
USING TIME:

400W

7-DEGREE SLOPES



Detailed specifications of the tractor's power, including its 24V 9AH large battery, 400W motors (200W*2), speed range of 2.5-4.5 MPH, and a usage time of 100-180 minutes.



The 2-in-1 design of the ride-on tractor, highlighting its easy-to-install and detachable trailer for versatile play scenarios.




The tractor's all-terrain capability, suitable for various road surfaces including asphalt, brick, grass, and muddy roads.

SAFE AND COMFORTABLE FOR KIDS



88 LBS

Load Capacity:



3+ YEARS

Recommended for Age:



Safety and comfort features for kids, including an 88 lbs load capacity, recommended age of 3+ years, and a soft start mechanism for smooth acceleration.



Entertainment features of the tractor, such as built-in music, Bluetooth connectivity, FM radio, and a simple one-button starting mechanism.

3. ASSEMBLY AND SETUP

The ELEMARA Ride on Tractor comes with a detailed manual for assembly. Please refer to the included 'Manual*1' for step-by-step instructions.

- **Unpacking:** Carefully remove all components from the packaging. Verify all parts listed in the manual are present.
- **Battery Connection:** Connect the battery as instructed in the manual. Ensure a full charge before first use (refer to charging section).
- **Trailer Assembly:** The trailer is designed for easy installation and disassembly with a one-click mechanism. Align the trailer hitch with the tractor's connection point and secure it.
- **Steering Wheel Installation:** Attach the steering wheel securely. Some models may require a screw, which should be included.
- **Initial Charge:** Fully charge the battery before the first ride to ensure optimal performance and battery

longevity.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the controls before operating the tractor.

- **Starting the Tractor:** Press the 'One starting' button to power on the tractor.
- **Speed Control:** The tractor features two speeds: 2.5 mph and 4.5 mph. Select the appropriate speed using the speed selector switch.
- **Acceleration:** Press the gas pedal to move forward. The soft start feature ensures a smooth acceleration, preventing sudden jerks.
- **Steering:** Use the steering wheel to control the direction of the tractor.
- **Braking:** Release the gas pedal to engage the brake.
- **Music and Bluetooth:** The tractor is equipped with built-in music, Bluetooth connectivity, and FM radio. Use the control panel to manage audio playback.
- **Trailer Use:** The detachable trailer can be used to transport light items such as toys, leaves, or sand. Do not exceed the trailer's maximum load capacity (approximately 11 lbs).

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your ELEMARA Ride on Tractor.

- **Battery Care:** Charge the battery regularly, even when not in use, to maintain its health. Avoid completely draining the battery.
- **Cleaning:** Wipe down the tractor with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the tractor in a dry, covered area to protect it from weather elements.
- **Inspection:** Periodically check all screws, connections, and moving parts for tightness and wear.
- **Replaceable Parts:** Should any part require replacement, refer to the diagram below for common replaceable components. Contact customer support for assistance with obtaining genuine replacement parts.



Common replaceable parts for the ELEMARA Ride on Tractor. For detailed part numbers and ordering, consult the full manual.

6. TROUBLESHOOTING

If you encounter issues with your tractor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Tractor does not move or turn on.	Low battery, loose battery connection, faulty switch.	Charge the battery fully. Check battery terminals for secure connection. Inspect power switch for damage.
Trailer detaches easily or breaks.	Overload, improper attachment, damaged hitch.	Ensure trailer is securely attached. Do not exceed 11 lbs load capacity. Inspect hitch for damage and replace if necessary.
Hood pops off easily.	Loose clips or improper seating.	Ensure the hood is properly aligned and all clips are securely fastened.
Reduced speed or short battery life.	Undercharged battery, old battery, operating on difficult terrain.	Ensure battery is fully charged. Consider replacing the battery if it's old. Operate on smoother surfaces for longer duration.

If the problem persists after attempting these solutions, please contact ELEMARA customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	61 x 26.2 x 24.4 inches
Item Weight	38 pounds
Model Number	BDM-0925
Manufacturer Recommended Age	3 - 8 years
Battery	24V 9AH
Motors	400W (2 x 200W)
Speed Range	2.5 - 4.5 mph
Max Load Capacity	88 lbs
Usage Time	Up to 180 minutes (at 2.5 mph)
Features	Detachable Trailer, 3-Point Seat Belt, Soft Start, Bluetooth, Music, FM Radio

8. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your ELEMARA 24V 9AH Ride on Tractor, please contact ELEMARA customer service. While specific warranty details are not provided in this manual, ELEMARA is committed to customer satisfaction and product support.

You can find more information and contact details by visiting the official ELEMARA store:

[Visit the ELEMARA Store on Amazon](#)

