

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Yaber PROJECTOR](#) /
- › [Yaber PROJECTOR T2 HDMI Adapter User Manual](#)

Yaber PROJECTOR T2 HDMI Adapter

Yaber PROJECTOR T2 HDMI Adapter User Manual

Model: T2 HDMI Adapter

Brand: Yaber PROJECTOR

1. INTRODUCTION

Welcome to the user manual for your Yaber PROJECTOR T2 HDMI Adapter. This document provides comprehensive instructions to help you set up, operate, maintain, and troubleshoot your device. Please read this manual carefully to ensure proper use and to maximize your viewing experience.

2. PRODUCT OVERVIEW

The Yaber PROJECTOR T2 HDMI Adapter is designed to enhance your viewing experience by providing access to a wide range of streaming services and smart features. This compact device connects to your projector or display via HDMI, transforming it into a smart entertainment hub. It supports Wi-Fi 6, 4K resolution, HDR 10, and Dolby Audio, integrating Google TV, Chromecast, and Google Assistant for a user-friendly interface.



Image of the Yaber PROJECTOR T2 HDMI Adapter and its accompanying remote control. The adapter is a compact, cream-colored stick, and the remote is black with various control buttons and dedicated streaming service buttons.

3. PACKAGE CONTENTS

Upon opening the package, verify that you have received the following items:

- Yaber PROJECTOR T2 HDMI Adapter
- Remote Control

4. SETUP GUIDE

4.1. Connect the Adapter

1. Insert the T2 HDMI Adapter into an available HDMI port on your projector or display.
2. The adapter is HDMI-powered. Ensure your projector provides sufficient power through the HDMI port. If using with a Yaber T2 Projector, the adapter is designed to integrate seamlessly and save a USB port.



Image showing the T2 HDMI Adapter connected to a Yaber T2 Projector. The adapter is plugged into an HDMI port, and a small, separate power adapter is shown with text indicating 'Only for T2', emphasizing the HDMI-powered feature and saving a USB port.

4.2. Power On and Initial Setup

1. Power on your projector or display and select the corresponding HDMI input.
2. Follow the on-screen prompts to complete the initial setup, which includes connecting to your Wi-Fi network and logging into your Google account. **Note:** A Google account is required to access many features and download applications.




Diagram illustrating the easy setup process: 1) Power connection (power cord not included), 2) Plug the 4K TV Dongle to your device, and 3) Connect to Internet and enjoy. This visual guide simplifies the initial setup steps.

4.3. Pair the Remote Control

If the remote control is not automatically paired, follow the on-screen instructions or refer to the remote control's specific pairing guide. Ensure batteries are inserted correctly.

5. OPERATING INSTRUCTIONS

5.1. Navigating Google TV

The adapter features a user-friendly Google TV interface. Use the remote control's directional pad to navigate through menus and select options.

User-Friendly Interface

Entertainment with 7000+ APPS & 100,000+ Movies




Screenshot of the Google TV user interface displayed on a screen, showing various streaming app icons and content recommendations. This illustrates the user-friendly interface provided by the T2 HDMI Adapter.

5.2. Accessing Streaming Services

Dedicated buttons on the remote provide one-click access to popular streaming services such as Netflix, Disney+, YouTube, and Prime Video.

One-click Access To Streaming Services



Close-up image of the remote control highlighting the dedicated one-click access buttons for Netflix, Disney+, YouTube, and Prime Video. This demonstrates the ease of accessing popular streaming services.

5.3. Using Chromecast and Google Assistant

The adapter supports Chromecast, allowing you to cast content from compatible mobile devices directly to your display. Use the built-in Google Assistant for voice commands to search for content, control playback, and more.

6. MAINTENANCE

6.1. Cleaning

Gently wipe the adapter and remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.

6.2. Software Updates

Ensure your adapter's software is up to date for optimal performance and security. Updates are typically managed through the Google TV settings menu. Regularly checking for and installing updates is recommended.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your T2 HDMI Adapter.

7.1. No Power / No Signal

- Ensure the adapter is fully inserted into the HDMI port.
- Verify the projector or display is set to the correct HDMI input.
- Check if the adapter is receiving sufficient power from the HDMI port.

7.2. Wi-Fi Connection Issues

- If the adapter struggles to connect to Wi-Fi or reports 'No Internet' despite being connected, try restarting the adapter and your Wi-Fi router.
- Ensure the adapter is within range of your Wi-Fi signal.
- For persistent issues, check for available software updates in the settings.

7.3. Remote Control Unresponsive

- Check the remote control batteries and replace them if necessary.
- Ensure there are no obstructions between the remote and the adapter.
- Re-pair the remote if the issue persists by following the on-screen instructions.

7.4. Google Account Login Problems

- Verify your Google account credentials.
- If you encounter issues, try logging in on another device to confirm account access.
- A stable internet connection is required for login.

7.5. Slow Interface / Delayed Responses

- Ensure the adapter has the latest software updates.
- Restarting the device can often resolve temporary performance issues.

8. SPECIFICATIONS

Feature	Specification
Brand Name	Yaber PROJECTOR
Item Model Number	T2 HDMI Adapter
Item Weight	5 ounces (0.14 Kilograms)
Product Dimensions	5.91 x 1.18 x 3.94 inches
Color	Cream + Black
Special Features	Universal
Connectivity Technology	Bluetooth, Wi-Fi (Wi-Fi 6)
Connector Type	HDMI
Resolution	1080p (Supports 4K)
Controller Type	Touch Control (on remote)

Form Factor	TV Stick
Date First Available	August 1, 2024

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact Yaber PROJECTOR customer support directly. For technical assistance, troubleshooting beyond this manual, or further inquiries, please visit the official Yaber PROJECTOR website or contact their customer service department. Keep your purchase receipt for warranty claims.