Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALMAKRAM SP16 TWS

ALMAKRAM SP16 TWS Professional Bluetooth Earbuds User Manual

Model: SP16 TWS

Introduction

Thank you for choosing the ALMAKRAM SP16 TWS Professional Bluetooth Earbuds. This manual provides essential information for setting up, operating, and maintaining your new earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.
These SP16 TWS Bluetooth sports earbuds are designed for active lifestyles, featuring a secure ear hook design that stays comfortably in place during workouts or outdoor activities. With IPX4 water resistance, you can wear them without worry during intense sweating or light rain. Enjoy crystal-clear Hi-Fi stereo sound and seamless connectivity with your smartphone or other Bluetooth-enabled devices. The compact and lightweight design ensures all-day comfort, while intuitive touch controls allow you to easily manage audio playback and calls. Whether you're at the gym, running, or simply enjoying your favorite tunes, these versatile earbuds provide an immersive audio experience on the go.

What's in the Box

- ALMAKRAM SP16 TWS Wireless Earbuds (Left & Right)
- Wireless Charging Case with LED Display
- USB Charging Cable
- Multi-size Ear Tips
- User Manual
- Warranty Card

Product Overview

The ALMAKRAM SP16 TWS earbuds feature an ergonomic design for comfortable wear and secure fit. The charging case includes an LED display to show battery status.



Image: ALMAKRAM SP16 TWS Earbuds and Charging Case. This image displays the earbuds with their charging case, highlighting their sleek design and the LED battery indicator on the case.

Key Features:

- **Wireless Freedom:** Enjoy music and calls without tangled wires.
- **Secure Fit:** Ear hook design ensures stability during intense activities.
- **Water Resistant (IPX4):** Withstands sweat and light rain.
- **Hi-Fi Stereo Sound:** Rich and immersive audio experience.
- **Long Battery Life:** Extended usage time for earbuds and charging case.
- **Automatic Pairing:** Instant connection to your device.
- **Compact and Portable:** Pocket-sized charging case for easy transport.
- **Built-in Microphone:** For clear, hands-free calls.

- **Touch Control:** Intuitive control of playback, calls, and voice assistants.

Setup

1. Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and to a power source (e.g., USB wall adapter, computer USB port).
3. The LED display on the charging case will indicate the charging status. A full charge is indicated when the display shows 100%.
4. Earbud battery charge time: Approximately 30 minutes.
5. Carrying case battery charge time: Approximately 60 minutes.



Image: ALMAKRAM SP16 TWS Charging Case with LED Display. This image illustrates the charging case with its lid open, showing the earbuds inside and the digital LED display indicating battery percentage.

2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and turn on Bluetooth.
4. Search for available devices and select "SP16 TWS" from the list.
5. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.



Image: ALMAKRAM SP16 TWS Automatic Connection. This image shows the earbuds in their charging case next to a smartphone, illustrating the automatic connection feature upon opening the case.

Note: After the first successful pairing, the earbuds will automatically connect to the last paired device when removed from the charging case, provided Bluetooth is enabled on your device.

Operating Instructions

Wearing the Earbuds

The SP16 TWS earbuds feature an ear hook design for a secure and comfortable fit. Gently place the earbud into your ear canal and adjust the ear hook over your ear until it feels stable.



Image: ALMAKRAM SP16 TWS Ergonomic Design. This image highlights the ergonomic ear hook design of the earbuds, showing how they fit securely around the ear for comfort during activity.

Touch Controls

The earbuds are equipped with intuitive touch-sensitive surfaces for easy control.



Image: ALMAKRAM SP16 TWS Touch Control. This image visually represents the touch control area on the earbuds, indicating where users can tap to manage functions.

Touch Control Functions

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track
Triple Tap (Left Earbud)	Volume Down
Triple Tap (Right Earbud)	Volume Up
Long Press (2 seconds)	Reject Call, Activate Voice Assistant

Using Single or Dual Earbuds

The SP16 TWS earbuds support dual host dual channel design, allowing you to use either earbud independently or both together.



Image: ALMAKRAM SP16 TWS Dual Host Dual Channel. This image illustrates the flexibility of using one or both earbuds, showcasing the independent functionality of each earbud.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical sprays.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

Troubleshooting

Common Issues and Solutions

Problem	Solution
Earbuds not turning on	Ensure earbuds and charging case are fully charged. Place earbuds in case and close lid, then open again.
Earbuds not pairing	Make sure Bluetooth is enabled on your device. Forget "SP16 TWS" from your device's Bluetooth list and try pairing again. Ensure earbuds are in pairing mode (LED indicator blinking).
Only one earbud working	Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out. This should re-sync them. If the issue persists, try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not in manual).
Poor sound quality	Ensure earbuds are clean and properly seated in your ears. Check the audio source device for sound settings. Move closer to your device to avoid interference.
Earbuds falling out	Try different sizes of ear tips to find the most secure fit. Adjust the ear hook for better stability.

Specifications

Technical Specifications

Feature	Detail
Brand	ALMAKRAM
Model Name	SP16 TWS
Model Number	RH00012
Color	Black
Ear Placement	In-Ear
Form Factor	True Wireless
Earbud Shape	Hook
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3

Feature	Detail
Impedance	32 Ohms
Sensitivity	100 dB
Frequency Response	20Hz - 20kHz
Noise Control	Passive Noise Cancellation, Sound Isolation
Audio Driver Type	Dynamic Driver
Water Resistance Level	IPX4 (Water-resistant)
Control Type	Touch Control
Earbud Battery Charge Time	30 minutes
Carrying Case Battery Capacity	350 mAh
Carrying Case Battery Charge Time	60 minutes
Carrying Case Average Battery Life	48 hours
Item Weight	68.2 grams
Carrying Case Dimensions (L x W x H)	94 mm x 69 mm x 35 mm
Carrying Case Weight	60 grams
Materials	ABS Plastic, Polycarbonate (PC), Silicone, Fabric
Compatible Devices	Smartphones, Tablets

Warranty

The ALMAKRAM SP16 TWS Professional Bluetooth Earbuds come with a one-year warranty. This warranty covers manufacturing defects and issues not caused by user misuse or damage. Please retain your proof of purchase for warranty claims.

Support

For further assistance, troubleshooting, or warranty inquiries, please contact ALMAKRAM customer support through the retailer where you purchased the product or refer to the contact information provided on the official ALMAKRAM website or warranty card.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBVX81MV

More documents and user manuals: **https://manuals.plus/**