Irfora LAKUSET00372EU-2

Irfora 21V Cordless Dust Blower & Vacuum User Manual

Model: LAKUSET00372EU-2

Important Safety Instructions

Read all instructions carefully before using the appliance. Failure to follow the instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, such as safety glasses, when operating the blower.
- Do not operate the blower in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating the blower. Distractions can cause you to lose control.
- Ensure the battery is fully charged before use and properly inserted.
- Do not use the blower to inflate high-pressure products like vehicle tires, basketballs, or footballs. This device is not designed for such applications.
- Avoid directing the airflow towards people or animals.
- Store the blower in a dry, secure place out of reach of children.

Package Contents

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.



This image displays the complete package contents of the Irfora 21V Cordless Dust Blower. It includes the main blower unit, a deflation hose, a flexible nozzle, various specialized nozzles, two rechargeable batteries, and a charger.

- 1 x Cordless Blower Unit
- 1 x Deflation Hose

- 1 x Flexible Nozzle
- 6 x Assorted Nozzles (for various applications)
- 2 x 21V 1300mAh Battery Packs (EU Plug & 2 Battery variant)
- 1 x Battery Charger

Product Overview

Familiarize yourself with the components of your Irfora 21V Cordless Dust Blower.



This diagram highlights the key components of the blower: the Brushless Motor, Connector for attachments, LED Light, ON/OFF Switch, Intake vent, Safety Lock Button, and the Rubberized Non-slip Handle.

Brushless Motor: Provides high-speed rotation and powerful airflow.

Connector: Point for attaching various nozzles and hoses.

LED Light: Illuminates the work area, especially useful in dark environments.

ON/OFF Switch: Activates and deactivates the blower.

Intake: Air intake vent for the motor. Keep clear of obstructions.

Safety Lock Button: Prevents accidental activation and allows for continuous operation.

Rubberized Non-slip Handle: Ergonomic design for comfortable and secure grip.

Setup

1. **Charge the Battery:**

   Before first use, fully charge the battery using the provided charger. Insert the battery into the charger and plug the charger into a suitable power outlet. The indicator light on the battery will show charging status.

2. **Install the Battery:**

   Once charged, slide the battery pack into the base of the blower handle until it clicks securely into place.

3. **Attach Nozzle/Hose:**

   Select the appropriate nozzle or the deflation hose for your task. Align the attachment with the connector on the blower and push firmly until it is securely seated. For inflation/deflation, use the flexible nozzle or deflation hose with the relevant adapter.



This image illustrates the variety of nozzles included for different applications, such as pinch valve nozzles for inflatable devices, high-speed nozzles for dusting or inflating, and wide-angle nozzles for broader blowing force. It also includes a crucial caution against using the pump for high-pressure items like tires, basketballs, or footballs.

Operating Instructions

General Operation

1. Ensure the battery is installed and the desired nozzle is attached.
2. Press the ON/OFF switch to activate the blower. The integrated LED light will automatically illuminate when the unit is in operation.
3. For continuous operation, engage the trigger lock function.
4. Direct the airflow or suction towards the area to be cleaned or inflated/deflated.
5. To turn off the unit, release the ON/OFF switch or disengage the trigger lock.

Blower Mode

The blower mode is ideal for dusting electronics, keyboards, car interiors, and other hard-to-reach areas.



This image demonstrates the utility of the integrated LED light, which illuminates the work area, making it easier to clean in dark or poorly lit spaces, such as under car seats or inside computer cases.

Select a suitable nozzle for the task. For example, a narrow nozzle for precise dusting or a wider nozzle for general surface cleaning. The powerful brushless motor provides up to 80000 RPM for effective dust removal.

Vacuum Mode

The vacuum mode is effective for picking up crumbs, small debris, and dust from surfaces like desks, car seats, and sofa corners.

1. Attach the deflation hose to the intake port of the blower.
2. Attach a suitable nozzle to the end of the deflation hose.
3. Activate the blower. The unit will now function as a vacuum, drawing air and debris through the hose into the collection area.

Inflation/Deflation

This device can be used to inflate or deflate items such as swimming rings, yoga balls, and air mats. **Do not use for high-pressure items like vehicle tires, basketballs, or footballs.**

1. For inflation, attach the appropriate nozzle to the blower's output.
2. For deflation, attach the deflation hose to the blower's intake port, and then attach the appropriate nozzle to the end of the hose.
3. Insert the nozzle into the valve of the item to be inflated or deflated.
4. Activate the blower until the desired inflation/deflation level is reached.

Maintenance

- **Cleaning:** Regularly wipe the exterior of the blower with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Nozzle Cleaning:** Clean nozzles and the deflation hose after each use to prevent blockages.
- **Battery Care:** Store batteries in a cool, dry place. Do not expose them to extreme temperatures. Charge batteries fully before long-term storage and recharge every 3-6 months to maintain battery health.
- **Intake Vent:** Ensure the air intake vent remains clear of dust and debris to prevent overheating and maintain optimal performance.
- **Storage:** When not in use, store the blower and its accessories in a clean, dry environment, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Blower does not turn on.	Battery not installed correctly or not charged.	Ensure battery is fully charged and securely inserted.
Weak airflow/suction.	Nozzle or hose blocked; low battery; intake vent obstructed.	Clear any blockages from nozzles/hose. Recharge battery. Clear intake vent.
Blower overheats.	Prolonged use; obstructed intake vent.	Allow the unit to cool down. Ensure intake vent is clear. Avoid continuous long-duration use.
LED light not working.	Unit not powered on; LED malfunction.	Ensure the blower is turned on. If problem persists, contact customer support.

Specifications

Feature	Detail
Model	LAKUSET00372EU-2
Power	1500W
Rotational Speed	0-80000 RPM
Air Volume (Without Nozzle)	0-2.2 m^3/min
Wind Speed (Using Nozzle)	0-300 m/sec

Feature	Detail
Wind Pressure (Using Nozzle)	0-42.7 kPa
Suction Force (Using Air Hose)	16.3 kPa (Maximum Sealing Suction)
Battery Voltage	21V
Battery Capacity	1300mAh
Material	ABS
Product Dimensions	14.96 x 11.02 x 4.33 inches
Color	Red & Black
Country of Origin	China

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Irfora website. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer: Irfora

© 2024 Irfora. All rights reserved.