Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave HJH-GX709AAK-0802

Bellemave Twin Over Full Bunk Bed with Desk and 3 Storage Drawers Instruction Manual

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bellemave Twin Over Full Bunk Bed with Desk and 3 Storage Drawers. Please read all instructions carefully before assembly and use to ensure safe and proper operation of the product. Keep this manual for future reference.

Safety Information

WARNING: Failure to follow these safety instructions may result in serious injury or death.

- **Assembly Warning:** Follow instructions carefully to prevent instability or collapse. Ensure all hardware is securely tightened before use.
- **Weight Capacity Warning:** Do not exceed 250 pounds on the upper bed or 400 pounds on the lower bed.
- **Fall Prevention Warning:** Always use the ladder to access the upper bed. Do not jump on the bunk bed.
- **Caution Around Sharp Edges:** Be careful around the edges of the bed frame to prevent injury during assembly and use.
- **Mattress Thickness:** Upper bed mattress thickness should not exceed 6 inches. Lower bed mattress thickness should be between 8-10 inches.
- **Guard Rails:** The upper bunk is equipped with guard rails. Ensure they are always in place and properly secured.
- **Ventilation:** Ensure adequate ventilation around the bed.

Setup and Assembly

Assembly of this bunk bed is required. It is recommended that two adults perform the assembly. Please ensure all parts are present before beginning. Refer to the included hardware package for specific components.

1. **Unpack Components:** Carefully unpack all parts and hardware from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your separate assembly guide to identify each component.

3. **Assemble Base Frames:** Begin by assembling the base frames for both the twin loft bed and the full platform bed according to the step-by-step instructions provided in the separate assembly guide.
4. **Attach Slats:** Securely attach the wooden slats to both bed frames. Ensure even spacing and firm attachment for mattress support.
5. **Assemble Desk and Drawers:** Construct the integrated desk and 3-drawer storage unit. Ensure drawers slide smoothly and are properly aligned.
6. **Connect Loft Bed and Desk Unit:** Attach the twin loft bed frame to the desk and drawer unit, ensuring all connections are tight and stable.
7. **Attach Ladder:** Securely attach the ladder to the loft bed frame. Verify it is stable and can support weight safely.
8. **Position Full Bed:** Place the full platform bed beneath the loft bed or in a separate configuration as desired.
9. **Final Check:** Double-check all bolts, screws, and connections to ensure they are fully tightened. Do not overtighten.




Image: Detailed dimensions of the assembled bunk bed, including the twin loft, full platform, desk, and drawers. This diagram provides measurements for overall length, width, height, and individual components, crucial for planning placement and assembly.



Image: An overall view of the Bellemave Twin Over Full Bunk Bed with Desk and 3 Storage Drawers, fully assembled in a room. The image shows the white wooden frame, the upper twin bunk, the lower full bed, the integrated desk, and the three storage drawers.

Operating and Usage

The Bellemave Twin Over Full Bunk Bed is designed for versatile use, offering sleeping arrangements and integrated storage/workspace.

- **Upper Twin Loft Bed:** Access the upper bed using the provided ladder. Ensure the ladder is stable before climbing. Always use the guard rails for safety.
- **Lower Full Platform Bed:** The lower bed provides a spacious sleeping area. It can be positioned directly under the loft bed or moved to another location in the room.
- **Integrated Desk:** The built-in desk provides a convenient surface for studying, working, or other activities.
- **Storage Drawers:** Utilize the three integrated drawers for organizing clothes, books, toys, or other personal items. Ensure drawers are closed fully when not in use.
- **Separate Design:** This bunk bed can be separated into two independent beds: a twin loft bed with the desk and drawers, and a standalone full platform bed. To separate, carefully disassemble the connecting hardware as

instructed in the assembly guide, ensuring stability for both units.



Image: A detailed view of the integrated desk and the three pull-out storage drawers. The desk surface is shown clear, and the drawers are partially open, highlighting their storage capacity and design.



Image: This image demonstrates the versatility of the bunk bed, showing it separated into two distinct units: a twin loft bed with the

attached desk and drawers, and a separate full-size platform bed. This illustrates the product's adaptable design.

Maintenance

Regular maintenance will help prolong the life and appearance of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **Wood Care:** The bed is crafted from solid pine wood and MDF. Protect it from excessive moisture and direct sunlight to prevent warping or fading.
- **Drawer Maintenance:** Ensure drawer slides are free of debris for smooth operation.

Troubleshooting

If you encounter issues with your bunk bed, refer to the following common solutions:

- **Bed feels unstable or wobbly:**
  - Ensure all assembly hardware (bolts, screws) are fully tightened.
  - Verify that the bed is placed on a level surface.
  - Check that all structural components are correctly aligned according to the assembly instructions.
- **Drawers do not slide smoothly:**
  - Check for any obstructions in the drawer slides.
  - Ensure the drawer unit was assembled correctly and is level.
  - Lightly lubricate drawer slides with a silicone-based spray if necessary.
- **Squeaking noises:**
  - Tighten all hardware connections.
  - Ensure mattress slats are properly seated and not rubbing against the frame.

Specifications

Feature	Detail
Overall Product Dimension	77"L x 77.5"W x 64"H
Loft Bed Dimension	75.5"L x 38"W
Platform Bed Dimension	75.5"L x 54.3"W
Total Height	64"
Material	Pine Wood + MDF
Color	White
Number of Each Bed Slats	14/14 pcs

Feature	Detail
Upper Bed Weight Capability	250 lb
Down Bed Weight Capability	400 lb
Upper Bed Mattress Thickness	6" (Maximum)
Down Bed Mattress Thickness	8"-10"
Assembly Required	Yes
Model Number	HJH-GX709AAK-0802

Warranty and Support

For any questions, missing parts, or concerns regarding your Bellemave Twin Over Full Bunk Bed, please contact Bellemave customer support. Refer to your purchase documentation for specific warranty details and contact information.

© 2024 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBYYQ1DM

More documents and user manuals: **https://manuals.plus/**