

Fierscial HKWH002-800W-4

Fierscial 800W Electric Convection Panel Wall Heater User Manual

Model: HKWH002-800W-4

Brand: Fierscial

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Placement:** Always place the heater on a firm, level surface. Ensure adequate clearance from walls and other objects to allow for proper air circulation.
- **Power Supply:** Connect the heater directly to a 120 Volts electrical outlet. Do not use extension cords or power strips.
- **Overheat Protection:** The heater is equipped with an automatic overheat protection system. If the heater overheats, it will automatically shut off. Unplug the heater, allow it to cool, and then plug it back in.
- **Tip-Over Protection:** For safety, the heater includes a tip-over switch that automatically turns off the unit if it is accidentally knocked over.
- **Flame Retardant Materials:** Constructed with V0 flame retardant materials to minimize fire risk.
- **Children and Pets:** Keep children and pets away from the heater. The surface can become hot during operation.
- **Moisture:** Do not use the heater in wet or damp locations.

PRODUCT OVERVIEW

The Fierscial 800W Electric Convection Panel Wall Heater provides efficient and quiet heating for indoor spaces. Its fan-less design ensures silent operation and prevents the circulation of dust, making it suitable for individuals with asthma or dust allergies. The heater utilizes convection currents to circulate warm air throughout the room, offering constant ambient warmth.

- **Energy Efficient:** Designed to save up to 60% on heating costs compared to conventional space heaters.
- **Quiet Operation:** Fan-less design ensures noiseless heating.
- **Safety Features:** Includes tip-over and overheat protection, and is made with V0 flame retardant materials.
- **Versatile Placement:** Can be used freestanding with universal wheels or wall-mounted with included hardware.
- **Stylish Design:** Features a sleek aluminum frame and white finish.



Image: The Fierscial 800W Electric Panel Wall Heater highlighting its energy-saving capabilities, with an energy cost saving up to 60%.

Designed to meet all safety you needed



tip-over
protection



overheat
protection



V0 flame-retardant
materials



High-quality
Aluminum



Image: The Fierscial 800W Electric Panel Wall Heater emphasizing its safety features, including tip-over protection, overheat protection, V0 flame-retardant materials, and high-quality aluminum construction.

All aluminum integrated Wall Heater

Higher Heating Efficiency, long service life

290%

Multi-layer Extended fins

99%

Heat efficiency




Image: A detailed view of the Fierscial 800W Electric Panel Wall Heater's internal structure, showcasing its all-aluminum integrated design with multi-layer extended fins for higher heating efficiency.



Image: The Fierscial 800W Electric Panel Wall Heater in a bedroom, illustrating its quiet and comfortable operation with no blower, noiseless, non-drying, and non-illuminating features.

SETUP AND INSTALLATION

The Fierscial 800W Electric Convection Panel Wall Heater offers both freestanding and wall-mount installation options for your convenience.

Freestanding Installation (with Universal Wheels)

1. Carefully unpack the heater and all accessories.
2. Attach the universal wheels to the designated slots at the bottom of the heater. Ensure they are securely fastened.
3. Place the heater on a flat, stable surface in your desired location, ensuring it is away from flammable materials and has adequate clearance.

Wall-Mount Installation

1. Choose a suitable wall location, ensuring it is a sturdy surface and away from curtains or other flammable objects.
2. Use the provided wall-mount assembly hardware (screws and anchors).
3. Mark the drilling points on the wall using the heater as a guide or a template if provided.

4. Drill pilot holes at the marked points and insert the wall anchors.
5. Secure the mounting brackets to the wall using the screws.
6. Carefully hang the heater onto the mounted brackets, ensuring it is level and securely attached.
7. For enhanced efficiency, consider placing a reflective film (not included) behind the heater to direct heat back into the room and prevent wall absorption.



Image: The Fierscial 800W Electric Panel Wall Heater demonstrating its dual mounting options: wall-mount assembly and freestanding with universal wheels.

OPERATING INSTRUCTIONS

The Fierscial 800W Electric Convection Panel Wall Heater features intuitive knob controls for temperature and wattage settings.

Powering On/Off

- Ensure the power cord is securely plugged into a working 120V outlet.
- Check if the power knob is in the 'ON' position.
- Verify that the circuit breaker has not tripped.
- If the heater has overheated, unplug it, let it cool down for 10-15 minutes, and then plug it back in.
- Ensure the heater is on a stable surface and has not activated the tip-over switch.

Adjusting Temperature and Wattage

- **Temperature Control:** Use the rotary switch (top knob) to set your desired temperature between 45-86°F. The heater will maintain this temperature by cycling on and off.
- **Wattage Control:** Use the knob shift (bottom knob) to select between 400W (low) and 800W (high) heating modes, depending on your heating needs and energy preferences.



Image: A detailed view of the Fierscial 800W Electric Panel Wall Heater's knob temperature control, illustrating the rotary switch for temperature adjustment (45-86°F) and the knob shift for wattage selection (400W/800W).

Video: Product Overview and Operation

Your browser does not support the video tag.

Video: An official seller video providing an overview of the Fierscial 800W Electric Panel Wall Heater, demonstrating its features and basic operation.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Disconnect the heater from the power outlet before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If any damage is found, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter any issues with your Fierscial 800W Electric Convection Panel Wall Heater, refer to the following common troubleshooting steps:

- **Heater does not turn on:**
 - Ensure the power cord is securely plugged into a working 120V outlet.
 - Check if the power knob is in the 'ON' position.
 - Verify that the circuit breaker has not tripped.
 - If the heater has overheated, unplug it, let it cool down for 10-15 minutes, and then plug it back in.
 - Ensure the heater is on a stable surface and has not activated the tip-over switch.
- **Heater is not producing enough heat:**

- Ensure the wattage control is set to 800W (high).
- Check the thermostat setting; increase the desired temperature.
- Ensure the room size is appropriate for an 800W heater (refer to specifications).
- Verify that there are no obstructions blocking the air circulation around the heater.

• **Unusual noises or odors:**

- A slight clicking sound from the thermostat is normal as it cycles on and off.
- A new heater may emit a slight odor during its first few uses; this should dissipate quickly.
- If loud or persistent noises/odors occur, turn off and unplug the heater immediately and contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Fierscial
Model Number	HKWH002-800W-4
Heat Output	800 Watts
Voltage	120 Volts
Fuel Type	Electric
Product Dimensions	20.5"D x 5.5"W x 25"H
Item Weight	20.5 pounds
Color	White
Special Features	Bladeless, Energy Efficient, Flame Resistant, Noiseless, Overheat Protection, Tip-Over Protection, Wheels
Mounting Type	Wall Mount/Floor Mount
Indoor/Outdoor Usage	Indoor
Recommended Uses	Bathroom, Bedroom, Home, Living Room, for Indoor Use

WARRANTY AND SUPPORT

Fierscial offers a **30-day exchange/refund policy** and a **1-year warranty service** for your 800W Electric Convection Panel Wall Heater. This ensures your satisfaction with the product.

If you have any questions, concerns, or require technical assistance, please do not hesitate to reach out to Fierscial customer support. Refer to your purchase documentation for contact details.