

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Foxsky](#) /

› Foxsky FS43GATV 43-inch Full HD QLED Google TV User Manual

Foxsky FS43GATV

Foxsky FS43GATV 43-inch Full HD QLED Google TV User Manual

Model: FS43GATV

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Foxsky FS43GATV 43-inch Full HD QLED Google TV. Please read these instructions thoroughly before using the product and retain them for future reference.

Important Safety Information

- Ensure proper ventilation around the television.
- Do not expose the TV to rain or moisture.
- Avoid placing the TV near heat sources or in direct sunlight.
- Use only the power cord supplied with the TV.
- Do not open the TV casing; refer all servicing to qualified personnel.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your product packaging:

- 1 x Foxsky FS43GATV 43-inch LED TV
- 2 x Table Stand Base
- 1 x User Manual (this document)
- 1 x Remote Control



Image: The Foxsky FS43GATV 43-inch QLED Google TV, showcasing its frameless design and key features like Google TV and Full HD resolution.

3. SETUP GUIDE

3.1 Attaching the Table Stand

1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
2. Align the table stand bases with the corresponding screw holes on the bottom of the TV.
3. Securely fasten the bases using the provided screws.
4. Gently lift the TV and place it on a stable, level surface.



Image: Side and bottom profiles of the Foxsky FS43GATV television, illustrating the stand attachment points and slim design.

3.2 Wall Mounting (Optional)


If you choose to wall mount your TV, ensure you use a VESA-compatible wall mount kit (not included) and follow the instructions provided with the wall mount. Professional installation is recommended.

3.3 Connecting Peripherals

- **HDMI Devices:** Connect your set-top box, Blu-ray player, or gaming console to the HDMI ports on the TV. The TV has 2 HDMI ports.
- **USB Devices:** Connect USB hard drives or other USB devices to the 2 USB ports for media playback.
- **Power:** Connect the power cord to the TV and then to a power outlet.

FOXSKY

Slim Bezel Design



178°

TV Viewing Angle



Metal Stand



Image: Close-up of the side-mounted ports on the Foxsky FS43GATV, showing USB and RCA connections.



Image: Close-up of the bottom-mounted ports on the Foxsky FS43GATV, showing HDMI connections.

3.4 Initial Power On and First-Time Setup

1. Plug in the TV and press the power button on the remote control or TV.
2. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi), and Google account login.
3. The Google TV interface will guide you through personalizing your viewing experience.

4. OPERATING INSTRUCTIONS

4.1 Remote Control

Your Foxsky TV comes with a standard smart remote featuring voice assistant capabilities and quick access functions:

- **Quick Wake:** Turn on the TV in less than 5 seconds.
- **Quick Mute:** Double-tap the volume down button to mute the audio.
- **Quick Settings:** Press the settings button to access the quick settings menu.

- **Voice Assistant:** Use the dedicated button to activate the voice assistant for commands and searches.



Image: The Foxsky smart remote control, highlighting its Quick Wake, Quick Mute, and Quick Settings features.

4.2 Smart TV Features (Google TV)

The Foxsky FS43GATV operates on Google TV, offering a unified and personalized entertainment experience.

- **Integrated Content:** Google TV organizes movies, shows, live TV, and apps from various services into one interface.
- **Supported Applications:** Access popular streaming services such as Netflix, Prime Video, YouTube, Zee5, Sony Liv, Disney+Hotstar, and more.
- **Chromecast Built-in:** Easily cast content from your smartphone or tablet directly to the TV.
- **Google Assistant:** Use voice commands to search for content, control smart home devices, and get information.
- **Screen Mirroring:** Share your device's screen wirelessly with the TV.




Image: The Google TV home screen on the Foxsky TV, displaying various streaming applications like YouTube, Netflix, and Prime Video.




Image: An illustration of Google TV features, including Google Assistant, Chromecast built-in, and screen mirroring capabilities.

4.3 Display Features

- **QLED Panel:** Experience enhanced color volume and brightness.
- **HDR 10:** Provides superior contrast and color accuracy for a more vivid picture.
- **Micro Dimming:** Optimizes contrast by analyzing and adjusting brightness in different zones of the

screen.

- **178-Degree Wide Viewing Angle:** Ensures consistent picture quality from various positions.
- **Metallic Bezel-Less Design:** Offers an immersive viewing experience with minimal borders.




Image: Visual representation of the Foxsky TV's display technologies, including QLED, HDR Brightness, Micro Dimming, and Ultra Slim Design.

FOXSKY



Google TV

“Show me dramas”



Use Your voice remote to search across all apps including live TV and YouTube. Find exactly what you're looking for.

Google Assistant

1080
FULL HD





Image: A split-screen comparison demonstrating the enhanced vividness and detail provided by HDR on the Foxsky TV compared to non-HDR content.

4.4 Audio Features

- **30 Watts Output:** Powerful sound for an immersive audio experience.
- **Dolby Atmos:** Delivers rich, clear, and spatial audio.

5. MAINTENANCE

5.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using alcohol, benzene, thinners, or other volatile substances.

5.2 Software Updates

Your Foxsky Google TV may receive automatic software updates. Ensure your TV is connected to the internet to receive the latest features and performance improvements. You can also manually check for updates in the TV's settings menu.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Check if the power cord is securely plugged into both the TV and the power outlet. Ensure the power outlet is functional.
No picture, but sound is present	Verify the correct input source is selected. Check all cable connections (HDMI, etc.). Try restarting the TV.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio settings and external speaker connections if applicable.
Remote control not working	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV's IR sensor. Re-pair the Bluetooth remote if necessary.
Cannot connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password. Try restarting both the TV and the router.

For further assistance, please contact Foxsky customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Foxsky
Model	FS43GATV
Screen Size	43 Inches (109 cm)
Display Technology	QLED
Resolution	1920x1080 Pixels (Full HD)
Refresh Rate	60 Hz
Operating System	Google TV
RAM Memory	1 GB
Storage Capacity	8 GB

Feature	Detail
Connectivity	Wi-Fi (Dual Band), Bluetooth, 2 HDMI ports, 2 USB ports, Ethernet
Audio Output	30 Watts, Dolby Atmos
Viewing Angle	178 Degrees
Product Dimensions (LxWxH)	96 x 8 x 55.8 cm
Item Weight	9 kg
Special Features	Voice Remote, HDR-10, Wide Color Gamut, Chromecast built-in, Google Assistant



Image: Diagram illustrating the dimensions of the Foxsky FS43GATV television in centimeters.

8. WARRANTY AND SUPPORT

Warranty Information:

- 1-Year Foxsky India Standard Warranty on the product from the date of purchase.
- Six months standard warranty on the remote control (covers technical defects only).
- Warranty claims can be processed using your Amazon e-invoice.

Customer Support:

- For technical assistance or warranty claims, please contact Foxsky customer care.
- Toll Free No.: +91-7079797902
- Email: customercare@foxskyindia.com
- Website: www.foxskyindia.com