

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [MILOUZ](#) /

› MILOUZ TK-Pro Remote Control with Phone Stand User Manual

## MILOUZ TK-Pro

# MILOUZ TK-Pro Remote Control with Phone Stand User Manual

Model: TK-Pro | Brand: MILOUZ

## 1. INTRODUCTION AND OVERVIEW

The MILOUZ TK-Pro Remote Control with Phone Stand is a versatile device designed to enhance your digital experience across various platforms. It combines a stable phone stand with a multi-functional Bluetooth remote, allowing for hands-free interaction with your smartphone or tablet.

This device supports remote control for popular short video applications like TikTok and YouTube, enabling actions such as scrolling, volume adjustment, pausing/playing, and liking content. It also functions as an e-book page turner for reading apps (not compatible with Kindle devices) and a Bluetooth camera shutter for remote photo and video capture.



Image: MILOUZ TK-Pro Remote Control and Phone Stand in use with a smartphone displaying TikTok content.

Video: Overview of the MILOUZ Multi-functional Remote Control with Phone Holder, demonstrating its various uses.

## 2. WHAT'S IN THE BOX

- Remote control
- Phone stand
- USB-C Charging Cable
- User's manual

## 3. SETUP

---

### 3.1 Charging the Remote Control

Before first use, fully charge the remote control using the provided USB-C charging cable. A full charge takes approximately 1.5 hours and provides 70-80 hours of use.

### 3.2 Bluetooth Pairing

1. **Turn on the Remote Control:** Long press the power button (usually located on the top or side) for 3 seconds until the indicator light flashes.
2. **Enable Bluetooth on Your Device:** Go to your phone or tablet's Settings and ensure Bluetooth is turned on.
3. **Connect to "TK-PRO":** In the Bluetooth settings, locate and select "TK-PRO" from the list of available devices to pair.
4. **(For iOS Users - Important Accessibility Setting):** To ensure full functionality, especially for scrolling, navigate to your iOS device's Settings > Accessibility > Zoom. Turn on Zoom. If the screen becomes zoomed, double-tap the screen with three fingers to restore the normal view. This step is crucial for the remote's scrolling features to work correctly on iOS.
5. **Start Using:** Once paired, you can open your desired app (TikTok, Kindle App, Camera) and begin using the remote.

Video: Detailed guide on connecting the MILOUZ TK-Pro remote control to iOS devices for TikTok scrolling.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Remote Control Functions



Image: MILOUZ TK-Pro Remote Control button layout and corresponding functions.

- **Slide Up/Down:** Use the up/down arrow buttons to scroll content vertically.
- **Slide Left/Right:** Use the left/right arrow buttons to navigate horizontally (e.g., turn pages in e-books).
- **Volume +/-:** Adjust media volume using dedicated buttons.
- **Pause/Play:** The 'OK' button typically functions as pause/play.
- **Like/Continuous Likes:** Pressing a specific button (often 'OK' or a designated 'like' button) can register a like. Double-clicking may enable continuous liking in some apps.
- **Camera Shutter:** Press the camera button to remotely take photos or start/stop video recording. Long press for 2 seconds to focus for clearer shots.

### 4.2 Using with TikTok and Short Video Apps

Place your phone on the stand. Use the up/down buttons to scroll through videos. Use the 'OK' button to

pause/play or like videos. The remote allows for hands-free viewing and interaction.



Image: Remote control functions for TikTok, including slide up/down, left/right, volume, pause/play, and liking.

### 4.3 Using as an E-book Page Turner

For reading apps (e.g., Kindle App, not Kindle devices), use the left/right arrow buttons to turn pages forward or backward. This provides a comfortable reading experience without needing to touch the screen.

**Note:** Not compatible with dedicated Kindle e-readers (e.g., Paperwhite, Oasis).

# E-Book Page Turner


**Note:** Only for kindle app, not compatible with kindle devices.



iPhone/Android eBooks



iPad eBooks



Tablet eBooks



Kindle app



Kindle Devices

Image: MILOUZ TK-Pro remote control used as an e-book page turner for various devices, highlighting incompatibility with Kindle devices.



Image: Demonstrating the remote control's use for scrolling through e-books on a tablet.

## 4.4 Using as a Bluetooth Camera Shutter

Open your device's camera app. Use the camera button on the remote to take photos or start/stop video recording from a distance. This is ideal for selfies, group photos, or stable video recording.

## REMOTE CONTROL FOR TAKING PHOTOS/VIDEOS



Image: Remote control functionality for taking photos and videos, including focusing for clearer shots.

### 4.5 Phone Stand Features

The integrated phone stand can rotate 360° to switch between horizontal and vertical screen orientations. It provides a stable base for your device, allowing for comfortable viewing.



Image: The phone stand's 180-degree rotation for horizontal/vertical viewing and the magnetic storage feature for the remote.

#### 4.6 Magnetic Storage

The remote control is magnetically stored within the phone stand, preventing loss and ensuring it's always ready for use.

Video: Demonstration of the remote control's magnetic storage within the phone holder.

### 5. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place when not in use. Ensure the remote is securely stored in its magnetic slot.
- **Charging:** Charge the remote regularly to maintain battery health, even if not used frequently.

### 6. TROUBLESHOOTING

- **Remote Not Connecting:**

- Ensure the remote is charged and powered on.
  - Check that Bluetooth is enabled on your device.
  - Forget the device in your Bluetooth settings and try pairing again.
  - Ensure no other Bluetooth devices are interfering.
- **Scrolling Not Working (iOS):**
    - Verify that the Accessibility > Zoom setting is enabled as described in the Setup section.
- **Remote Not Responding:**
    - Recharge the remote control.
    - Restart your phone/tablet and try reconnecting.
- **Incompatible with Kindle Devices:**
    - The remote is designed for reading apps on smartphones and tablets, not for dedicated Kindle e-readers.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	TK-Pro
Package Dimensions	5.2 x 3.66 x 1.73 inches
Item Weight	5.3 ounces
Batteries	1 A battery required (included)
Charging Time	Approx. 1.5 hours
Use Time	Approx. 70-80 hours
Special Feature	Remote control, Phone Stand
Color	Black
Max Number of Supported Devices	1
Compatible Devices	iPhone, Android, iPad, Tablet (Incompatible Devices: Amazon Fire HD 10 (10th/11th generation))

# WIDE COMPATIBILITY



iPhone/Android



iPhone/Android/iPad/Tablet

Image: Illustrates the wide compatibility of the MILOUZ TK-Pro with various mobile devices.

## 8. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your MILOUZ TK-Pro Remote Control with Phone Stand, please refer to the contact information provided with your purchase or visit the official MILOUZ website. Keep your purchase receipt for warranty claims.