

TopMade CB154

TopMade MagSafe Wallet with Adjustable Stand Instruction Manual

Model: CB154

INTRODUCTION

Thank you for choosing the TopMade MagSafe Wallet with Adjustable Stand. This product is designed to securely hold your cards and provide a versatile stand for your iPhone 12, 13, 14, 15, 16, and 17 series. It features strong magnetic attachment, RFID blocking, and a multi-angle adjustable stand for enhanced convenience.

PRODUCT OVERVIEW

The TopMade MagSafe Wallet is a compact accessory made from premium vegan leather. It includes:

- Magnetic attachment system for secure connection to MagSafe-compatible iPhones or cases.
- Integrated adjustable stand with a hinge for multiple viewing angles.
- Card slots capable of holding up to 6 cards.
- Clear ID window for easy identification display.
- Thumb slot for quick card access.
- RFID blocking technology to protect card data.
- Anti-demagnetization lining for magnetic cards.



Image: The TopMade MagSafe Wallet in black, showcasing its sleek design and magnetic attachment area.

SETUP

1. Attaching the Wallet:

Align the TopMade MagSafe Wallet with the MagSafe area on the back of your iPhone (iPhone 12/13/14/15/16/17 series) or MagSafe-compatible case. The strong magnets will automatically snap the wallet into place, ensuring a secure connection.



Image: Illustration demonstrating the strong magnetic connection between the wallet and an iPhone, highlighting the 3800 Gauss magnetic strength.

2. Inserting Cards:

Gently slide your credit cards, ID cards, or cash into the designated card slots. The wallet is designed to securely hold up to 6 cards. Utilize the clear ID window for frequently accessed identification.

Smart Card Holder

Tightly holds 1-4 cards equally secure



Image: A hand inserting a credit card into the wallet's card slot, demonstrating the secure fit.


OPERATING INSTRUCTIONS

1. Using the Adjustable Stand:


The wallet features a built-in adjustable hinge. Fold the wallet to create a stand. It supports three modes: horizontal screen, vertical screen, and suspension. Adjust the angle between 15 to 160 degrees to find your preferred viewing position for activities like watching videos, video calls, or browsing.

Free Your Hands with Adjustable Stand

Adjust your most comfortable viewing angle



Landscape



Portrait

Image: An iPhone propped up by the wallet's adjustable stand in both landscape and portrait orientations, illustrating its versatility.

2. Accessing Cards:

To retrieve a card, use the thumb slot at the bottom of the wallet to push the desired card upwards. The design allows for quick and easy access without removing the wallet from your phone.



Image: A close-up of a hand utilizing the thumb slot to easily slide out an ID card from the wallet.

3. **RFID Blocking:**

The wallet is equipped with RFID blocking technology. This feature automatically protects your credit cards and other RFID-enabled cards from unauthorized scanning and data theft when stored inside the wallet.

Secure Your Magnetic Cards

Anti-degaussing & RFID Barrier Protect Cards



Anti-degaussing
lining

Image: A visual representation of the anti-degaussing lining and RFID barrier protecting cards within the wallet from external scanning devices.

Product Demonstration Video

Your browser does not support the video tag.

Video: An official demonstration of the TopMade MagSafe Wallet with Stand, showcasing its features and functionality, including card storage and stand adjustments.

MAINTENANCE

- **Cleaning:** Wipe the vegan leather surface with a soft, damp cloth. Avoid using harsh chemicals or

abrasive cleaners, as these can damage the material.

- **Storage:** When not in use, store the wallet in a cool, dry place away from direct sunlight to preserve the material's integrity.
- **Avoid Overstuffing:** While the wallet can hold up to 6 cards, consistently overstuffing it may stretch the material and reduce its ability to securely hold fewer cards over time.

TROUBLESHOOTING

Wallet does not attach securely to iPhone:

Ensure your iPhone is a MagSafe-compatible model (iPhone 12/13/14/15/16/17 series). If using a case, verify it is a MagSafe-compatible case. Non-magnetic cases will prevent proper attachment.

Compatibility



iPhone 15/14/
13/12 Series



MagSafe Cases



Normal Case + Magnetic
Metal Ring



iPhone 12 Mini/
13 Mini



Non-magnetic cases



Leather Cases

Image: A compatibility chart showing compatible iPhone models and cases (MagSafe-enabled) and incompatible ones (iPhone 12/13 Mini, non-magnetic cases).

Cards feel loose or fall out:

The wallet is designed to hold 1-6 cards securely. If you are only carrying one or two cards and they feel loose, ensure they are properly seated. Avoid stretching the card slots by inserting too many cards beyond the recommended capacity.

Stand is unstable:

Ensure the wallet is fully unfolded and the hinge is locked into position for the desired viewing angle. Place the phone on a flat, stable surface. Adjust the angle within the 15-160 degree range for optimal stability.

Magnetic cards are demagnetizing:

The wallet includes anti-degaussing protection. If you experience demagnetization issues, ensure cards are fully inserted into the slots and not exposed. Contact support if issues persist.

SPECIFICATIONS

Brand	TopMade
Model Number	CB154
Material	Vegan Leather
Color	Black
Magnetic Strength	Up to 3,800 Gauss
Card Capacity	Up to 6 cards
Stand Adjustment Angle	15-160 degrees
Dimensions (L x W x H)	4.07 x 2.59 x 0.53 inches
Special Features	ID Window, RFID Blocking, Adjustable Stand, Thumb Slot
Compatibility	iPhone 17/16/15/14/13/12 Series (MagSafe compatible phones/cases only). Not compatible with iPhone 12/13 mini or non-magnetic cases.

WARRANTY AND SUPPORT

TopMade products are manufactured with quality and customer satisfaction in mind. For any questions, concerns, or support needs regarding your MagSafe Wallet, please contact TopMade US directly through the Amazon platform or visit the official TopMade store page.

Please retain your proof of purchase for any warranty claims. Specific warranty details may be available on the product packaging or the official TopMade website.

Online Support: [Visit the TopMade Store on Amazon](#)