

[Manuals.plus](#) /

› [MEDION](#) /

› MEDION P66096 Bluetooth FM Shower Radio User Manual

MEDION P66096

MEDION P66096 Bluetooth FM Shower Radio User Manual

Model: P66096 / MD43884

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your MEDION P66096 Bluetooth FM Shower Radio. Please read this manual thoroughly before using the device and retain it for future reference. The MEDION P66096 is designed to provide wireless music streaming and FM radio reception in wet environments, featuring IPX6 water protection and a convenient suction cup for mounting.



The MEDION P66096 shower radio, shown in blue, features a circular LED display and control buttons, surrounded by water splashes, highlighting its water-resistant design.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent damage to the device or personal injury:

- Do not immerse the device in water. While it is IPX6 water-protected against strong water jets, it is not designed for submersion.
- Keep the USB-C charging port dry before connecting the charging cable.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Ensure the suction cup is securely attached to a clean, smooth surface before mounting the radio.
- Avoid extreme temperatures and direct sunlight.

IPX6 Wasserschutz

Rundum geschützt
vor starkem Strahlwasser



A woman smiles while showering, with the MEDION P66096 radio visible on the tiled wall, demonstrating its IPX6 water protection against strong water jets.

3. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- MEDION P66096 Bluetooth FM Shower Radio
- USB-C Charging Cable
- User Manual

4. PRODUCT FEATURES

- **Bluetooth 5.1:** For wireless music streaming from compatible devices.
- **IPX6 Water Protection:** Resistant to strong water jets, suitable for shower environments.
- **Integrated Lithium-Polymer Battery:** Up to 12 hours of music playback.
- **Hands-Free Function:** Built-in microphone for calls.

- **FM Radio:** Automatic station search for easy tuning.
- **Clock with Alarm Function:** Convenient timekeeping and wake-up feature.
- **Removable Suction Cup:** For easy and secure mounting on smooth surfaces.
- **LED Display:** Shows radio frequency, time, Bluetooth status, charging status, and battery level.
- **Acoustic Low Battery Warning:** Alerts you when the battery needs recharging.



A man with soap suds on his head sings enthusiastically in the shower, with the MEDION P66096 radio mounted on the wall, symbolizing its music playback capability.

5. SETUP

5.1 Charging the Device

1. Locate the USB-C charging port on the side of the radio. Ensure the port is dry.
2. Connect the provided USB-C cable to the radio and the other end to a compatible USB power adapter (not included).
3. The LED display will indicate charging status. A full charge typically takes approximately 3-4 hours.

4. Disconnect the charging cable once fully charged.

5.2 Attaching the Suction Cup

1. Ensure the desired mounting surface (e.g., shower wall, tile) is clean, smooth, and dry.
2. Press the suction cup firmly against the surface.
3. Attach the radio to the suction cup. Verify that the radio is securely mounted before releasing it.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

- Press and hold the **Power button** (●) for a few seconds to turn the radio on or off.
- The LED display will illuminate when the device is powered on.

6.2 Bluetooth Pairing

1. Turn on the radio. It will automatically enter Bluetooth pairing mode if no device is connected. The Bluetooth icon on the LED display will flash.
2. On your smartphone or tablet, enable Bluetooth and search for available devices.
3. Select "MEDION P66096" from the list of devices.
4. Once paired, the Bluetooth icon on the radio's display will stop flashing and remain solid. You can now stream audio wirelessly.

Kabelloses Musikstreaming per Bluetooth 5.0

Lieblingslieder bequem vom Smartphone abspielen



An illustration showing a smartphone playing music, with a Bluetooth connection icon, indicating wireless music streaming to the MEDION P66096 shower radio.

6.3 FM Radio Operation

1. Press the **Mode button (M)** to switch to FM radio mode. The display will show the radio frequency.
2. Press and hold the **Play/Pause button** (⏮) to initiate automatic station search. The radio will scan and save available FM stations.
3. Use the **Previous** (⏮) and **Next** (⏭) buttons to navigate through the saved stations.

UKW-Radioempfang

Am frühen Morgen schon bestens informiert



A man shaves in front of a mirror, with the MEDION P66096 radio mounted nearby, indicating its FM radio reception capability for morning routines.

6.4 Hands-Free Function

- When connected via Bluetooth, incoming calls will be routed through the radio.
- Press the **Call button** (●) to answer an incoming call.
- Press the **Call button** again to end the call.

6.5 Clock and Alarm Function

- Refer to the full user manual for detailed instructions on setting the clock and alarm. These functions are typically accessed via the Mode button and navigation buttons.

7. MAINTENANCE

- **Cleaning:** Wipe the radio with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, even if not in use for extended periods.

- **Storage:** Store the device in a cool, dry place when not in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device using the USB-C cable.
No sound.	Volume too low; device not connected; incorrect mode.	Increase volume; ensure Bluetooth is connected or FM radio is tuned; check mode setting.
Bluetooth not connecting.	Device out of range; not in pairing mode; previously connected to another device.	Ensure device is within 10m; put radio into pairing mode; disconnect from other devices.
Poor FM radio reception.	Weak signal; interference.	Relocate the radio; perform automatic station search again.

9. SPECIFICATIONS

Feature	Detail
Brand	MEDION
Model Number	P66096 (MD43884)
Connectivity Technology	Bluetooth 5.1
Water Protection	IPX6 (Protected against strong water jets)
Power Source	Battery Powered (Integrated Lithium-Polymer)
Battery Life	Up to 12 hours (music playback)
Charging Port	USB-C
Music Output Power	30W Max (3W RMS)
Supported Radio Bands	FM
Special Features	Integrated battery, Bluetooth, microphone, LED display, clock, alarm function, removable suction cup.
Compatible Devices	Smartphone, Tablet
Dimensions (approx.)	80 mm (W) x 80 mm (D) x 70 mm (H)



An image displaying the approximate dimensions of the MEDION P66096 shower radio: 80 mm width, 80 mm depth, and 70 mm height.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official MEDION website. Information regarding spare parts availability and software updates is not available in this manual.

If you encounter any issues not covered in the troubleshooting section, please contact MEDION customer service for assistance.

© 2024 MEDION. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DBZZ4Z1T>

More documents and user manuals: <https://manuals.plus/>