

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Memorex](#) /

> [Memorex MX-PDV200 10-Inch Dual Screen DVD Player User Manual](#)

Memorex MX-PDV200

Memorex MX-PDV200 10-Inch Dual Screen DVD Player User Manual

Model: MX-PDV200 | Brand: Memorex

INTRODUCTION

The Memorex MX-PDV200 is a portable dual-screen DVD player designed for entertainment on the go. It features two 10-inch digital screens for synchronized playback, supporting various media formats including DVD, CD, MP3, and JPEG files. This system includes options for USB and SD card playback, a rechargeable battery, and accessories for car installation, making it suitable for travel and home use.

WHAT'S INCLUDED

The Memorex MX-PDV200 package contains the following items:

What's Included in The Box



10 INCH DUAL LCD SCREEN



SUPPORT LEG

CAR CHARGER



DC TO DC CABLE



REMOTE CONTROL



WALL CHARGER



memorex®

Image: Contents of the Memorex MX-PDV200 package, showing two 10-inch LCD screens, a support leg, car charger, DC to DC cable, remote control, and wall charger.

- Two (2) 10-inch Digital LCD Screens (Master and Slave units)
- AC Adapter (Wall Charger)
- Car Adapter (Car Charger)
- Remote Control
- DC-to-DC Cable (for connecting master and slave units)
- AV Cable
- Mounting Straps (for car headrest installation)

PRODUCT FEATURES

- **Dual 10-Inch Digital Screens:** Provides synchronized playback for a shared viewing experience. The master screen controls playback, and the slave screen mirrors the content.
- **Wide Media Compatibility:** Supports DVD, CD, DVD±R/DVD±RW, CD-R/RW, MP3, and JPEG files.

- **USB and SD Card Slots:** Allows direct playback of digital media files from USB drives or SD cards.
- **Rechargeable Li-Ion Polymer Battery:** Offers up to 3 hours of continuous playback on a single charge, with overheat protection.
- **Comprehensive Accessories:** Includes all necessary cables and mounting hardware for versatile use in vehicles or at home.



Image: Two Memorex MX-PDV200 10-inch dual screens displaying a movie, shown side-by-side, highlighting the synchronized playback feature.

SETUP

Connecting the Dual Screens

To enable synchronized playback, connect the master unit to the slave unit using the provided DC-to-DC cable. Ensure both units are powered on for the slave unit to display content from the master.

Car Mounting

The MX-PDV200 can be securely mounted to car headrests using the included mounting straps or brackets.



Enjoy your DVDs on the way

Keep your kids entertained on long road trips

memorex®

Image: Two Memorex MX-PDV200 DVD players mounted on the back of car seats, providing entertainment for rear passengers during a road trip.

Powering the Device

Use the AC adapter for home use or the car adapter for in-vehicle charging and operation. The built-in rechargeable battery provides portable power for up to 3 hours.

OPERATION

Media Playback

The player supports various media types:

**DVD / CD / CD-R / CD-RW / DVD+R
DVD+RW / MP3 / JPEG**



Image: Memorex MX-PDV200 DVD player displaying a movie, with a remote control and text indicating supported media types: DVD, CD, CD-R, CD-RW, DVD+R, DVD+RW, MP3, JPEG.

- **DVD/CD:** Open the disc tray, insert a compatible disc, and close the tray. Playback will typically begin automatically.
- **USB/SD Card:** Insert a USB drive into the USB port or an SD card into the SD card slot. Use the player's menu to navigate and select media files (MP3, JPEG).



Image: Close-up view of the Memorex MX-PDV200 DVD player's side ports, including earphone jack, AV out, SD/MMC card slot, USB port, DC out, and DC in, with a DVD disc in the open tray.

Using the Remote Control

The included remote control allows for convenient operation of playback functions, volume adjustment, menu navigation, and source selection.

MAINTENANCE

- Keep the device clean by wiping with a soft, dry cloth.
- Avoid exposing the player to extreme temperatures, direct sunlight, or moisture.
- Handle discs and media cards carefully to prevent scratches or damage.
- Store the player and accessories in a safe place when not in use.

TROUBLESHOOTING

- **No Power:** Ensure the AC adapter or car adapter is securely connected and the power outlet is functional. Check the battery charge level.
- **No Picture/Sound:** Verify that all cables (DC-to-DC, AV) are correctly connected. Ensure the correct input source is selected if connected to an external display. Check volume levels.
- **Disc Read Error:** Ensure the disc is clean and free of scratches. Try a different disc to confirm the issue is not with the media.
- **USB/SD Card Not Recognized:** Ensure the USB drive or SD card is inserted correctly and contains compatible media files.

SPECIFICATIONS

Feature	Specification
Brand	Memorex
Model Name	MX-PDV200
Screen Size	10-inch (Dual Screens)
Resolution	640 x 480 pixels
Media Type Support	CD, DVD, DVD±R/RW, CD-R/RW, MP3, JPEG
Connectivity	USB, SD card, AV cable
Audio Output Mode	Stereo
Battery Type	Rechargeable Li-Ion Polymer
Battery Runtime	Up to 3 hours
Special Features	Dual Screen Synchronized Playback

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included in your product packaging or visit the official Memorex website. Keep your purchase receipt as proof of purchase for any warranty claims.