



Manuals.plus /

› Hikenture /

› Hikenture Collapsible Wagon (Model 1054-BLACK) Instruction Manual

## Hikenture 1054-BLACK

# Hikenture Collapsible Wagon Instruction Manual

Model: 1054-BLACK

Brand: Hikenture

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your Hikenture Collapsible Wagon. Designed for versatility and durability, this extra-large utility wagon is ideal for transporting heavy loads in various outdoor and daily scenarios.

### Key Features:

- **Large Capacity:** Offers a spacious interior of 36.2" x 21.7" x 15" (7 cubic feet / 200L), capable of holding up to 330 lbs (150 kg).
- **Compact Folding:** Collapses to a compact size of approximately 9" x 11.4" x 24.4" for easy storage and transport.
- **Durable Construction:** Features a strong alloy steel frame and thickened oxford fabric for tear resistance.
- **All-Terrain Wheels:** Equipped with large, all-terrain wheels, including 360-degree rotating front wheels, for smooth navigation across diverse surfaces.
- **Flexible Handle:** Telescoping handle with a rebound function ensures easy control and upright positioning.

## 2. SETUP AND UNFOLDING

---

Your Hikenture Collapsible Wagon comes pre-assembled, requiring minimal setup to begin use.

## Steps to Unfold:

1. Remove the wagon from its packaging. It will be in a compact, folded state.
2. Locate the central pull strap inside the wagon.
3. Gently push down on the sides of the wagon while pulling the central strap upwards. The wagon frame will expand outwards.
4. Once fully expanded, the bottom fabric will flatten. Insert the removable hard base panel into the bottom of the wagon to provide a stable surface.
5. Adjust the telescoping handle to your desired height by pressing the red button on the handle shaft and extending it.



Image: The Hikenture Collapsible Wagon fully unfolded and ready for use, demonstrating its large capacity with various items.

## 3. OPERATING INSTRUCTIONS

The Hikenture Collapsible Wagon is designed for easy and efficient transport of goods.

## Loading the Wagon:

- Ensure the wagon is fully unfolded and the base panel is securely in place before loading.
- Distribute weight evenly within the wagon to maintain stability.
- Do not exceed the maximum weight capacity of 330 lbs (150 kg).
- Utilize the two water bottle holders located at the front of the wagon for beverages or small items.

## Maneuvering the Wagon:

- The telescoping handle can be adjusted for comfortable pulling by users of various heights.
- The 360-degree rotating front wheels allow for easy turning and navigation around obstacles.
- The all-terrain wheels are suitable for various surfaces including roads, grass, and rough terrain.
- For optimal control, pull the wagon rather than pushing it, especially when heavily loaded or on uneven ground.



Image: Detail of the wagon's all-terrain wheel, showing its features for smooth movement.



Image: The adjustable handle of the wagon, illustrating its flexibility for various users.

Your browser does not support the video tag.

Video: Demonstration of the Hikenture 7CU.FT. Extra Large Collapsible Wagon in various usage scenarios, highlighting its capacity and ease of movement.

## 4. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your wagon.

### Cleaning:

- The thickened oxford fabric is removable for easy cleaning.
- Hand wash the fabric with mild soap and water. Do not machine wash or tumble dry.
- Wipe down the steel frame with a damp cloth as needed.
- Ensure all components are completely dry before folding and storing to prevent mold or rust.

## 5. FOLDING AND STORAGE

The wagon's compact folding design allows for convenient storage in small spaces.

## Steps to Fold:

1. Empty the wagon of all contents.
2. Remove the hard base panel from the bottom of the wagon.
3. Locate the central pull strap (the same one used for unfolding).
4. Pull the central strap upwards firmly. The sides of the wagon will begin to collapse inwards.
5. Continue pulling until the wagon is fully folded into its compact form.
6. Secure the folded wagon with the integrated Velcro strap to keep it tightly closed.
7. Place the removable base panel into the designated pocket on the cover (if applicable) or store it alongside the folded wagon.
8. The folded wagon can be easily stored in a car trunk, closet, or garage, requiring minimal space.

## COMPACT STORAGE



Image: The wagon in its folded state, illustrating its compact size for storage.

# SPECIFICATIONS



Image: Detailed dimensions of the wagon in both unfolded and folded configurations.

## 6. SPECIFICATIONS

---

Feature	Detail
Product Dimensions (Unfolded)	37.4"D x 22.5"W x 42.2"H
Product Dimensions (Folded)	Approx. 9"D x 11.4"W x 24.4"H
Material	Alloy Steel Frame, Thickened Oxford Fabric
Color	Black
Weight Limit	330 Pounds (150 kg)
Capacity	7 Cubic Feet (200 L)
Item Weight	22 Pounds
Number of Wheels	4 (All-Terrain, 360-degree front rotation)
Handle Material	Alloy Steel (Telescoping with rebound function)
Assembly Required	No (Comes pre-assembled)

## 7. TROUBLESHOOTING

---

If you encounter any issues with your Hikenture Collapsible Wagon, please refer to the following common solutions:

- **Wagon not unfolding/folding smoothly:** Ensure the central pull strap is fully engaged or disengaged. Check for any obstructions in the folding mechanism.
- **Difficulty maneuvering:** Verify that the wheels are free of debris. Ensure weight is evenly distributed. For heavy loads, pulling is generally easier than pushing.
- **Wagon unstable:** Confirm the hard base panel is correctly inserted and lies flat at the bottom of the wagon. Avoid exceeding the maximum weight capacity.

## 8. WARRANTY AND SUPPORT

---

The Hikenture Collapsible Wagon includes Lifetime Customer Support. For any questions, concerns, or assistance, please contact Hikenture customer service.