Faber MYSTIC BLDC FL HC BK 60

Faber 60 cm 1500 m³/hr Autoclean Kitchen Chimney

Model: HOOD MYSTIC BLDC FL HC BK 60
Brand: Faber

1. Introduction

Thank you for choosing the Faber HOOD MYSTIC BLDC FL HC BK 60 Kitchen Chimney. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read this manual thoroughly before installation and use, and keep it for future reference.

What's Included:

- 1 x Faber Kitchen Chimney Unit
- 1 x User Manual

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury to persons, observe the following:

- Always disconnect the appliance from the power supply before cleaning or maintenance.
- Installation must be carried out by a qualified technician in accordance with all local codes and regulations.
- Ensure the voltage and frequency of the power supply match the specifications on the rating plate of the appliance.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not use the chimney for purposes other than its intended use (extracting cooking fumes).

- Maintain adequate ventilation in the room when the range hood is used at the same time as appliances burning gas or other fuels.
- Never leave frying food unattended as grease can ignite.
- Clean the chimney regularly to prevent grease accumulation.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Product Overview and Features

The Faber HOOD MYSTIC BLDC FL HC BK 60 is a sophisticated wall-mounted kitchen chimney designed for efficient smoke and odor extraction. It features advanced filterless technology, a powerful BLDC motor, and convenient control options.

Key Features:

- **High Suction Power:** 1500 m^3/hr for effective smoke removal.
- **Filterless Technology:** Eliminates the need for traditional filters, reducing maintenance.
- **Heat Auto Clean:** Automated cleaning function for internal components.
- **Touch & Gesture Control:** Modern and intuitive control interface.
- **Remote Control:** For convenient operation from a distance.
- **BLDC Motor:** Energy-efficient and durable motor.
- **9 Speed Options:** Adjustable suction power to suit various cooking needs.
- **LED Lighting:** Bright and energy-efficient illumination for your cooking area.

Product Views:



Figure 3.1: Front view of the Faber Kitchen Chimney, showcasing the sleek black finish and touch control panel.



Figure 3.2: Bottom view of the chimney, illustrating the filterless suction area and oil collector tray.



Figure 3.3: The remote control unit for convenient operation of the chimney's functions.

4. Setup and Installation

The Faber HOOD MYSTIC BLDC FL HC BK 60 is a wall-mounted chimney. Proper installation is crucial for optimal performance and safety. It is highly recommended that installation be performed by a qualified professional.

Pre-Installation Checklist:

- Ensure the wall is strong enough to support the chimney's weight (24 kg).
- Verify the availability of a suitable electrical outlet (230 Volts).
- Confirm adequate space for ducting (ducted ventilation type).
- Maintain appropriate distance between the cooking surface and the chimney as per local regulations and manufacturer guidelines.

Installation Steps (General Guide - Consult Professional):

1. **Marking and Drilling:** Accurately mark drilling points on the wall based on the chimney's mounting bracket. Drill holes and insert wall plugs.
2. **Mounting Bracket Installation:** Securely fasten the mounting bracket to the wall using appropriate screws.
3. **Chimney Mounting:** Carefully lift and mount the chimney unit onto the installed bracket. Ensure it is level and securely fixed.
4. **Ducting Connection:** Connect the exhaust duct to the chimney's outlet and route it to the external vent. Ensure airtight connections to maximize suction efficiency.

5. **Electrical Connection:** Connect the chimney to the power supply. Ensure proper grounding.
6. **Final Checks:** Test all functions (lights, fan speeds, auto-clean) to ensure proper operation.

Product Dimensions:

The overall dimensions of the chimney are approximately:

Depth (D): 42 Centimeters

Width (W): 59.5 Centimeters

Height (H): 43.9 Centimeters



Figure 4.1: Side view of the chimney, illustrating its compact design and dimensions.

5. Operating Instructions

Your Faber chimney offers multiple ways to control its functions: a touch and gesture control panel on the unit itself, and a remote control.

Control Panel (Touch & Gesture):

The control panel is located on the front of the chimney. It features touch-sensitive buttons and supports gesture recognition for common functions.

- **Power On/Off:** Touch the power icon to turn the chimney on or off.
- **Fan Speed Adjustment:** Use the '+' and '-' icons to increase or decrease the fan speed. There are 9 speed options available.
- **Light Control:** Touch the light icon to turn the LED lights on or off.
- **Auto Clean:** Press the auto-clean icon to initiate the heat auto-clean cycle.
- **Gesture Control:** Specific hand gestures (e.g., waving left/right) can be used to control power and fan speed. Refer to the on-screen indicators for gesture recognition.

Remote Control:

The remote control provides convenient access to all chimney functions from a distance.

- **Power Button:** Turns the chimney on or off.

- **Light Button:** Controls the LED lighting.
- **Speed Up/Down Buttons:** Adjusts the fan speed (9 levels).
- **Auto Clean Button:** Activates the heat auto-clean function.
- **Timer Button:** Sets a timer for automatic shutdown (if applicable, check specific model features).

For optimal performance, always select a fan speed appropriate for the amount of cooking fumes being generated.

6. Maintenance and Cleaning

Regular maintenance ensures the longevity and efficient operation of your Faber chimney. Thanks to its filterless technology and auto-clean function, maintenance is simplified.

Heat Auto Clean Function:

The heat auto-clean feature uses a heating element to melt and collect oil and grease particles from the internal components into an oil collector tray. It is recommended to run the auto-clean cycle regularly, depending on your cooking frequency.

1. Ensure the chimney is off and cool before starting.
2. Press the "Auto Clean" button on the control panel or remote. The chimney will run a cycle, typically indicated by a specific light or display.
3. Once the cycle is complete, carefully remove the oil collector tray (located at the bottom of the chimney).
4. Empty the collected oil and wash the tray with warm, soapy water. Rinse thoroughly and dry before reinserting.

CAUTION: The oil collector tray may contain hot oil immediately after an auto-clean cycle. Handle with care.

Exterior Cleaning:

- Wipe the exterior surfaces of the chimney with a soft cloth dampened with mild soap and water.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- For stainless steel parts, use a specialized stainless steel cleaner and polish in the direction of the grain.
- Ensure the chimney is completely dry before resuming operation.

7. Troubleshooting Guide

Before contacting customer service, please refer to the following table for common issues and their possible solutions.

Problem	Possible Cause	Solution
Chimney does not turn on.	No power supply. Power cord not properly connected. Fuse blown or circuit breaker tripped.	Check if the power plug is securely inserted into the outlet. Check your home's fuse box or circuit breaker. Ensure the main power switch for the chimney is on.

Problem	Possible Cause	Solution
Low suction power.	Ducting blocked or improperly installed. Oil collector tray full. Fan speed set too low.	Check for obstructions in the ducting system. Ensure ducting is airtight. Empty and clean the oil collector tray. Increase the fan speed.
Unusual noise during operation.	Loose components. Obstruction in the fan. Improper installation.	Ensure all screws and fittings are tight. Turn off and unplug the chimney, then carefully check for any foreign objects near the fan blades. Contact a qualified technician for inspection.
Auto Clean function not working.	Power interruption during cycle. Malfunction.	Ensure continuous power supply. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Faber customer support.

8. Technical Specifications

Feature	Specification
Brand	Faber
Model	MYSTIC BLDC FL HC BK 60
Mounting Type	Wall Mount
Material	Alloy Steel
Colour	Black
Finish Type	Black Finish
Airflow Displacement (Suction Power)	1500 m^3/hr (1500 CMPH)
Filter Type	Filterless
Special Feature	Auto Clean (Heat Auto Clean)
Controls Type	Remote, Touch & Gesture
Number of Speeds	9
Voltage	230 Volts
Noise Level	56 dB
Light Source Type	LED
Item Weight	24 Kilograms
Product Dimensions (LxWxH)	42D x 59.5W x 43.9H Centimeters

Feature	Specification
Ventilation Type	Ducted
Annual Energy Consumption	180 Kilowatt Hours Per Year
Manufacturer	Franke Faber India Pvt Ltd

9. Warranty and Customer Support

Warranty Information:

Your Faber HOOD MYSTIC BLDC FL HC BK 60 Kitchen Chimney comes with a comprehensive warranty:

- **Product Warranty:** 5 years on the entire product.
- **Motor Warranty:** 12 years on the motor.

This warranty covers manufacturing defects and ensures reliable performance under normal use. Please retain your purchase receipt as proof of purchase for warranty claims.

Customer Support:

For any service requests, technical assistance, or warranty claims, please contact Faber customer support. Ensure you have your product model number and purchase details ready when contacting support.
For the most up-to-date contact information, please visit the official Faber India website or refer to the contact details provided with your purchase documentation.

Note: Specifications are subject to change without prior notice for product improvement.

© 2024 Faber. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question