

[Manuals.plus](#) /

› [Yakry](#) /

› Yakry Y46 Baby Car Camera User Manual

Yakry Y46

Yakry Y46 Baby Car Camera User Manual

Model: Y46

INTRODUCTION

This user manual provides detailed instructions for the installation, operation, and maintenance of your Yakry Y46 Baby Car Camera. Please read this manual thoroughly before using the product to ensure proper functionality and safety. This camera is designed to provide a clear view of your baby in the back seat while driving, enhancing safety and peace of mind.

SAFETY INFORMATION

Always prioritize safety while driving. Do not attempt to adjust the camera or view the monitor for extended periods while the vehicle is in motion. Ensure the camera is securely mounted and cables do not obstruct driving controls or airbags. Keep the camera and accessories out of reach of children.

- Ensure all connections are secure before driving.
- Do not block the driver's view or interfere with vehicle operation.
- Avoid exposing the camera to extreme temperatures or direct sunlight for prolonged periods.
- Clean the lens with a soft, dry cloth only.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Yakry Y46 Baby Car Camera

Based on the product information, the package includes: 1* Baby Car Camera. Additional mounting hardware and power cables are typically included but not explicitly listed in the provided data.

SETUP

The Yakry Y46 Baby Car Camera is designed for easy installation. Follow these steps for optimal setup:

1. **Choose a Mounting Location:** Select a location in your vehicle that provides a clear, unobstructed view of your baby. Common locations include the headrest of the back seat or the rear window. The camera features a surface mount installation type.



Image: Front view of the Yakry Y46 Baby Car Camera, showing its compact design and integrated mounting bracket. The camera body is black with a central lens and a small indicator light above it. The mounting bracket extends from the back, designed for secure attachment.

2. **Secure the Camera:** Use the provided mounting hardware to firmly attach the camera. Ensure it is stable and does not wobble, even on bumpy roads.



Image: Side view of the Yakry Y46 Baby Car Camera, illustrating its adjustable base. The camera can be tilted to achieve the desired viewing angle, and the base provides a stable platform for surface mounting.

3. **Connect Power:** Connect the camera to your vehicle's power source using the provided power cable. The camera uses an RCA connector type for video output.
4. **Connect to Monitor:** Connect the camera's video output (RCA) to your compatible car monitor or display. The camera is designed to work with baby car camera compatible devices.
5. **Adjust Angle:** Once powered, adjust the camera's angle to get the best view of your baby.

OPERATING

The Yakry Y46 Baby Car Camera operates automatically once connected and powered. It provides a 720p video capture resolution with CCD CMOS optical sensor technology and a wide-angle lens for a comprehensive view.

- **Power On/Off:** The camera powers on automatically with your vehicle's ignition and powers off when the vehicle is turned off.
- **Viewing:** The camera transmits video wirelessly to your connected monitor. Ensure your monitor is set to the correct input channel to view the camera feed.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your camera.

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Cable Inspection:** Periodically check all cables and connections for wear or damage. Replace any damaged cables

immediately.

- **Mounting Check:** Ensure the camera remains securely mounted. Tighten any loose screws if necessary.

TROUBLESHOOTING

If you encounter issues with your Yakry Y46 Baby Car Camera, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image on monitor	No power to camera Loose video connection Monitor not on correct input	Check power cable and vehicle's power outlet. Ensure RCA connector is securely plugged in. Switch monitor input to the correct channel for the camera.
Flickering or distorted image	Interference Loose connection	Ensure no other electronic devices are causing interference. Check all cable connections for tightness.
Camera not staying in position	Mounting screws loose Mounting surface unstable	Tighten mounting screws. Re-mount the camera on a more stable surface.

SPECIFICATIONS

Feature	Detail
Brand	Yakry
Model Number	Y46
Product Dimensions	4.4 x 2 x 6.1 inches (4.4"L x 2"W x 6.1"H)
Item Weight	6.4 ounces
Color	Black
Installation Type	Surface Mount
Video Capture Resolution	720p
Optical Sensor Technology	CCD CMOS
Lens Type	Wide Angle
Connector Type	RCA
Compatible Devices	Baby car camera compatible devices
Manufacturer	Shenzhen Shi Ruchuang Kejiyouxian Gongsi
Date First Available	August 3, 2024

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Yakry website. Keep your purchase receipt for warranty claims.
Manufacturer: Shenzhenshi Ruchuang Kejiyouxian Gongsi

© 2024 Yakry. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question