

[Manuals.plus](#) /

› [Kviflon](#) /

› Kviflon 132 cm Silent Ceiling Fan with LED Light and Remote Control User Manual

## Kviflon 8903

# Kviflon 132 cm Silent Ceiling Fan with LED Light and Remote Control User Manual

Model: 8903

## 1. INTRODUCTION

Thank you for choosing the Kviflon 132 cm Silent Ceiling Fan with LED Light. This modern ceiling fan combines powerful airflow, quiet operation, adjustable lighting, and year-round comfort in a sleek and functional design. Equipped with a high-performance DC motor, it offers powerful airflow while maintaining an ultra-quiet operation below 35 dB. This manual provides detailed instructions for safe installation, operation, and maintenance of your new ceiling fan.

# VENTILATEUR DE PLAFOND DE 132 cm AVEC LUMIÈRE



Image 1.1: Kviflon 132 cm Silent Ceiling Fan with LED Light. Features include 6 speeds, reversible function, 3 light colors, dimmable light, 2-hour timer, and silent operation.

## 2. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Professional Installation Recommended:** Installation should be performed by a qualified electrician.
- **Power Disconnection:** Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- **Mounting Structure:** Ensure the mounting structure is capable of supporting the weight of the fan (at least 15 kg).
- **Blade Clearance:** Maintain a minimum clearance of 2.3 meters (7.5 feet) from the floor to the bottom of the fan blades. Ensure blades are clear of any obstructions.

- **Wiring:** All wiring must be in accordance with national and local electrical codes.
- **Remote Control:** Keep the remote control away from children.
- **Cleaning:** Do not use water or harsh chemicals for cleaning. Wipe with a dry, soft cloth.

### 3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact customer support.

- Ceiling Fan Motor Housing
- Fan Blades (5 pieces)
- Light Kit with LED Module
- Remote Control with Wall Mount
- Downrod (various lengths may be included)
- Mounting Bracket and Hardware
- User Manual


### 4. ASSEMBLY AND INSTALLATION

Professional installation is recommended for this product. A detailed installation video is available to assist with the mounting process. Please refer to the video for visual guidance.

#### 4.1 Pre-Installation Checks

- Ensure power is OFF at the circuit breaker.
- Confirm the ceiling junction box is securely mounted and can support the fan's weight.
- Check the dimensions of the fan to ensure it fits your space.

## VENTILATEUR DE PLAFOND 132 cm



Plafond plat Plafond incliné



Image 4.1: Fan dimensions (132 cm width, 24-34 cm height) and compatibility with flat or inclined ceilings.

### 4.2 Mounting the Bracket

1. Attach the mounting bracket to the ceiling junction box using the provided screws and washers. Ensure it is firmly secured.

### 4.3 Assembling the Fan

2. Insert the downrod through the canopy and motor housing.
3. Carefully hang the fan motor assembly onto the mounting bracket.
4. Connect the electrical wires according to the wiring diagram in the detailed manual.
5. Attach the fan blades to the motor housing. The blades are reversible, offering a choice between a silver or white finish.

# PALES DE VENTILATEUR RÉVERSIBLES

5 pales de ventilateur en bois, choisissez votre style pour votre espace



Image 4.2: Reversible fan blades, allowing selection between silver (Side A) and white (Side B) finishes.

6. Install the LED light kit to the bottom of the fan motor housing.
7. Secure the canopy to cover the wiring and mounting bracket.

## 5. OPERATION

Your Kviflon ceiling fan is controlled by the included remote control. Ensure batteries are installed correctly in the remote.

### 5.1 Fan Speed Control

The fan features 6 adjustable speeds to suit various needs and seasons.

# RÉGLAGE DE 6 VITESSES

Répondant aux besoins des différentes saisons et scénarios d'utilisation, vous offrant une expérience personnalisée et rafraîchissante.



## 1-2 VITESSES

**Vent confortable**  
adapté pour le sommeil

## 3-4 VITESSES

**Vent naturel**  
adapté à la vie quotidienne

## 5-6 VITESSES

**Vent fort**  
adapté pour l'été chaud

Image 5.1: 6 speed settings. Speeds 1-2 for comfortable sleep, 3-4 for natural daily wind, and 5-6 for strong wind in hot weather.

## 5.2 Light Control

The integrated LED light offers adjustable brightness and 3 color temperatures.

- **Color Temperature:** Switch between Warm White (3000K), Natural White (4500K), and Cool White (6000K).
- **Dimmable:** Adjust the brightness continuously from 0% to 100% to create the ideal ambiance.

## LUMIÈRES VIVES DE HAUTE QUALITÉ



**3000K**  
Lumière chaude



**4500K**  
Lumière naturelle



**6000K**  
Lumière blanche




Image 5.2: High-quality LED lights offering 3000K (Warm), 4500K (Natural), and 6000K (White) color temperatures, with continuous dimming.

### 5.3 Reversible Motor Function

The reversible DC motor allows for year-round use, optimizing air circulation for both cooling and heating.

- **Summer Mode (Forward Rotation):** Air circulates downwards, creating a refreshing breeze.
- **Winter Mode (Reverse Rotation):** Air circulates upwards, helping to distribute warm air evenly throughout the room.

# ROTATION INVERSÉE

Avec un design intelligent de rotation inversée, modifiant la direction du flux d'air pour une circulation améliorée, le rendant adapté à toutes les saisons.



## Rotation avant

L'air circule de haut en bas, créant un effet de brise fraîche.




## Rotation inversée

L'air circule de bas en haut, favorisant la circulation de l'air.

Image 5.3: Intelligent reverse rotation design. Forward rotation creates a cool breeze, while reverse rotation aids in warm air circulation.

## 5.4 Timer Function

Set the fan to automatically turn off after 2 hours using the timer function on the remote control.



## FONCTIONNEMENT SILENCIEUX

Profitez de la fraîcheur sans le dérangement du bruit, garantissant un environnement serein.



Image 5.4: Enjoy fresh air without noise disturbance, ensuring a serene environment. Features a convenient 2-hour timer.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically wipe the fan blades and motor housing with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Blade Tightness:** Check blade screws annually to ensure they are tight. Loose blades can cause wobbling and noise.
- **Light Cover:** Ensure the light cover is securely attached.
- **No Lubrication Needed:** The DC motor is permanently lubricated and does not require additional oiling.

## 7. TROUBLESHOOTING

Refer to this section for common issues and their solutions. If the problem persists, contact customer support.

| Problem                    | Possible Cause                                                  | Solution                                                                                                    |
|----------------------------|-----------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Fan does not start         | No power supply; Loose wiring; Remote control battery low/dead. | Check circuit breaker; Ensure all connections are secure; Replace remote control batteries.                 |
| Light does not work        | Loose wiring; LED module fault; Remote control issue.           | Check light kit wiring; Contact support for LED module replacement; Check remote batteries.                 |
| Fan wobbles                | Loose blade screws; Unbalanced blades; Loose mounting bracket.  | Tighten all blade screws; Use balancing kit (not included) if necessary; Ensure mounting bracket is secure. |
| Noisy operation            | Loose screws; Motor issue; Obstruction.                         | Check all screws; Ensure no wires are rubbing; Contact support if motor noise persists.                     |
| Remote control not working | Batteries dead/incorrectly inserted; Remote not paired.         | Replace batteries, ensure correct polarity; Refer to remote pairing instructions in the full manual.        |

## 8. SPECIFICATIONS

| Feature                | Detail                      |
|------------------------|-----------------------------|
| Brand                  | Kviflon                     |
| Model Number           | 8903                        |
| Color                  | Nickel                      |
| Dimensions (L x W x H) | 132 x 132 x 24 cm           |
| Power Source           | Corded Electric             |
| Voltage                | 230 Volts                   |
| Wattage                | 60 Watts                    |
| Noise Level            | 35 Decibels                 |
| Airflow Capacity       | 350 Cubic Meters per Minute |
| Number of Blades       | 5                           |
| Blade Material         | Wood                        |
| Light Type             | LED                         |

| Feature            | Detail                                                               |
|--------------------|----------------------------------------------------------------------|
| Special Features   | Silent Operation, LED Light, Timer, Remote Control, Reversible Motor |
| Control Method     | Remote Control                                                       |
| Indoor/Outdoor Use | Indoor                                                               |

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase. Our professional customer service team is available to assist you with any questions or issues you may encounter. Please contact us through the retailer's platform or the contact information provided in your purchase documents.