

## FRIDEKO HOME DE210803

# FRIDEKO HOME Vintage Metal Pendant Light

Model: DE210803

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and retain this manual for future reference. Improper installation can lead to electrical shock or fire.

- Always disconnect the power supply at the main circuit breaker before beginning any installation, maintenance, or bulb replacement.
- Installation should be performed by a qualified electrician if you are unsure about the process.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulb (Max 60W).
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Keep children away from the installation area.

## PRODUCT OVERVIEW

The FRIDEKO HOME Vintage Metal Pendant Light (Model DE210803) is a modern suspension luminaire featuring a durable semi-circular metal lampshade with a rust finish. It is designed to provide ambient lighting and enhance the aesthetic of various indoor spaces.



*Image: The FRIDEKO HOME Vintage Metal Pendant Light installed above a dining table, showcasing its design and illumination.*


### **Key Features:**

- **Durable Construction:** High-quality, rust-free metal lampshade ensures longevity.
- **Adjustable Cable:** Maximum length of 110 cm allows for customized height.
- **E27 Socket:** Compatible with various E27 bulb types (LED, CFL, Halogen, Incandescent).
- **Versatile Design:** Blends vintage aesthetics with modern simplicity, suitable for multiple room types.
- **Easy Installation:** Comes with all necessary mounting hardware and instructions.

### **PACKAGE CONTENTS**

---

Verify that all components are present and undamaged before proceeding with installation.



*Image: A close-up view of the individual components of the pendant light, including the metal base, electrical wire, E27 bulb socket, and the metal lampshade.*

- Metal Lampshade (Ø30cm)
- Ceiling Canopy (Ø12cm)

- Adjustable Suspension Cable (Max 110cm)
- E27 Bulb Socket
- Mounting Hardware (screws, anchors, wire connectors)
- Instruction Manual

## SPECIFICATIONS



*Image: A technical diagram illustrating the precise dimensions of the pendant light, including the lampshade, ceiling canopy, and adjustable cable length.*

Attribute	Value
Model Number	DE210803
Lampshade Dimensions (D x H)	30 cm x 15 cm
Ceiling Canopy Dimensions (D x H)	12 cm x 2 cm

Max. Adjustable Cable Length	110 cm
Material	Metal
Color/Finish	Rust
Bulb Base	E27
Max. Wattage	60W
Voltage	220V-240V
Number of Bulbs	1 (Bulb not included)
Installation Type	Semi-flush mount / Ceiling mount
Usage	Indoor
Item Weight	1.88 Kilograms

For detailed product information and energy efficiency data, please refer to the EPREL database:  
<https://eprel.ec.europa.eu/qr/1508364>

## SETUP AND INSTALLATION

Follow these steps carefully to ensure safe and correct installation of your pendant light.

### Tools Required:

- Screwdriver (Phillips and Flathead)
- Wire Strippers
- Pliers
- Drill (if installing new mounting holes)
- Ladder
- Voltage Tester

### Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker for the area where you are installing the light and turn off the power. Verify with a voltage tester.
2. **Prepare Mounting Surface:** If replacing an existing fixture, remove it. Ensure the junction box is securely mounted and can support the fixture's weight.
3. **Attach Mounting Bracket:** Secure the mounting bracket (usually included with the ceiling canopy) to the junction box using the provided screws.
4. **Adjust Cable Length:** Determine the desired hanging height for the pendant light. Loosen the cable grip on the ceiling canopy and adjust the cable length. Tighten the grip once the desired length is achieved.
5. **Wire Connections:** Carefully connect the electrical wires. Connect the live (usually brown or black) wire from the fixture to the live wire from the ceiling. Connect the neutral (usually blue or

white) wire from the fixture to the neutral wire from the ceiling. Connect the ground (green/yellow or bare copper) wire from the fixture to the ground wire from the ceiling/junction box. Use wire connectors to secure all connections.


6. **Secure Ceiling Canopy:** Tuck the wires neatly into the junction box. Align the ceiling canopy with the mounting bracket and secure it with the decorative nuts or screws provided.
7. **Install Bulb:** Screw an E27 bulb (not included) into the socket. Ensure the bulb's wattage does not exceed 60W.
8. **Restore Power:** Turn the power back on at the circuit breaker and test the light.



*Image: The pendant light beautifully integrated into a modern kitchen, demonstrating a typical installation scenario.*



Metal base



1.1 meters of wire



Exquisite Handwerkskunst E27



Lamp shade of metal

*Image: A pair of pendant lights illuminating a dining area, showing how multiple units can be used together.*

## OPERATING INSTRUCTIONS

---

This pendant light operates like any standard ceiling fixture. Once installed and powered, it can be controlled via a wall switch connected to the circuit.

- Ensure the light is properly installed and connected to a power source.
- Use a compatible E27 bulb (LED, CFL, Halogen, Incandescent) with a maximum wattage of 60W.
- Flip the wall switch to turn the light ON or OFF.

## MAINTENANCE

---

Regular maintenance will help prolong the life and appearance of your pendant light.

- **Cleaning:** Always turn off the power before cleaning. Wipe the lampshade and ceiling canopy with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Ensure the power is off and the bulb has cooled down before attempting to replace it. Unscrew the old E27 bulb and screw in a new one, ensuring it does not exceed 60W.
- **Inspection:** Periodically check the wiring and connections for any signs of wear or damage. If any issues are found, consult a qualified electrician.

## TROUBLESHOOTING

If you encounter any issues with your pendant light, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on	No power supply Loose wiring Faulty bulb Faulty wall switch	Check circuit breaker Verify wire connections (power off) Replace bulb Test/replace wall switch
Light flickers	Loose bulb Loose wiring Incompatible dimmer switch (if applicable)	Tighten bulb Check wire connections (power off) Ensure dimmer is compatible with bulb type
Buzzing sound	Loose bulb Incompatible bulb/fixture Loose wiring	Tighten bulb Try a different bulb type Check wire connections (power off)
Fixture is unstable	Improper mounting Loose screws	Ensure mounting bracket is secure Tighten all mounting screws

If the problem persists after attempting these solutions, please contact customer support.

## WARRANTY AND SUPPORT

FRIDEKO HOME products are manufactured with quality and durability in mind. This product comes with a standard warranty against manufacturing defects. Please retain your proof of purchase for warranty claims.

For any questions, technical assistance, or warranty inquiries, please contact FRIDEKO HOME customer support through the retailer where the product was purchased or visit our official website.

We are committed to providing excellent customer service and will assist you in resolving any issues you may encounter with our products.

© 2026 FRIDEKO HOME. All rights reserved.