



**Manuals.plus /**

- › **Tuxiwei /**
- › Tuxiwei Foxx FOXXD A55 Phone Case Instruction Manual

## **Tuxiwei Tuxiwei-20223939**

# **Instruction Manual**

Tuxiwei Foxx FOXXD A55 Phone Case with Wallet and Crossbody Lanyard

## **INTRODUCTION**

---

Thank you for choosing the Tuxiwei Phone Case for Foxx FOXXD A55. This product is designed to provide comprehensive protection for your device while offering convenient features such as a card holder, kickstand, and a detachable crossbody lanyard for hands-free portability. This manual will guide you through the installation, usage, and maintenance of your new phone case.



Image: The Tuxiwei Foxx FOXXD A55 Phone Case in black, featuring a clear back, integrated wallet, and a detachable crossbody lanyard, shown in use.

## COMPATIBILITY

---

This phone case is specifically designed for the **Foxx FOXXD A55** model only. Please ensure your phone model matches this specification before attempting installation to guarantee a proper fit and optimal protection. It is not compatible with any other phone models.

## PRODUCT FEATURES

---

- **High-Quality Materials:** Constructed from premium PU leather for a comfortable touch and a durable TPU bottom case for robust protection.
- **Detachable Crossbody Strap:** An adjustable and removable shoulder strap (30 to 55 inches) allows for hands-free carrying, offering versatility as a crossbody bag or a wristlet.
- **Integrated Wallet Pocket:** A flip-back wallet pocket with magnetic button closure securely holds cards, cash, and coins, ensuring your essentials are safe and easily accessible.
- **Convenient Kickstand:** The wallet flap doubles as a kickstand, providing a comfortable viewing angle for media consumption or video calls.
- **Enhanced Protection:** Features a clear back panel that is scratch-resistant and raised edges (0.33mm taller than the camera) to protect the camera lens and screen from scratches and impacts. The TPU bumper corners are designed

for drop protection, reducing impact from accidental falls.



Image: A collage showing the phone case from various angles, highlighting the card slot, kickstand function, and the detachable strap.



Durable magnetic snap to keep closed and protected

## DROP PROTECTION

Reduce the impact and vibration of mobile phones in the event of accidental falls or collisions



Image: An illustration demonstrating the drop protection capabilities of the case, with shockwaves emanating from the corners.

# SCRATCH RESISTANT & CAMERA PROTECTION

Scratch resistant clear back panel and raised edges provide extra protection

Taller than  
0.33mm



Image: A close-up view of the camera area, illustrating how the raised edges protect the camera lens from scratches.

## PACKAGE CONTENTS

---

Your package should contain the following items:

- 1 x Soft TPU Bumper Case with Integrated Wallet Pocket
- 1 x Detachable Crossbody Lanyard

## SETUP AND INSTALLATION

---

1. **Inserting Your Phone:** Gently align your Foxx FOXXD A55 phone with the case, ensuring all buttons and ports are correctly positioned. Press the phone firmly into the case until it is securely seated. The flexible TPU material allows for easy insertion and removal.
2. **Attaching the Crossbody Lanyard:** Locate the small loops on the side of the phone case, typically near the bottom. Attach the metal clasps of the detachable crossbody lanyard to these loops. Ensure the clasps are securely fastened.

to prevent accidental detachment.

3. **Adjusting the Lanyard Length:** The lanyard features an adjustable buckle. Slide the buckle along the strap to achieve your desired length, ranging from 30 to 55 inches, for comfortable crossbody or shoulder wear.



Image: A visual representation of the adjustable length of the crossbody lanyard, showing its range from 30 to 55 inches.

## OPERATING INSTRUCTIONS

### Using the Wallet Pocket

The integrated wallet pocket is located on the back of the case. Open the magnetic flap to access the card slots and a compartment for cash or coins. Insert your cards securely into the designated slots. Close the flap, ensuring the magnetic buttons engage to keep your belongings safe.



Image: A close-up view of the wallet pocket on the back of the case, showing a card inserted into one of the slots.

### **Utilizing the Kickstand Function**

To use the kickstand, simply open the wallet flap and fold it back to create a triangular stand. This allows you to prop your phone horizontally on a flat surface for hands-free viewing of videos, video calls, or reading.



## CONVENIENT BRACKET

Free your hands for reading and viewing. And there are two bracket functions convenient for daily use and watching dramas



Image: The phone case positioned on a surface, demonstrating its kickstand functionality for hands-free viewing.

### **Wearing the Crossbody Lanyard**

Once the lanyard is attached and adjusted, you can wear your phone case across your body or over your shoulder. This provides convenient, hands-free access to your phone, making it ideal for travel, events, or daily activities where you need quick access without holding your phone.



## Crossbody Strap Lanyard

The crossbody lanyard can be easily installed and disassembled. You can easily adjust the length according to your own needs, allowing you to cross your phone diagonally when your hands are not available to meet your needs in different occasions.



Image: A person wearing the phone case with the crossbody strap, illustrating its practical use for hands-free carrying.

### CARE AND MAINTENANCE

---

- **Cleaning:** To clean the PU leather and TPU surfaces, gently wipe with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these may damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures to preserve its material integrity and color.
- **Avoid Overstuffing:** Do not overfill the wallet pocket with too many cards or excessive cash, as this can stretch the material, weaken the magnetic closure, and potentially damage the case or its contents.

## TROUBLESHOOTING

---

### Case Does Not Fit Phone

Ensure your phone is indeed a Foxx FOXXD A55 model. This case is designed exclusively for this specific model. If your phone is a different model, the case will not fit correctly.

### Magnetic Closure Not Holding

Check if the wallet pocket is overstuffed. Excessive contents can prevent the magnetic closure from engaging properly. Remove some items to see if the closure improves. If the issue persists, inspect the magnets for any obstructions or damage.

### Lanyard Detaches Easily

Verify that the metal clasps of the lanyard are fully and securely closed onto the case's loops. Ensure there is no damage to the clasps or the loops on the case. Always double-check the connection before relying on the lanyard for carrying.

## SPECIFICATIONS

---

<b>Model Number</b>	Tuxiwei-20223939
<b>Compatible Phone Model</b>	Foxx FOXXD A55
<b>Material</b>	Premium PU Leather, TPU (Thermoplastic Polyurethane)
<b>Color</b>	Black
<b>Item Weight</b>	3.52 ounces (approximately 100 grams)
<b>Package Dimensions</b>	6 x 3 x 0.5 inches (approximately 15.24 x 7.62 x 1.27 cm)
<b>Lanyard Length</b>	Adjustable from 30 to 55 inches

## WARRANTY AND SUPPORT

---

Tuxiwei is committed to providing high-quality products. For any questions, concerns, or support needs regarding your phone case, please refer to the seller's contact information on your purchase platform or visit the official Tuxiwei brand page. Please retain your proof of purchase for any warranty claims.