

[manuals.plus](#) /

› [Lukasa](#) /

› [Lukasa Candle Warmer Lamp Instruction Manual](#)

Lukasa 075

Lukasa Candle Warmer Lamp Instruction Manual

Model: 075 | Brand: Lukasa

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Lukasa Candle Warmer Lamp. Please read this manual thoroughly before use and retain it for future reference.



Image: The Lukasa Candle Warmer Lamp, featuring a golden metallic stand, a textured glass lampshade, and a wooden base with a candle. The base emits a dynamic multi-color light, indicating its 7-color lamp base feature. The lamp is placed on a wooden table in a home setting.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please adhere to the following safety guidelines:

- Do not use the lamp with an open flame. This product is designed to melt candles using heat from the bulb, eliminating the need for a wick.
- Place the lamp on a stable, flat, and heat-resistant surface.
- Keep the lamp away from water or other liquids. Do not immerse any part of the lamp in water.
- Ensure the power cord is not pinched, tangled, or placed near hot surfaces.
- Unplug the lamp from the power outlet before cleaning or when not in use for extended periods.
- Do not touch the halogen bulb directly when it is hot. Allow it to cool before handling.
- Use only the specified 50-watt halogen bulbs (GU10 type) provided or recommended by the manufacturer.

- Keep out of reach of children and pets.
- Do not cover the lamp during operation. Ensure adequate ventilation around the unit.

FLAMELESS CANDLE LAMP

No flame, no smoke & no pollution



VS

<input checked="" type="checkbox"/> Safe and fire-free	<input type="checkbox"/> More dangerous
<input checked="" type="checkbox"/> Candle Last Longer	<input type="checkbox"/> Short candle life
<input checked="" type="checkbox"/> Flat Candle Surface	<input type="checkbox"/> Dented Candle Surface
<input checked="" type="checkbox"/> Fast Fragrance Release	<input type="checkbox"/> Slow Fragrance Release

Image: A visual comparison highlighting the safety benefits of the flameless candle warmer lamp (left) against a traditional burning candle (right). The lamp side shows "Safe and fire-free," "Candle Last Longer," "Flat Candle Surface," and "Fast Fragrance Release," while the traditional candle side shows "More dangerous," "Short candle life," "Dented Candle Surface," and "Slow Fragrance Release."

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Lukasa Candle Warmer Lamp Unit (Golden finish, Model 075)
- 2 x 50-watt Halogen Bulbs (GU10 type)
- Power Cord with In-line Dimmer and Timer Control
- User Manual (This document)



PRODUCT DETAILS



Dimmer & Timer



Height Adjustable



Glass Lampshade



Dimmer & Timer



Non-slip Mat



2 x 50 Watt

Image: A detailed breakdown of the product components, including the remote-like dimmer and timer control, the height-adjustable joint, the textured glass lampshade, the wooden base, the non-slip mat, and two 50-watt halogen bulbs.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Lamp:** The lamp unit typically comes pre-assembled. Ensure the metal stand is securely attached to the wooden base.
3. **Install Bulb:** Gently insert one of the provided 50-watt GU10 halogen bulbs into the socket located inside the lampshade. Twist to secure if necessary.
4. **Place Candle:** Position your desired scented candle (not included) on the center of the wooden base, directly beneath the bulb.
5. **Adjust Height:** Loosen the height adjustment knob on the metal stand. Adjust the height of the lampshade so that the bulb is approximately 2.6 to 5.9 inches (6.6 to 15 cm) above the top of your candle. This allows for optimal melting and fragrance dispersion. Tighten the knob to secure the height.
6. **Connect Power:** Plug the power cord into a standard electrical outlet.

HEIGHT ADJUSTABLE

Perfect to different size candle



Image: A diagram illustrating the adjustable height feature of the lamp. It shows the lamp's overall height can be adjusted between 9.8 inches and 12.5 inches, and the ideal candle height for effective warming is between 2.6 inches and 5.9 inches.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Locate the in-line control on the power cord. Press the power button to turn the lamp on or off.

5.2 Brightness Adjustment (Dimmer)

The lamp features 4 adjustable brightness levels. Use the dimmer buttons on the in-line control to increase or decrease the light intensity. Adjusting the brightness also controls the speed of fragrance dispersion from the candle.

5.3 Timer Function

The built-in timer allows you to set the lamp to automatically turn off after a specified duration. Press the timer button on the in-line control to cycle through the available settings:

- 2 Hours
- 4 Hours
- 8 Hours

The lamp will operate for the selected duration and then power off automatically.

Safe Timing Function

Embrace the flexibility of the 2/4/8 hour timer for sweet dreams.



Image: A graphic illustrating the timer function with options for 2, 4, and 8 hours, emphasizing its role in providing a safe and flexible user experience.

5.4 Dynamic 7-Color Lamp Base

The wooden base of the lamp features a dynamic 7-color LED light. This can be controlled independently from the main warming light.

- **Individual Color Selection:** Press the dedicated button on the in-line control to cycle through the 7 available colors.
- **Automatic Color Cycle:** Continue pressing the button to activate the automatic 7-color cycling mode.

- **Speed Adjustment:** In automatic cycling mode, there are two speed options to choose from.



Image: A visual representation of the dynamic 7-color LED lamp base, showing the lamp in a festive setting with a family. Below the image, swatches of the seven available colors (light blue, dark blue, pink, red, orange, green, purple) are displayed.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp:

- **Cleaning:** Unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the metal stand, glass

lampshade, and wooden base. Do not use abrasive cleaners or solvents.

- Bulb Replacement:** If the bulb burns out, ensure the lamp is unplugged and the bulb has cooled completely. Gently remove the old GU10 bulb and insert a new 50-watt GU10 halogen bulb.
- Wax Management:** If wax spills onto the wooden base, allow it to cool and harden. Gently scrape off the hardened wax using a plastic scraper or credit card to avoid damaging the wood. Wipe any residue with a soft cloth.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in. Power outlet is not working. Bulb is loose or burnt out.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another device. Check if the bulb is securely installed. Replace the bulb if it is burnt out.
Candle not melting or fragrance is weak.	Lamp height is too high. Brightness setting is too low. Bulb wattage is incorrect.	Adjust the lamp height closer to the candle (recommended 2.6-5.9 inches above candle). Increase the brightness level using the dimmer control. Ensure you are using a 50-watt GU10 halogen bulb.
7-Color lamp base not working.	Feature not activated. Internal LED issue.	Press the dedicated button on the in-line control to activate the color base. If the issue persists, contact customer support.

8. SPECIFICATIONS

Brand	Lukasa
Model Number	075
Colour	B2-golden
Product Dimensions	19.05 x 19.05 x 34.29 cm (7.5 x 7.5 x 13.5 inches)
Item Weight	1.1 kg (2.4 lbs)
Power/Wattage	50 watts
Special Features	Dimmable, 7-Color Lamp Base, Timer (2/4/8H), Adjustable Height
Lamp Type	Decorative Lamp / Candle Warmer
Bulb Type	GU10 Halogen (2 included)
Base Material	Wood
Shade Material	Glass

Switch Type	Push Button (In-line control)
-------------	-------------------------------

9. WARRANTY AND SUPPORT

Lukasa products are manufactured with quality and reliability in mind. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Lukasa website. Please have your model number (075) and purchase date available when contacting support.

For additional information, you may visit the [Lukasa Store on Amazon](#).

© 2025 Lukasa. All rights reserved.

Related Documents - 075

GRUPPSPEL  IKEA GRUPPSPEL Gaming Chair Assembly Instructions Step-by-step assembly guide for the IKEA GRUPPSPEL gaming chair, detailing parts, assembly steps, and important safety information.
 NEXA LDR-075 LED Dimmer Receiver - Installation and Operation Guide Comprehensive guide for the NEXA LDR-075 LED dimmer receiver, covering technical specifications, safety, installation, pairing, dimmer settings, and control methods for 12-24V LED lighting systems.
 Obi Robot Dining Companion: Instructions for Use Comprehensive instructions for the Obi robot dining companion, designed to assist individuals with upper extremity impairments in performing independent mealtime activities. Learn about setup, operation, safety, and maintenance.
 Vertical Doors Inc. Installation Guide for Chevrolet Camaro 2010 Comprehensive installation guide for Vertical Doors Inc. (Lambo Doors) conversion kit for the 2010 Chevrolet Camaro. Includes kit contents, required tools, and step-by-step instructions for modifying your vehicle's doors.

 <p>Tips on Installing and Maintaining Rain Bird Residential Valves</p> <p>Valves are an essential part of any sprinkler system. Their role in the system is to control the flow of water to specific areas of the lawn or garden.</p> <p>RAIN BIRD. 800-782-2444 • 800-338-2444 www.rainbird.com • 1-800-RAIN-BIRD</p>	<p>Rain Bird Residential Valves: Installation, Maintenance, and Troubleshooting Guide</p> <p>A comprehensive guide for installing, maintaining, and troubleshooting Rain Bird residential sprinkler valves. Covers valve types, installation procedures, operation, and common issues with detailed solutions.</p>
	<p>Lukasa SN004 Bluetooth/CD/MP3/USB Playback User Manual</p> <p>User manual for the Lukasa SN004, a Bluetooth, CD, MP3, and USB playback device. This guide provides information on product features, precautions, and technical specifications.</p>

Documents - Lukasa – 075



[**Produktkatalog: Vielfältige Artikel für Haushalt, Garten, Sport und Automobil**](#)

Umfassender Produktkatalog mit einer breiten Auswahl an Artikeln für den Haushalt, Garten, Sport und Automobilbereich, inklusive detaillierter Beschreibungen und Preise von bekannten Marken wie Gardena, HELLA, HP, Sony und vielen mehr.
lang:en score:9 filesize: 1.58 M page_count: 24 document date: 2019-08-06