

[Manuals.plus](#) /

> [Masterpart](#) /

> Masterpart Fridge Door Milk Bottle Holder Shelf Instruction Manual

Masterpart 00743291

Instruction Manual for Masterpart Fridge Door Milk Bottle Holder Shelf

Brand: Masterpart | Model: 00743291

1. PRODUCT OVERVIEW

This manual provides instructions for the Masterpart Fridge Door Milk Bottle Holder Shelf, a genuine replacement part designed to fit various Siemens refrigerator models. This clear plastic shelf is intended for the lower door section, providing organized storage for milk bottles and other items.



Figure 1: Front view of the Masterpart Fridge Door Milk Bottle Holder Shelf, showing its clear construction and the "SIEMENS" branding.

2. SETUP AND INSTALLATION

The Masterpart Fridge Door Milk Bottle Holder Shelf is designed for easy installation as a direct replacement part. No tools are typically required for installation.

Installation Steps:

1. **Preparation:** Ensure your refrigerator is unplugged or the power to the appliance is turned off before attempting installation. Clear any items from the existing shelf (if applicable) and remove it.
2. **Identify Placement:** Locate the designated slots or runners on the inside of your Siemens refrigerator door where the lower door tray is typically installed.
3. **Insert the Shelf:** Carefully align the new Masterpart shelf with the slots. Gently slide the shelf into place until it clicks securely into position. Ensure both ends of the shelf are fully seated and stable.
4. **Verify Stability:** Lightly push down on the shelf to confirm it is firmly installed and does not wobble.
5. **Restore Power:** Once the shelf is securely in place, restore power to your refrigerator.




Figure 2: Side view of the shelf, illustrating its depth and the clear plastic construction, which aids in proper alignment during installation.



Figure 3: Top-down view of the shelf, highlighting the full length and the design of the attachment points for secure fitting.

3. OPERATION AND USAGE

The Masterpart Fridge Door Milk Bottle Holder Shelf functions as a dedicated storage compartment within your Siemens refrigerator door. It is designed to hold standard milk bottles, juice cartons, and other similar-sized containers, optimizing

space and organization.

Usage Guidelines:

- Place items gently onto the shelf to prevent damage to the shelf or the items.
- Avoid overloading the shelf beyond its reasonable capacity to ensure stability and longevity.
- Distribute weight evenly to prevent stress on the shelf's mounting points.

4. MAINTENANCE

Regular cleaning and proper care will ensure the longevity and clear appearance of your Masterpart Fridge Door Milk Bottle Holder Shelf.

Cleaning Instructions:

- **Removal:** For thorough cleaning, carefully remove the shelf from the refrigerator door by reversing the installation steps.
- **Washing:** Wash the shelf by hand using warm water and a mild dish soap. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the clear plastic.
- **Rinsing:** Rinse the shelf thoroughly with clean water to remove all soap residue.
- **Drying:** Dry the shelf completely with a soft cloth before re-installing it in the refrigerator. Ensure no moisture is trapped in crevices.
- **Regular Wiping:** For light cleaning, the shelf can be wiped down with a damp cloth while still installed in the refrigerator.

5. TROUBLESHOOTING

If you encounter issues with your Masterpart Fridge Door Milk Bottle Holder Shelf, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Shelf does not fit or is loose.	Incorrect model compatibility or improper installation.	Verify your refrigerator model number against the compatible models list in Section 6. Ensure the shelf is correctly aligned and fully seated in the door slots. Apply gentle, even pressure until it clicks into place.
Shelf appears scratched or cloudy after cleaning.	Use of abrasive cleaners or materials.	Only use mild dish soap and a soft cloth for cleaning. Avoid harsh chemicals or abrasive sponges.
Shelf breaks or cracks easily.	Overloading or impact damage.	Avoid placing excessively heavy items on the shelf. Handle with care during installation and removal to prevent impact.

6. SPECIFICATIONS

Attribute	Detail
Brand	Masterpart

Attribute	Detail
Model Number	00743291
Product Type	Fridge Door Milk Bottle Holder Shelf / Lower Door Tray / Bottom Rack
Colour	Clear
Product Dimensions	50 x 20 x 20 cm (approximate)
Item Weight	500 g (approximate)
Included Components	Fridge Milk Bottle Holder Shelf Lower
	<p>Designed to fit various Siemens Refrigerators. Compatible models include (but are not limited to):</p> <p>KI21RAD30/01, KI21RAD30/02, KI21RAD30/03, KI21RAD40/01, KI21RAD40/02, KI21RAD40/03, KI21RAD40/04, KI21RAD40/05, KI21RADD0/01, KI21RADD0/02, KI21RADF0/01, KI21RADF0/02, KI21RAF30/01, KI21RAF30/02, KI21RAF30/03, KI21RAF30G/01, KI21RAF30G/02, KI21RAF30G/03, KI21RAF40/01, KI21RAF40/02, KI21RAF40/03, KI21RAF40/04, KI21RAF40/05, KI21RAFF0/01, KI21RAFF0/02, KI21REDD0/01, KI21REDD0/02, KI21RGD30/01, KI21RGD30/02, KI21RGD30/03</p> <p>KI22LAD30/01, KI22LAD30/02, KI22LAD30/03, KI22LAD30/04, KI22LAD30/05, KI22LAD30H/01, KI22LAD30H/02, KI22LAD30H/03, KI22LAD30H/04, KI22LAD30H/05, KI22LAD40/01, KI22LAD40/02, KI22LAD40/03, KI22LAD40/04, KI22LAD40/05, KI22LAD40/06, KI22LADD0/01, KI22LADE0/01, KI22LAF30/01, KI22LAF30/02, KI22LAF30/03, KI22LAF30/04, KI22LAF30/05, KI22LAF40/01, KI22LAF40/02, KI22LAF40/03, KI22LAF40/04, KI22LAF40/05, KI22LAF40/06, KI22LGD30/01, KI22LGD30/02</p> <p>KI31RAD30/01, KI31RAD30/02, KI31RAD30/03, KI31RAD40/01, KI31RAD40/02, KI31RAD40/03, KI31RAD40/04, KI31RAD40/05, KI31RADD0/01, KI31RADD0/02, KI31RADF0/01, KI31RADF0/02, KI31RADF0/03, KI31RAF30/01, KI31RAF30/02, KI31RAF30/03, KI31RAF30G/01, KI31RAFF0/01, KI31RAFF0/02, KI31RAFF0/03, KI31REDD0/01, KI31REDD0/02</p> <p>KI32LAD30/01, KI32LAD30/02, KI32LAD30/03, KI32LAD30/04, KI32LAD30H/01, KI32LAD40/01, KI32LAD40/02, KI32LAD40/03, KI32LAD40/04, KI32LAD40/05, KI32LAD40G/01, KI32LADD0/01, KI32LADF0/01, KI32LAF30/01, KI32LAF30/02, KI32LAF30/03, KI32LAF30G/01</p> <p>KI41FAD30/01, KI41FAD30/02, KI41FAD30/03, KI41FAD30/04, KI41FAD30/05, KI41FAD30/06, KI41FAD30/99, KI41FAD30R/01, KI41FAD30R/02, KI41FAD30R/03, KI41FAD30R/04, KI41FAD30R/05, KI41FAD40/01, KI41FAD40/02, KI41FAD40/03, KI41FAD40/04, KI41FAD40/99, KI41FADD0/01, KI41FADD0/02, KI41FADE0/01, KI41FAF30/01, KI41FAF30/02, KI41FAF30/03, KI41FAF30/04, KI41FAF30/05</p> <p>KI41RAD30/01, KI41RAD30/02, KI41RAD30/03, KI41RAD30/04, KI41RAD30/05, KI41RAD30H/01, KI41RAD30H/02, KI41RAD30H/03, KI41RAD30H/04, KI41RAD30H/05, KI41RAD40/01, KI41RAD40/02, KI41RAD40/03, KI41RAD40/04, KI41RAD40/05, KI41RAD40/06, KI41RADD0/01, KI41RADD0/02, KI41RADF0/01, KI41RADF0/02, KI41RADF0/03, KI41RAF30/01, KI41RAF30/02, KI41RAF30/03, KI41RAF30/04, KI41RAF30/05, KI41RAF30G/01, KI41RAF30G/02, KI41RAF30G/03, KI41RAF30G/04, KI41RAF30G/05, KI41RAFF0/01, KI41RAFF0/02, KI41RAFF0/03, KI41REDD0/01, KI41REDD0/02</p>

Attribute	Detail
Compatibility	<p> KI42FAD30/01, KI42FAD30/02, KI42FAD30/03, KI42FAD30/04, KI42FAD30/05, KI42FAD30/06, KI42FAD30/07, KI42FAD40/01, KI42FAD40/02, KI42FAD40/03, KI42FAD40/04 KI42LAD30/01, KI42LAD30/02, KI42LAD30/03, KI42LAD30/04, KI42LAD30/05, KI42LAD30/06, KI42LAD30H/01, KI42LAD30H/02, KI42LAD30H/03, KI42LAD30H/04, KI42LAD30H/05, KI42LAD30H/06, KI42LAD40/01, KI42LAD40/02, KI42LAD40/03, KI42LAD40/04, KI42LAD40/05, KI42LAD40/06, KI42LAD40/07, KI42LAD40G/01, KI42LAD40G/02, KI42LAD40G/03, KI42LAD40H/01, KI42LADE0/01, KI42LADE0H/01, KI42LADF0/01, KI42LAE30H/01, KI42LAE30H/02, KI42LAE30H/03, KI42LAE30H/04, KI42LAE30H/05, KI42LAE30H/06, KI42LAE0H/01, KI42LAF30/01, KI42LAF30/02, KI42LAF30/03, KI42LAF30/04, KI42LAF30/05, KI42LAF30/06, KI42LAF30G/01, KI42LAF30G/02, KI42LAF30G/03, KI42LAF40/01, KI42LAF40/02, KI42LAF40/03, KI42LAF40/04, KI42LAF40/05, KI42LAF40/06, KI42LAF40/07, KI42LAFF0/01, KI42LAFF0K/01 KI51FAD30/01, KI51FAD30/02, KI51FAD30/03, KI51FAD30/04, KI51FAD30/05, KI51FAD30/06, KI51FAD30/99, KI51FAD40/01, KI51FADE0/01, KI51FAF30/01, KI51FAF30/02, KI51FAF30/03, KI51FAF30/04, KI51FAF30/05, KI51FAF30/06 KI51RAD30/01, KI51RAD30/02, KI51RAD40/01, KI51RAD40/02, KI51RAD40/03, KI51RAD40/04, KI51RADE0/01, KI51RADE0/02, KI51RADF0/01, KI51RAF30G/01, KI51RAF30G/02, KI51RAF30G/03 KI52FAD30/01, KI52FAD30/02, KI52FAD30/03, KI52FAD30/04, KI52FAD30/05, KI52FAD30/06, KI52FAD30/07, KI52FAD40/01, KI52FADF0/01, KI52FADF0/02 KI52LAD30/01, KI52LAD30/02, KI52LAD30/03, KI52LAD40/01, KI52LAD40/02, KI52LAD40/03, KI52LADE0/01, KI52LADE0/02 KI72LAD30/01, KI72LAD30/02, KI72LAD30/03, KI72LAD30/04, KI72LAD30/05, KI72LAD30H/01, KI72LAD30H/02, KI72LAD30H/03, KI72LAD30H/04, KI72LAD30H/05, KI72LAD30Y/01, KI72LAD40/01, KI72LAD40/02, KI72LAD40/03, KI72LAD40/04, KI72LAD40/05, KI72LAD40/06, KI72LAD40/07, KI72LAD40/08, KI72LAD40H/01, KI72LAD40H/02, KI72LAD40H/03, KI72LAD40H/04, KI72LAD40H/05, KI72LAD40H/06, KI72LAD40H/07, KI72LADE0/01, KI72LADE0/02, KI72LADE0H/01, KI72LADE0H/02, KI72LAF30/01, KI72LAF30/02, KI72LAF30/03, KI72LAF30/04, KI72LAF30/05, KI72LAF30/06, KI72LAF30G/01, KI72LAF30G/02 KI77SAD30/01, KI77SAD30/02, KI77SAD30/03, KI77SAD30/04, KI77SAD30/05, KI77SAD30/06, KI77SAD30H/01, KI77SAD30H/02, KI77SAD30H/03, KI77SAD30H/04, KI77SAD30H/05, KI77SAD30H/06, KI77SAD40/01, KI77SAD40/02, KI77SAD40/03, KI77SAD40/04, KI77SAD40/05, KI77SAD40/06, KI77SAD40/07, KI77SAD40/08, KI77SADD0/01, KI77SADD0/02, KI77SADE0/01, KI77SADE0/02, KI77SADE0H/01, KI77SADE0H/02, KI77SAF30/01, KI77SAF30/02, KI77SAF30/03, KI77SAF30/04, KI77SAF30/05, KI77SAF30/06, KI77SAF30H/01, KI77SAF30H/02, KI77SAF30H/03, KI77SAFE0H/01, KI77SAFE0H/02 KI81FHD30C/01, KI81FHD30C/02, KI81FHD30C/03, KI81FPD20R/01, KI81FPD20R/02, KI81FPD30H/01, KI81FPD40H/01, KI81FPDE0/01, KI81FPF30G/01, KI81FPF30K/02 KI81RAD20R/01, KI81RAD20R/02, KI81RAD20R/03, KI81RAD20R/04, KI81RAD20R/05, KI81RAD20R/06, KI81RAD30/01, KI81RAD30/02, KI81RAD30/03, KI81RAD30/04, KI81RAD30/05, KI81RAD30/06, KI81RAD30/07, KI81RAD30A/01, KI81RAD30A/02, KI81RAD30H/01, KI81RAD30H/02 </p>

Attribute	Detail
	<p> KI81RAD30H/03, KI81RAD30H/04, KI81RAD30H/05, KI81RAD30H/06, KI81RADE0/01, KI81RADE0/02, KI81RADE0G/01, KI81RADE0G/02, KI81RADE0H/01, KI81RADE0H/02 KI81RAF30/01, KI81RAF30/02, KI81RAF30/03, KI81RAF30/04, KI81RAF30/05, KI81RAF30/06, KI81RAF30/07, KI81RAF30/08, KI81RAF30/09, KI81RAF30G/01, KI81RAF30G/02, KI81RAF30G/03, KI81RAF30G/04, KI81RAF30G/05, KI81RAF30G/06, KI81RAF30G/07, KI81RAF30G/08, KI81RAF30G/09, KI81RAF30M/01, KI81RAF30M/02, KI81RAF30M/03, KI81RAF30M/04, KI81RAF30M/05, KI81RAF30M/06, KI81RAF30M/07, KI81RAF30M/08, KI81RAF30M/09, KI81RAF30Z/01, KI81RAF30Z/02, KI81RAF31/01, KI81RAF31/02, KI81RAF31/03, KI81RAF31/04, KI81RAF31/05, KI81RAF31/06, KI81RAF31/07, KI81RAF31I/01, KI81RAF31I/02, KI81RAF31I/03, KI81RAF31I/04, KI81RAF31I/05, KI81RAFE0/01, KI81RAFE0/02, KI81RAFE0/03, KI81RAFE0G/01, KI81RAFE0G/02, KI81RAFE0G/03, KI81RAFE1/01, KI81RAFE1/02, KI81RAFE1/03, KI81RAFE2/01, KI81RAFE2/02, KI81REDE0/01, KI81REDE0/02 KI82CAF30/01, KI82CAF30/02, KI82FHD20R/01, KI82FHD20R/02, KI82FPD30H/01, KI82FPD30H/02, KI82FPDE0H/01 KI82LAD30/01, KI82LAD30/02, KI82LAD30/03, KI82LAD30/04, KI82LAD30/05, KI82LAD30H/01, KI82LAD30H/02, KI82LAD30H/03, KI82LAD30H/04, KI82LAD30H/05, KI82LAD40/01, KI82LAD40/02, KI82LAD40/03, KI82LAD40/04, KI82LAD40/05, KI82LAD40/06, KI82LAD40/07, KI82LAD40/08, KI82LAD40/09, KI82LAD40H/01, KI82LAD40H/02, KI82LAD40H/03, KI82LAD40H/04, KI82LAD40H/05, KI82LAD40H/06, KI82LAD40H/07, KI82LAD40H/08, KI82LAD40H/09, KI82LADE0/01, KI82LADE0H/01, KI82LADE0H/02 KI82LAF30/01, KI82LAF30/02, KI82LAF30/03, KI82LAF30/04, KI82LAF30/05, KI82LAF30/06, KI82LAF30/07, KI82LAF30G/01, KI82LAF30G/02, KI82LAF30G/03, KI82LAF30G/04, KI82LAF30N/01, KI82LAF30N/02, KI82LAF30N/03, KI82LAF30N/04, KI82LAF30N/05, KI82LAF30N/06, KI82LAF30N/07, KI82LAF30N/08, KI82LAF30N/09, KI82LAF30N/10 KI84FPD40/01, KI84FPDD0/01, KI84FPF30/01, KI84FPFE0/01 KI85NAD30/01, KI85NAD30/02, KI85NAD30/03, KI85NAD30/04, KI85NAD30/05, KI85NAD30/06, KI85NAD30/07, KI85NAD30G/01, KI85NAD30G/02, KI85NAD30G/03, KI85NAD30G/04, KI85NAD30G/05, KI85NAD30G/06, KI85NAD30G/07, KI85NADE0/01, KI85NADE0G/01, KI85NAF30/01, KI85NAF30/02, KI85NAF30/03, KI85NAF30/04, KI85NAF30/05 </p>

7. WARRANTY AND SUPPORT

Specific warranty information for this replacement part is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the original purchase documentation or contact Masterpart customer service directly.

For further assistance, please visit the [Masterpart brand page on Amazon](#) or consult your appliance's original manufacturer manual for part compatibility verification.

