

FZF Nugget Ice Maker Countertop

FZF Nugget Ice Maker Countertop User Manual

Model: Nugget Ice Maker Countertop | Brand: FZF

1. INTRODUCTION

Welcome to the user manual for your new FZF Nugget Ice Maker Countertop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

2. SAFETY INSTRUCTIONS

To ensure safe operation, please adhere to the following precautions:

- Always plug the ice maker into a grounded electrical outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker before cleaning or when not in use.
- Keep children away from the appliance during operation.
- Do not operate the appliance with a damaged cord or plug.
- Ensure proper ventilation around the unit.
- Use only potable water for ice production.

3. PRODUCT FEATURES

Your FZF Nugget Ice Maker is designed with convenience and efficiency in mind:

- **Crunchy Chewable Nugget Ice:** Produces soft, chewable nugget ice, ideal for various beverages.
- **Fast Ice Making:** Capable of producing ice in approximately 7 minutes, with a daily capacity of up to 34 lbs.
- **Quiet Operation:** Engineered for low noise levels during ice production.
- **One-Click Operation:** Simple interface with indicators for "Ice Full" and "Add Water".
- **Self-Cleaning Function:** Automated cleaning cycle for easy maintenance.

- **Compact Design:** Small footprint suitable for countertops, home bars, RVs, and camping.



Image: The FZF Nugget Ice Maker, a compact black unit with a clear lid, producing chewable nugget ice. A glass with a strawberry drink and ice is next to it.

4. PARTS LIST

Familiarize yourself with the components of your ice maker:

- Ice Maker Unit
- Ice Basket
- Ice Scoop
- Power Cord (integrated)

Self-Cleaning Function



 **1 PRESS**

 **15 MINS**

Image: The FZF Nugget Ice Maker displayed with its included ice basket and ice scoop, along with a bag of ice, illustrating the complete set of components.

5. SETUP

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit (at least 4 inches of space on all sides).
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

6.1. Making Ice

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Start Ice Production:** Press the "Ice/Clean" button once to start the ice making cycle. The "Ice Full" and "Add Water" indicators will illuminate as needed.
3. **Monitor Ice:** The ice maker will automatically stop when the ice basket is full or when water is low. The corresponding indicator light will turn on.
4. **Collect Ice:** Use the provided ice scoop to remove ice from the basket.



Image: A visual guide showing three steps to get nugget ice: 1. Add Water, 2. Press Ice/Clean button to start Ice Making, 3. Enjoy fresh and crunchy ice.

6.2. Indicator Lights

- **Ice Full:** Illuminates when the ice basket is full. The ice making process will pause.
- **Add Water:** Illuminates when the water reservoir is low. The ice making process will pause. Add water to resume.

One-Click Operation



Add-water Indicator



Ice-Full Indicator



Turn On/Off
Self-Cleaning



Image: A close-up of the ice maker's control panel, highlighting the "Ice Full", "Add Water", and "Ice/Clean" buttons and their corresponding indicator lights, demonstrating the one-click operation.

7. MAINTENANCE

7.1. Self-Cleaning Function

The ice maker features a convenient self-cleaning function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "Ice/Clean" button for 5 seconds. The ring indicator light will flash white.
3. The self-cleaning procedure will run for 15 minutes and then automatically exit.
4. To exit cleaning mode manually, press the "Ice/Clean" button again.

Come with Ice Bags

Ice Scoop and Basket



Image: The ice maker's interior during the self-cleaning cycle, showing water circulating, with text indicating "1 Press" and "15 Mins" for the cleaning process.

7.2. Regular Cleaning

For optimal performance and hygiene, regular manual cleaning is recommended:

- Unplug the ice maker before cleaning.
- Remove the ice basket and clean it with mild detergent and warm water. Rinse thoroughly.
- Wipe the interior and exterior surfaces of the ice maker with a soft cloth dampened with mild detergent.
- Drain any remaining water from the reservoir.
- Ensure all parts are completely dry before reassembling and storing or using the appliance.
- The fully open design allows for convenient cleaning of the interior.

Fully Open Design

Fully open lid for convenient cleaning



Image: The FZF Nugget Ice Maker with its lid fully open, revealing the interior water reservoir and ice-making components, emphasizing its design for easy cleaning.

8. TROUBLESHOOTING

Refer to this table for common issues and their solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; "Add Water" indicator on.	Fill the water reservoir with potable water.
	Ice basket is full; "Ice Full" indicator on.	Remove ice from the basket.

Problem	Possible Cause	Solution
	Appliance not plugged in or power outage.	Ensure the unit is properly plugged into a working outlet. Check power supply.
Ice production is slow or ice is not forming properly.	Ambient temperature is too high.	Place the ice maker in a cooler environment.
	Poor ventilation around the unit.	Ensure at least 4 inches of space around the ice maker for proper airflow.
Unusual noise during operation.	Normal operation sounds (compressor, water pump).	This is typically normal. If noise is excessive or unusual, contact customer support.

9. SPECIFICATIONS

Attribute	Detail
Model Name	Nugget Ice Maker Countertop
Brand	FZF
Product Dimensions (D x W x H)	11.3" x 8.66" x 12.68"
Weight	Approximately 20.94 Pounds
Capacity	34 Pounds (daily production)
Wattage	160 watts
First Ice Production Time	Approx. 7 minutes

Soft & Chewable Nugget Ice

Smaller & crunchy ice cubes Ice cubes melt slower
Suitable for mixed drinks Chills quickly



Image: A diagram showing the dimensions of the FZF Nugget Ice Maker: 12.68 inches in height, 11.3 inches in depth, and 8.66 inches in width.

10. WARRANTY AND SUPPORT

FZF offers a **12-month warranty** for this sonic ice maker. For any issues or support inquiries, please contact FZF customer service. They are available to assist you with product-related questions and troubleshooting.

For further assistance, you may visit the official FZF store on Amazon:[FZF Store](#)

