JOMAA JOMAA Wireless Keyboard Mouse Combo

JOMAA Ergonomic Wireless Keyboard and Mouse Combo User Manual

Model: JOMAA Wireless Keyboard Mouse Combo

1. Introduction

Thank you for choosing the JOMAA Ergonomic Wireless Keyboard and Mouse Combo. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless peripheral set. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

2. Package Contents

Please verify that all items are present in your package:

- 1 x Wireless Keyboard
- 1 x Wireless Mouse
- 1 x USB Receiver (stored in the mouse battery compartment)
- 1 x User Manual (this document)
- *Note: Batteries are not included and must be purchased separately.*



Image: The JOMAA wireless keyboard, mouse, and USB receiver. The keyboard is black with white keys, and the mouse is white. The small USB receiver is shown between them.

3. Setup Instructions

3.1. Installing Batteries

1. **For the Keyboard:** Open the battery compartment cover on the back of the keyboard. Insert 2 AAA batteries (not included), ensuring correct polarity (+/-). Close the cover.
2. **For the Mouse:** Open the battery compartment cover on the bottom of the mouse. Insert 1 AA battery (not included), ensuring correct polarity (+/-). The USB receiver is typically stored in this compartment; remove it before inserting the battery. Close the cover.

3.2. Connecting the USB Receiver

1. Locate the USB receiver, usually stored in the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer (laptop or desktop).
3. Your computer will automatically detect and install the necessary drivers. This is a plug-and-play device, so no manual driver installation is required.
4. The keyboard and mouse should now be ready for use.



Image: An overhead view of the wireless keyboard and mouse on a desk, next to a computer monitor. Icons below indicate features like 33ft transmission, ergonomic design, plug-and-play functionality, and 3 adjustable DPI levels for the mouse.

4. Operating Instructions

4.1. Keyboard Features

- **Full-Size Layout:** The keyboard features a standard full-size layout, including a numeric keypad, for comprehensive input.
- **Multimedia Hotkeys:** Access common functions quickly using the dedicated multimedia keys. These typically include volume control, play/pause, previous/next track, and more. Refer to the key legends for specific functions.
- **Ergonomic Design:** The keyboard is designed with an ergonomic profile to reduce strain during extended use.
- **Foldable Stands:** Utilize the foldable stands on the back of the keyboard to adjust the typing angle for improved comfort.



Image: A close-up view of the JOMAA wireless keyboard, highlighting the foldable stands extended to provide an elevated typing angle. A hand is shown typing on the keyboard.

4.2. Mouse Features

- **3-Level CPI Adjustment:** The mouse offers three adjustable CPI (Counts Per Inch) settings: 800, 1200, and 1600. Press the CPI button (usually located near the scroll wheel) to cycle through these sensitivities to match your preference and task requirements.
- **Silent Clicks:** The mouse features silent click buttons, reducing noise during operation.
- **Ergonomic Design:** The mouse is shaped to fit comfortably in your hand, promoting natural wrist and arm posture.



Image: A diagram illustrating the 3-level adjustable DPI (800, 1200, 1600) for the JOMAA wireless mouse. Insets show the ergonomic shape of the mouse and its silent click mechanism.

4.3. 2.4G Wireless Connection

The keyboard and mouse utilize a stable 2.4GHz wireless connection via a single USB receiver. This provides a reliable connection up to 10 meters (33 feet) from your device, offering flexibility and freedom of movement.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Battery Replacement:** Replace batteries when performance degrades (e.g., delayed response, intermittent connection). Dispose of old batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, remove batteries to prevent leakage. Store the USB receiver in the mouse's battery compartment to avoid loss.
- **Avoid Extreme Conditions:** Do not expose the devices to extreme temperatures, humidity, or direct sunlight.

6. Troubleshooting

Problem	Solution
Keyboard/Mouse not responding	◦ Ensure batteries are correctly installed and not depleted. Replace if necessary. ◦ Check if the USB receiver is securely plugged into a working USB port. Try a different USB port. ◦ Ensure the distance between the devices and the receiver is within 10 meters (33 feet) and there are no major obstructions. ◦ Restart your computer.
Lag or intermittent connection	◦ Move the receiver closer to the keyboard and mouse. ◦ Avoid placing the receiver near other wireless devices (e.g., Wi-Fi routers, Bluetooth devices) that might cause interference. ◦ Ensure fresh batteries are installed.
Mouse cursor movement is too fast/slow	Press the CPI button on the mouse to adjust the sensitivity (800/1200/1600 CPI).
Multimedia keys not working	Ensure your operating system and media player support these functions. Some functions may require specific software or settings.

7. Specifications

- **Brand:** JOMAA
- **Connectivity:** 2.4GHz Wireless USB
- **Wireless Range:** Up to 10 meters (33 feet)
- **Keyboard Layout:** Full-size with numeric keypad
- **Mouse CPI:** 800 / 1200 / 1600 DPI (adjustable)
- **Keyboard Battery:** 2 x AAA (not included)
- **Mouse Battery:** 1 x AA (not included)
- **Compatible Devices:** Laptops, Desktops (Windows, Android, iOS compatible)
- **Special Features:** Ergonomic design, Multimedia keys, Silent mouse clicks, Foldable keyboard stands
- **Package Dimensions:** 17.6 x 9.3 x 1.75 inches
- **Item Weight:** 1.56 pounds




Image: A detailed diagram showing the dimensions of both the JOMAA wireless keyboard and mouse. The keyboard measures 443mm in length and 144.5mm in width, with two height options (29mm and 42mm) when using the adjustable stands. The mouse measures 109mm in length, 61mm in width, and 32.5mm in height.

8. Warranty and Support

JOMAA products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your purchase or contact JOMAA customer support directly.

If you encounter any issues or have questions regarding your JOMAA Ergonomic Wireless Keyboard and Mouse Combo, please contact our customer support team. Contact details can typically be found on the product packaging or the official JOMAA website.

Online Support: Visit the JOMAA Store on Amazon for product information and support resources.

© 2024 JOMAA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question