

PERFASCIN AR-REM5E

PERFASCIN AR-REM5E Replacement Remote Control Instruction Manual

For Fujitsu AC Air Conditioners

1. INTRODUCTION

This manual provides instructions for the PERFASCIN AR-REM5E replacement remote control, designed for various Fujitsu AC Air Conditioner models. This remote control operates using infrared technology and requires no programming or pairing. Please read this manual carefully before use to ensure proper operation and longevity of your device.

2. PRODUCT OVERVIEW

The AR-REM5E remote control is a direct replacement unit, featuring a clear LCD display and intuitive button layout for controlling your Fujitsu air conditioner. It is designed for ease of use with a comfortable grip.



Figure 1: Front view of the AR-REM5E remote control, showing its overall dimensions (20.5 cm / 8.07 in length, 6 cm / 2.36 in width) and primary buttons including Economy, Temp. Up/Down, Powerful, and Power On/Off.



ECONOMY TEMP. POWERFUL



MODE	ENERGY SAVING PROGRAM	FAN
	SENSOR	SWING
OUTDOOR UNIT LOW NOISE	SET	SET
WEEKLY	ON/OFF	SLEEP
TIMER SETTING	SELECT	NEXT
SEND		BACK
CLOCK ADJUST	TEST RUN	RESET
		AR-REM5E

Figure 2: Front view of the remote control with the slide-down panel open, revealing additional function buttons such as Mode, Energy Saving Program, Fan, Swing, Sensor, Weekly, On/Off, Sleep, Timer Setting, Select, Next, Back, Send, Clock Adjust, Test Run, and Reset.





Figure 3: Back view of the remote control, showing the battery compartment cover and instructions for battery installation (AAA/R03/LR03x2) in Chinese, emphasizing correct polarity.

3. SETUP: BATTERY INSTALLATION

The AR-REM5E remote control requires two AAA batteries for operation. No programming is needed; simply insert the batteries, and the remote is ready for use.

1. Locate the battery compartment on the back of the remote control (refer to Figure 3).
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect polarity can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always use new batteries and do not mix old and new batteries or different types of batteries. Remove batteries if the remote will not be used for an extended period.

4. OPERATING INSTRUCTIONS

This remote control operates via infrared signals and does not require any programming or pairing with your air conditioner. Ensure a clear line of sight between the remote control and the air conditioner's receiver for optimal performance. The maximum effective range is approximately 33 feet (10 meters).

Basic Functions:

- **Power (/):** Press to turn the air conditioner On or Off.
- **Temp. (▲ / ▼):** Use the Up (▲) and Down (▼) buttons to adjust the desired temperature.
- **Mode:** Press to cycle through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Fan:** Adjusts the fan speed.
- **Swing:** Controls the louver swing function.
- **Economy:** Activates the energy-saving mode.
- **Powerful:** Activates a rapid cooling or heating function.
- **Sleep:** Engages the sleep mode for comfortable nighttime operation.

Advanced Functions (under slide-down panel):

- **Energy Saving Program:** Access specific energy-saving settings.
- **Sensor:** Activates or deactivates the temperature sensor function.
- **Weekly:** Set weekly operating schedules.
- **Timer Setting:** Configure On/Off timers.

- **Clock Adjust:** Set the current time on the remote's display.
- **Reset:** Resets the remote control to default settings.

5. COMPATIBILITY

The PERFASCIN AR-REM5E remote control is compatible with a wide range of Fujitsu AC Air Conditioner models, including but not limited to:

- ASYG12LTCB, ASYG14LTCB, ASYG07KMTA, ASYG09KMTA, ASYG12KMTA, ASYG24LECA, ASYG09LZCA, ASYG14KMTA, ASYG18KMTA, ASYG24KMTA, ASYG30KMTA, ASYG36KMTA
- ASHG07KMTA, ASYG07LECA, ASYG09LECA, ASYG14LECA, ASHG09KMTA, ASHG12KMTA, ASYG12LZCA, ASYG14LZCA, ASHG12KXCA
- ASHG18KMTA, ASHG24KMTA, ASHG30KMTA, ASHG36KMTA, ASYG14LMCE, ASYG18KLCA, ASHG07KMTB, ASHG09KMTB, ASHG12KMTB, ASHG14KMTB
- ASHG09LTCA, ASHG12LTCA, ASYG09LTCB, ASHG14KMTA, ASYG07LMCE, ASYG09LMCE, ASYG12LMCE, ASYG24KLCA
- ASYG09KMCB, ASYG12KMCB, ASYG14KMCB, ASYG09KHCA, ASYG12KHCA, ASYG14KHCA, ASYG09LECB, ASYG12LECB, ASYG14LECB

6. SPECIFICATIONS

Feature	Detail
Brand	PERFASCIN
Model Name/Number	AR-REM5E
Special Feature	No Programming Required
Color	White
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	33 Feet (approx. 10 meters)
Batteries Required	2 AAA batteries
Battery Type	Alkaline
Item Weight	1.9 Ounces
Item Dimensions (L x W x H)	6"L x 3"W x 0.5"H (approx. 15.24 cm x 7.62 cm x 1.27 cm)

7. TROUBLESHOOTING

- **Remote not responding:** Ensure batteries are correctly installed with the proper polarity. Replace old or depleted batteries with new ones.
- **Limited range or intermittent function:** Check for any obstructions between the remote control and the air conditioner's infrared receiver. Ensure the remote is pointed directly at the AC unit.

- **Remote received damaged or not working:** If the remote control arrives damaged or does not function upon initial setup, please contact the seller for assistance.
- **Remote not working with specific AC model:** While compatible with many models, if the remote does not function as expected with your specific Fujitsu AC model, please contact the seller for support.

8. SUPPORT

For any issues, questions, or if you require further assistance with your PERFASCIN AR-REM5E remote control, please contact the seller directly. They will provide support and solutions to ensure your satisfaction.