

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [EXknight](#) /

› EXknight Height Adjustable Controller Freaks for Xbox One and Xbox Series (Model M3-XS) Instruction Manual

EXknight M3-XS

EXknight Height Adjustable Controller Freaks for Xbox One and Xbox Series (Model M3-XS)

Instruction Manual

INTRODUCTION

Thank you for choosing EXknight Height Adjustable Controller Freaks. These thumbstick extensions are designed to enhance your gaming precision, grip, and overall control on Xbox One and Xbox Series controllers. By offering adjustable heights, you can customize your controller to suit your playstyle, leading to improved accuracy and reduced hand fatigue during extended gaming sessions.

PRODUCT OVERVIEW

The EXknight Controller Freaks provide a significant upgrade to your standard Xbox controller thumbsticks. They feature a height-adjustable design, allowing for finely tuned sensitivity and easier adaptation to different gaming scenarios. The set includes both Mid-Rise and High-Rise sticks, offering multiple height options for optimal comfort and performance.

- **Height Adjustable:** Customize your thumbstick height for improved sensitivity and control.
- **More Options:** Mid-Rise stick adjusts to 7mm or 8mm. High-Rise stick adjusts to 9mm, 10mm, 11mm, or 12mm.
- **Enhanced Control:** Dramatically improve aim, grip, and overall control.
- **Increased Accuracy:** Achieve better control for movement and faster target acquisition with increased precision.

PACKAGE CONTENTS

- 1 x Mid-Rise Thumbstick Extension
- 1 x High-Rise Thumbstick Extension

SETUP AND INSTALLATION

Installing your EXknight Controller Freaks is a straightforward process. Follow these steps for optimal setup:

1. **Select Your Thumbstick:** Choose between the Mid-Rise or High-Rise extension based on your preference for the left or right analog stick.
2. **Adjust Height (if applicable):** For the adjustable models, gently pull apart the top and bottom halves of the thumbstick extension. Rotate the inner mechanism to align with your desired height setting (e.g., 7mm, 8mm for Mid-Rise; 9mm, 10mm, 11mm, 12mm for High-Rise). Push the halves back together until they click securely.
3. **Attach to Controller:** Align the thumbstick extension with the existing analog stick on your Xbox controller. Gently push down until it securely clips onto the analog stick. Ensure it is firmly attached and does not wobble.
4. **Test Functionality:** Move the analog stick in all directions to confirm proper installation and smooth operation.

For a visual guide on adjusting the height and installation, please refer to the videos below:

Your browser does not support the video tag.

Video Description: This video demonstrates how to adjust the height of the EXknight control freaks by separating the two parts of the thumbstick and reattaching them at different height settings. It also shows the process of attaching the adjusted thumbstick to an Xbox controller.

Your browser does not support the video tag.

Video Description: A detailed video showing the step-by-step process of adjusting the height of the EXknight control freaks and installing them onto an Xbox controller, highlighting the different height options available.

OPERATING INSTRUCTIONS

Once installed, your EXknight Controller Freaks are ready for use. The extended height and enhanced grip provide several benefits:

- **Improved Precision:** The increased range of motion from the taller thumbsticks allows for finer adjustments and more precise aiming, particularly beneficial in first-person shooter (FPS) games.
- **Enhanced Grip:** The textured surface of the thumbsticks prevents slippage, ensuring consistent control even during intense gaming sessions.
- **Reduced Fatigue:** The ergonomic design and customizable height can reduce strain on your thumbs and hands, allowing for longer, more comfortable gameplay.
- **Customizable Feel:** Experiment with different height combinations (e.g., a Mid-Rise on the left stick for movement and a High-Rise on the right stick for aiming) to find the setup that best suits your individual gaming style.

20.7mm



MID-RISE

↑
7mm



↑
8mm



HIGH-RISE

↑
9mm



↑
10mm



↑
11mm



↑
12mm



Finely Tuned Height & Sensitivity , Easier to Use.

Image Description: A close-up view of an Xbox controller with EXknight Controller Freaks installed on both analog sticks, showcasing their appearance and how they extend the height of the original thumbsticks.

EXknight Height Adjust Thumbsticks

Micro adjustment - Increase accuracy - Increase Comfort - Enhance control

★ 7 ~ 12MM off added height, micro sensitivity adjustment, increase accuracy

★ Surface diameter 20.7mm, increase range of motion

★ TPR anti-slip rubber, decrease hand&thumb fatigue




Image Description: A diagram illustrating the various height adjustments available for both Mid-Rise (7mm, 8mm) and High-Rise (9mm, 10mm, 11mm, 12mm) EXknight Controller Freaks, with measurements and benefits like increased range of motion and accuracy.

MAINTENANCE

To ensure the longevity and optimal performance of your EXknight Controller Freaks, follow these simple maintenance tips:

- **Cleaning:** Wipe the thumbsticks with a soft, dry cloth to remove dust and debris. For stubborn grime, a slightly damp cloth can be used, ensuring the thumbsticks are completely dry before re-use.
- **Storage:** When not in use, store the thumbsticks in a clean, dry place away from direct sunlight or extreme temperatures.
- **Inspection:** Periodically check the thumbsticks for any signs of wear or damage. Replace if necessary to maintain optimal grip and performance.

TROUBLESHOOTING

If you encounter any issues with your EXknight Controller Freaks, consider the following:

- **Thumbsticks feel loose or come off easily:**
 - Ensure the thumbstick extension is fully pressed down and securely clipped onto the analog stick.
 - Check if the original rubber on your controller's analog stick is worn out, as this can affect the grip of the extension.

- **Difficulty adjusting height:**

- Gently but firmly pull the two halves of the extension apart. They are designed to snap together securely, so some force may be needed.
- Ensure the internal mechanism is aligned correctly when reassembling.

- **Reduced grip or slippage:**

- Clean the textured surface of the thumbsticks to remove any oils or dirt that might reduce grip.

SPECIFICATIONS

Brand:	EXknight
Model Number:	M3-XS
Compatible Devices:	Xbox One Controller, Xbox Series Controller
Material:	Acrylonitrile Butadiene Styrene (ABS), Thermoplastic Rubber (TPR)
Color:	Black
Product Dimensions:	0.81 x 0.81 x 3.54 inches
Item Weight:	0.148 ounces

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the EXknight official website or contact their customer service directly. Keep your purchase receipt as proof of purchase.